

What Do Those Laundry Symbols Actually Mean?

Heat Level




Do Not Do This Action



Use Permanent Press Cycle¹



Use Delicate Cycle



Washing Symbols


How to wash



Hand Wash




Do Not Wash



Machine Wash




Machine Wash: Gentle or Delicate



Machine Wash: Permanent Press


Heat level




50°C or 120°F




30°C or 85°F



60°C or 140°F



40°C or 105°F



70°C or 160°F

Bleach usage



Ok to Bleach




Do NOT Bleach




Non-Chlorine Bleach If Needed

Drying Symbols


Air drying




Drip Dry



Hang Dry




Dry Flat




Dry in the Shade

Dryer cycles




Dry




Normal — Med. Heat



No Heat Tumble Dry



Normal — Low Heat




Normal — High Heat




Do NOT Tumble Dry

Permanent Press



Permanent Press Low Heat Tumble Dry




Permanent Press Tumble Dry Medium Heat




Permanent Press Tumble Dry No Heat


Gentle Cycle



Gentle Cycle Tumble Dry Low Heat




Gentle Cycle Tumble Dry Medium Heat



Gentle Cycle Tumble Dry No Heat

Ironing Symbols



Max. Temp. 110°C or 230°F



Max. Temp. 150°C or 300°F



Max. Temp. 200°C or 390°F




No Steam



Do Not Iron

Dry Cleaning Symbols



Dry Clean



Do NOT Dry Clean



Letter Tells the Dry Cleaner the Process

1. Permanent press may be labeled as a Wrinkle Shield™ option or Casuals cycle, depending on your washer.