




TOP AND CONSOLE PARTS

ELECTRIC DRYER

For Models: GEW9250PW1, GEW9250PL1, GEW9250PT1
(White/Platinum) (Pewter) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS


For Models: GEW9250PW1, GEW9250PL1, GEW9250PT1
(White/Platinum) (Pewter) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8578185	Use & Care Guide
	8558722	Tech Sheet
	8563723	Guide, Quick Start
2		Top
	8519251	White
	3980096	Pewter
	8519252	Biscuit
3	8529983	Harness, Main
4		Panel, Console
	8558748	Platinum
	8558751	Pewter
	8558750	Biscuit
5	3394427	Clip, Harness
6	8519271	Bracket, Console
7	353424	Connector, Sensor
8	94614	Terminal
9	3936144	Plug, Terminal
10	94613	Terminal
11	3390647	Screw, 8-18 x 1/2
12	488886	Screw, 8-18 x 1/2
13	8519406	Bezel, Cycle
14	3936150	Connector, 7-Circuit
15	3395683	Connector, (Motor)
16	8281225	Screw, 8-18 x 1/2
17	2203186	Connector, 5-Circuit
18		Knob, Assembly
	46197020472	Platinum
	46197020742	Pewter
	46197020741	Biscuit
19		User Interface
	8558753	Platinum
	8558756	Pewter
	8558755	Biscuit
20	8561811	Button, Start
21	8561812	Button, Pause/Cancel

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: GEW9250PW1, GEW9250PL1, GEW9250PT1
(White/Platinum) (Pewter) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS


For Models: GEW9250PW1, GEW9250PL1, GEW9250PT1
(White/Platinum) (Pewter) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8317342	Cover, Terminal Block	19	8283288	Wire, Jumper (Includes Illus. #41)	39	3388674	Idler Bracket
2	3390814	Screw, 8-18 x 3/8	20	690997	Tri Ring	41	8519323	Switch, Door
3	697776	Screw, 10-32 x 5/8 (Ground)	21	8066115	Cover-Plate	42	98129	Screw, 6-20 x 1 1/16
4	3397659	Block, Terminal	22	8529053	Ramp, Door	43	3390647	Screw, 8-18 x 1/2
5	3394881	Switch, Broken Belt	23	8521961	Dry Rack Support	44	3387242	Seal, Front Panel
6	8521959	Dry Rack (Top)	24		Panel, Side (R.H.)	45	3393008	Screw, 10-16 x 1/2
7		Panel, Side (L.H.)		8519213	White	46	8519459	Clip, Toe Panel
	8519209	White		8519217	Pewter	50	8519207	Base, Cabinet
	8519216	Pewter		8519214	Biscuit	51		Front Panel
	8519210	Biscuit	25	8521957	Dry Rack Assembly		8562167	White
8	3392100	Foot, Dryer	26	3393657	Restrainer, Belt		8562169	Pewter
	279810	Foot - Optional (Extended Length Package Of 2) (Not Included)	27	8538263	Motor, Assembly 60 HZ.		8562168	Biscuit
9	660658	Clamp, Motor (2)	28	3398948	Wire, Jumper (Broken Belt Switch)	52	696144	Strike, Door (2)
10	3387374	Spring, Idler	29	3389729	Pulley 60 HZ.	53	90767	Screw, 8-18 x 3/8
11	3389420	Retainer, Idler	30	3387610	Belt, Drive	55	8299925	Harness, Digital Interface
12		Plug, Multivent	32	3387118	Bracket, Motor	56	8519273	Bracket, Control
	697750	White	33	279393	Terminal Block Screw Kit (For Terminal Block)	57	8546219	Control Board
	3979261	Pewter	34	49026	4" - 90° Elbow	59	3400826	Screw, 8-18 x 3/4
	3388311	Biscuit	36	3395532	Exhaust Pipe & Bracket	61		Toe, Panel
13	3388672	Pulley Assembly	37	3395534	Exhaust Pipe (Short)		8519233	White
14	279318	Terminal, Brass & Tinned (3) (Includes Illus. 33)	38	3395535	Exhaust Pipe (Long)		3980095	Pewter
15	8066120	Lever, Snap Switch					8519234	Biscuit
16	3394081	Wire, Belt Switch				62	8519219	Panel, Rear
17	8564132	Sound Panel				63	692400	Nut, Push-In
18	233520	Washer, Thrust				64	343641	Screw, 10-16 x 1/2
						Optional Parts Not Included		
						Dryer Exhaust Kit (For Side & Bottom Venting)		
						66	279818	White
							279969	Pewter
							279925	Biscuit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: GEW9250PW1, GEW9250PL1, GEW9250PT1
(White/Platinum) (Pewter) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS


For Models: GEW9250PW1, GEW9250PL1, GEW9250PT1
(White/Platinum) (Pewter) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8575324	Shaft, R.H. Thread	18	3387459	Washer, Support	36	3403634	Socket Assembly
2	3390647	Screw, 8-18 x 1/2	19	8575325	Shaft, L.H. Thread	37	697772	Wheel, Blower
3	3394984	Door, Lint Screen	20	690997	Ring, Tri	39	3394986	Spring, Lint Screen Door
4	3406653	Harness, Sensor	21	8536973	Roller, Support	42	3976615	Thermistor
5	697354	Air Duct Assembly	22	8563745	Exhaust Pipe	43	487909	Screw, 8-15 x 1/2
6	697813	Seal, Outlet Housing	23	3394985	Housing, Outlet	44	8544362	Housing, Blower
7	697814	Seal, Drum Front	24	8529007	Plug, Rear Bulkhead	45	8066168	Lint Duct Assembly
8	3934666	Nut, 3/8 x 16(R.H.)	25	8299966	Complete Drum Assembly	46	3392537	Heater Box
9	8066086	Drum Hole Plug	26	97787	Screw, 11-16 x 3/4	47	8318314	Thermal Cut-Off (Includes Illus. 48)
10	3402841	Lens, Drum Light	27	697694	Seal, Drum	48	3391914	Thermostat 295°F (146°C)
11	489463	Screw, 8-18 x 3/8	28	695240	Screw, 8-18 x 1/2	49	8066099	Bracket, Heater Box
12	8572105	Clip, Exhaust Pipe	29	90767	Screw, 8-18 x 3/8	51	3387230	Screw, 10-16 x 1
14	3387747	Heater Element	30	8519221	Channel Bracket, Rear Bulkhead (2)	53	697693	Baffle, Drum
15	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)	31	8519275	Bracket, Upper Rear Bulkhead	54	8519245	Bulkhead, Front
16	W10001120	Nut, 3/8-16 (L.H.)	33	3406124	Bulb, Light	58	8299979	Grill, Outlet
17	8520836	Bulkhead, Rear	34	3387223	Electrode, Sensor	59	3392519	Thermal Fuse
			35	3977373	Bracket, Drum Light	60	697770	Seal, Cover Plate
						64	8066170	Lint, Screen

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: GEW9250PW1, GEW9250PL1, GEW9250PT1
(White/Platinum) (Pewter) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	8563855	Plug, Strip
2	8559709	Door Hinge Assembly
3	8534015	Screw
4	9742177	Screw, 8-18 x 5/8
5	8529539	Bracket, Handle
7	8559739	Handle, Door (LH)
	8559739	Platinum
	8559743	Pewter
	8559741	Biscuit
		(Following Parts Not Included)
		Handle, Door (RH)
	8559738	Platinum
	8559742	Pewter
	8559740	Biscuit
8	3357011	Screw, 10-16 x 1/2
9		Door Assembly (Outer)
	8572960	Platinum
	8572962	Pewter
	8572961	Biscuit
10	8557501	Door Assembly (Inner) (Includes Illus. 12)

Illus. No.	Part No.	DESCRIPTION
11	355515	Screw, 8-18 x 11/16
12	3389441	Door Catch Assembly
14	8529540	Badge, Assembly
15		Filler Handle (LH)
	8528289	Platinum
	3980082	Pewter
	3979771	Biscuit
		(Following Parts Not Included)
		Filler Handle (RH)
	8528287	Platinum
	3980101	Pewter
	3979772	Biscuit
16		Cover-Hinge, Stationary (RH)
	8559713	Platinum
	8559719	Pewter
	8559717	Biscuit
		(Following Parts Not Included)
		Cover-Hinge, Stationary (LH)
	8559712	Platinum
	8559718	Pewter
	8559716	Biscuit

Illus. No.	Part No.	DESCRIPTION
17		Cover-Hinge, Rotating
	8559722	Platinum
	8559724	Pewter
	8559723	Biscuit
18	8547091	Clip, Trim Panel
19		Trim & Clip Assembly (Lower)
	8558683	Platinum
	8558685	Pewter
	8558684	Biscuit
20		Trim & Clip Assembly (LH)
	8558687	Platinum
	8558692	Pewter
	8558690	Biscuit
21		Trim & Clip Assembly (RH)
	8558689	Platinum
	8558693	Pewter
	8558691	Biscuit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: GEW9250PW1, GEW9250PL1, GEW9250PT1
(White/Platinum) (Pewter) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

PAINT, TOUCH-UP (1/2oz.)

	72017	White
	4396174	Pewter
	4392899	Biscuit

PAINT, PRESSURIZED SPRAY (12 oz.)

	350930	White
	4396175	Pewter
	4392901	Biscuit
	350938	Primer, Gray

PAINT, BULK (1 qt.)

	799344	White (Uncut)
	4392900	Biscuit (Uncut)

ACCESSORY PARTS

	8529894	Kit, Hold Down
	8541503	Kit, Stack Assembly
		Kit, Door Reversing
	8530070	Platinum
	8530072	Pewter
	8530071	Biscuit
	80047	Kit, Dryer Repair