


OVEN PARTS

For Models: WOS92EC0AB00, WOS92EC0AW00, WOS92EC0AS00, WOS92EC0AE00, WOS93EC0AH00
(Black) (White) (Stainless) (Black Ice) (White Ice)



30" BUILT-IN ELECTRIC
SINGLE OVEN
WITH CONVECTION



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


OVEN PARTS

For Models: WOS92EC0AB00, WOS92EC0AW00, WOS92EC0AS00, WOS92EC0AE00, WOS93EC0AH00
(Black) (White) (Stainless) (Black Ice) (White Ice)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts Installation Instructions	11	W10282960	Gasket	25	W10351278	Bumper & Screw
	W10351242	English	12	W10282985	Exhaust, Vent Cover	26	W10412722	Lens, Light
	W10075750	French	13	W10318190	Side, Chassis	27	7101P426-60	Screw
	W10351318	Undercounter, Installation Instructions	14	W10282990	Back, Chassis	28	4450038	Screw
	W10354186	Use & Care Guide Tech Sheet	15		Liner, Oven (Not Serviceable)	29	W10283016	Grommet, Front Frame
	W10425193	English	16	7430P043-60	Sensor	30	W10347649	Spacers, Front
	W10425194	French	17	W10392683	Bumper, Rail	31	W10318196	Chassis, Back Duct Upper
2	W10282946	Tube, Cavity Vent	18	4449751	Thermostat	32	8285593	Cover, Connector
3	W10282975	Receiver, Hinge	19	W10282900	Base, Chassis	33	W10282984	Base, Exhaust Vent
4	W10318220	Spacer, Base	20		Assembly, Bottom Vent	34	W10412711	Bulb, Light
5	W10314880	Latch, Motorized		W10327373	Black	35	W10254050	Screw
6	W10282980	Top, Chassis		W10351279	Stainless	FOLLOWING PARTS NOT ILLUSTRATED		
7	W10260262	Light, Indicator	21	W10283008	Chassis, Bottom Duct			
8	W10318219	Foot, Base	22		Trim, Bottom Vent	INSULATION		
9	W10351258	Bracket, Blower Deflector		W10351236	Black			
10	W10283036	Vent, Top 30"		W10327377	Stainless			
			23	W10213759	Support, Air Channel	W10282942	Insulation, Wrap	
			24	W10351308	Chassis, Bottom Duct Spacer	W10282944	Insulation, Cavity	

OVEN DOOR PARTS

For Models: WOS92EC0AB00, WOS92EC0AW00, WOS92EC0AS00, WOS92EC0AE00, WOS93EC0AH00
(Black) (White) (Stainless) (Black Ice) (White Ice)



Illus. No.	Part No.	DESCRIPTION
1	W10347596	Assembly, Window Pack
2	W10284285	Spring, Door Glass Fixation
3	3196183	Screw
4		Badge
	W10481433	Black
	W10481434	White
5	W10320791	Assembly, Liner Welded 30"


Illus. No.	Part No.	DESCRIPTION
6	W10419876	Hinge, Door
7		Assembly, Door Glass
	W10352597	Black
	W10352598	White
	W10329434	Stainless
	W10416019	Black Shadow
	W10416020	White Chromium

Illus. No.	Part No.	DESCRIPTION
8		Door Handle
	W10327379	Black
	W10327380	White
	W10329434	Stainless
9	W10284901	Liner, Inner Glass
10	W10284297	Bracket, Glass
11	488130	Screw
12	7101P426-60	Screw
13	7101P653-60	Screw
14	7101P635-60	Screw
15	W10392683	Bumper, Rail

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS


For Models: WOS92EC0AB00, WOS92EC0AW00, WOS92EC0AS00, WOS92EC0AE00, WOS93EC0AH00
(Black) (White) (Stainless) (Black Ice) (White Ice)



Illus. No.	Part No.	DESCRIPTION
1	W10260252	Element, Broil
2	W10317430	Rack, Oven
3	W10318198	Tray, Hidden Bake
4	7101P376-60	Screw
5	7101P426-60	Screw
6	W10282957	Tray, Hidden Bake Crossbar
7	W10282948	Element, Bake
8	W10204157	Motor, Convection Fan
9	W10116349	Nut
10	W10116351	Blade, Fan
11	W10260248	Element, Ring
12	W10359278	Baffle
13	4449154	Screw

CONTROL PANEL PARTS

For Models: WOS92EC0AB00, WOS92EC0AW00, WOS92EC0AS00, WOS92EC0AE00, WOS93EC0AH00
(Black) (White) (Stainless) (Black Ice) (White Ice)



Illus. No.	Part No.	DESCRIPTION
1		Assembly, Control Panel (Includes Overlay)
	W10329412	Black
	W10329413	White
	W10329411	Stainless
	W10416013	Black Shadow
	W10416014	White Chromium
2	W10286213	Board, MRC2 Display
3	W10283075	Board, MRC2 Main

Illus. No.	Part No.	DESCRIPTION
4	W10363824	Spacer, Lateral
5	W10286217	Blower
6	7101P403-60	Screw
7	W10436434	Fuse, Thermal
8	7101P426-60	Screw
9	7101P434-60	Screw
10		Bracket, Blower
	W10351257	Left
	W10283078	Right
11	4451758	Block, Foam

Illus. No.	Part No.	DESCRIPTION
12	7401P038-60	Block, Terminal
13	W10347650	Tray, Electronic
14	W10318191	Chassis, Divider Back
15	W10351292	Gasket, Rubber
16	W10318192	Chassis, Cover Top Front 30"
17	W10318194	Chassis, Cover Top Back 30"
18	7103P027-60	Nut, Terminal Block

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: WOS92EC0AB00, WOS92EC0AW00, WOS92EC0AS00, WOS92EC0AE00, WOS93EC0AH00
(Black) (White) (Stainless) (Black Ice) (White Ice)

Illus.	Part
No.	No. DESCRIPTION

PAINT, TOUCH-UP (1/2oz.)

72017 White
72032 Black

PAINT, SPRAY

350930 White
261900 Citrine White
830864 Black

ADHESIVE

482338 Sealer, Silastic
(3 oz.)

WIRING HARNESS PARTS

W10260278 Harness, Main
W10284933 Harness,
Door Latch
W10409840 Harness, EOL
4450952 Conduit, Single
4448664 Clamp
W10318214 Bracket, Harness
313438 Clip
4450800 Screw, Ground
4452400 Lead,
Ground Strap

ACCESSORIES

4396923 Broiler Pan & Grid
31462 Stainless Steel
Cleaner & Polish
31682 All Purpose
Appliance Cleaner