



REFRIGERATOR


MODELS:

WRF560SMYW02 (White)

WRF560SMYB02 (Black)

WRF560SMYM02 (Monochromatic Stainless)

CABINET PARTS




CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10596092	Service and Wiring Sheet
	W10458270	Energy Label
	W10360467	Use & Care Guide
	2225623	Icemaker Service Sheet
2		Hinge, Top
	W10546298	Left Hand
	W10546299	Right Hand
3		Roller, Front
	W10359256	Left Hand
	W10359255	Right Hand
4	W10569758	Water Filter
5	W10352217	Clamp, Tube
6	2262176	Screw
7	489497	Screw
8		Cover, Toe Grille
	W10339257	White
	W10353930	Black
	W10353932	Grey
9	489442	Screw
10	W10141622	Brake, Roller

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
11	W10449880	Tube, Filter Inlet
12	549193	Clamp, Power Cord
13	489497	Screw
14		Hinge, Center
	W10521411	Left Hand
	W10521409	Right Hand
15	W10450363	Shim, Center Hinge
16	W10001260	Screw
17		Rail, Center (Not Serviced)
18		Fitting, Water Tube (NOT SERVICED)
19	W10346257	Housing, Water Filter
20		Corner Filler
	W10283959	White
	W10283960	Black
	W10283961	Grey
21		Grille
	W10300127	White
	W10353933	Black
	W10353935	Grey
22	W10331226	Drum, Toe Grille

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
23		Cover, Hinge
	W10465765	Left Hand (White)
	W10465764	Right Hand (White)
	W10465771	Left Hand (Black)
	W10465770	Right Hand (Black)
	W10465768	Left Hand (Grey)
	W10465767	Right Hand (Grey)
24	W10449611	Tube, Filter Outlet
25	W10306392	Cover, Water Filter
26	W10601149	Fitting, Water Tube
27	W10444800	Cover, Unit
28		Cabinet (Not a Serviceable Part)
29	1106508	Gasket, Seal
30	2174706	Clip, Roller


LINER PARTS



LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	15	488208	Screw	29	489478	Screw
2	2197380	Grommet	16	W10300900	Cover, Evaporator	30	2254454	Bracket, Evaporator Fan Rear
3	W10468762	Gasket, Evaporator Cover	17	W10317182	Tower, Freezer	31	W10313917	Housing, Freezer Lighting
4	W10360497	Assembly, LED Light	18	W10383615	Thermistor, Freezer Evaporator	32	W10313918	Lens, Light
5	W10469878	Housing, Light	19	1118894	Switch, Rocker Arm (Refrigerator)	33	W10440814	Socket, Light
6	W10326338	Container, Water Reservoir	20	W10413160	Cover, Water Reservoir	34	W10473925	Bulb, Light
7	12466105	Switch, Light	21	W10647626	UI Assembly	35	W10257451	Damper, Electronic Control
8	W10487766	Assembly, Freezer Wire	22	W10438761	Thermistor, Freezer	36	W10474774	Cover, Damper Housing
9	W10360550	Cover, Control Housing	23	W10425252	Cover, Thermistor	37	W10314204	Housing, Damper
10	W10464673	Motor, Fan	24	W10330850	Grille, Air Filter Bottom	38	W10448448	Assembly, Multiflow
11	2200509	Blade, Fan	25	W10315189	Filter, Air	39	W10438639	Thermistor, Refrigerator
12	W10435577	Housing, Control	26	W10336009	Cup, Screw			
13	W10356895	Tower, Multiflow Air	27	W10314195	Shield, Heat			
14	W10421350	Assembly, Refrigerator Lighting Wire	28	W10321162	Bracket, Fan Motor			


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Refrigerator Door (Includes #8)	5		Badge, Whirlpool	11	W10462299	Condiment Caddy
	W10393587	Left Hand (White)		W10481434	White	12	W10326335	Shallow Bin
	W10353181	Right Hand (White)		W10481433	Grey	13		Flipper Mullion Assembly
	W10413522	Left Hand (Black)	6	W10470155	Closure, Door		W10624451	White
	W10413518	Right Hand (Black)	7	W10308869	Bin, Medium		W10624448	Black
	W10413524	Left Hand (Stainless)	8		Gasket, RC		W10624450	Grey
	W10413519	Right Hand (Stainless)		W10353189	Beige	14	12990302	Screw
2	2189202	Bracket, Door Stop		W10413465	Black	15	W10170540	Screw
3	489276	Screw		W10413468	Grey	16	W10287054	Screw, Set
4	W10366270	Thimble, Top (White)	9		Handle Assembly	17	939101	Screw Anchor
	W10334042	Thimble, Top (Black)		W10357233	White			
				W10398786	Black			
				W10356566	Stainless			
			10	W10317224	Compartment, Utility			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Freezer Door (Includes Items 2 & 3)	3		Gasket, FC	4		Handle Assembly
	W10433606	White		W10465758	Beige		W10357241	White
	W10433607	Black		W10465761	Black		W10389516	Black
	W10433608	Stainless		W10465762	Grey		W10357240	Stainless
2	W10334042	Thimble, Top (Black)				5	W10378263	Pan, Ice
						6	W10170540	Screw
						7	W10287054	Screw, Set

UNIT PARTS




UNIT PARTS


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10300116	Plate, Unit Mounting	18	2179826	Axle, Rivet	36	W10510988	Tube, Suction
2	2319835	Grommet, Condenser	19	8533859	Screw	37	2219077	Clip, Harness
3	W10342567	Condenser	20	W10236396	Strap, Compressor	38	2215468	Insulation, Sound
4	W10436849	Heater, Defrost	21	W10174384	Strap, Bale	39	W10314197	Bracket, Evaporator
5	W10321158	Assembly, Evaporator	22	W10466213	Tray, Drain	40	2263990	Tie, Wire
6	8533961	Screw	23	W10349514	Cover, Condenser Bottom	Following Parts Not Illustrated		
7	W10314195	Shield, Heat	24	W10390445	Assembly, Unit Wire			
8	W10519112	Valve, Drain	25	W10139483	Blade, Fan			
9	W10314199	Tube, Drain	26	VS20001	Tube, Process			
10	W10248621	Clip, Condenser	27	488500	Screw			
11	W10424230	Assembly, Low Voltage Wire	28	W10445423	Compressor			
12	W10547719	Electronic Control	29	W10190413	Drier			
13	W10370696	Enclosure, Electronic Control	30	2264017	Capacitor			
14	10835903	Grommet	31	2315541	Baffle, Air			
15	W10448874	Device, Start	32	W10508362	Motor, Condenser			
16	W10313215	Cover, Electronic Control	33	W10296661	Clip, Bottom Cover	REFRIGERANT CHARGE		
17	W10475495	Roller	34	1114718	Clip, Wiring	4.25 oz (R-134A)		
			35	8281232	Screw			

SHELF PARTS

REFRIGERATOR




FREEZER



SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10486290	Assembly, Full Shelf (30")	10	W10356844	Humidity Control	19	W10257246	Axle, Roller
2	W10502933	Shelf Assembly, 2/3 Flip	11	W10513681	Glass, Pantry Cover	20	W10317289	Basket, Lower Freezer
3	W10468557	Rail, Track (Center)	12	W10397907	Assembly, Pantry Deli Pan	21	W10371538	Shaft, Rack
4	W10313893	Shelf, 2/3 Flip	13	W10317191	Pantry Rail, Left Hand	22	W10277361	Collar, Gear
5	W10468556	Rail, Track (Right Hand)	14	W10317189	Pantry Rail, Right Hand	23		Adaptor, Freezer
6	W10468555	Rail, Track (Left Hand)	15	W10278139	Roller		W10397636	Left Hand
7	W10370327	Pan, Crisper (16")	16	W10411411	Control, Temperature		W10397635	Right Hand
8	W10317184	Pan, Crisper (8")	17	W10507470	Assembly, Pantry Cover Support	24	W10346771	Filter, Produce Preserver
9	W10408748	Holder, Produce Filter	18	W10555437	Bin, Upper Freezer			

ICEMAKER PARTS



ICEMAKER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10329003	Clamp, Tube	10	628228	Mold & Heater Assembly (Also Order 542638)	18	489276	Screw
2	628320	Bracket, Icemaker Mounting	11	W10435665	Cup, Water Fill	19	W10474785	Shut Off Arm
3	628379	Clip, Thermal Fuse	12	627843	Ejector	20	W10309400	Assembly, Ice Maker Wire
4	2181939	Insert, Tube	13	W10122563	Stripper, Ice	21	489136	Screw
5	W10279909	Valve, Inlet	14	2194712	Support, Housing	22	W10223929	Assembly, Module and Motor
6	W10496649	Tube, Water	15	2315522	Retainer, Thermostat	100	W10632400	Icemaker Assembly
7	488208	Screw	16	628397	Thermostat (Also Order 542369 Cement Alumilastic)			
8	W10289690	Cover, Icemaker	17	W10001280	Screw			
9	489478	Screw						

OPTIONAL PARTS

FOLLOWING PARTS NOT ILLUSTRATED

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	W10413645A	Filter, Water (1/4 turn)
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	511873	White Porcelain (2 oz.)
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	606755	Bag
	503695	Cork, Sealer

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350942	White Primer
	350939	Enamel, Black
	350930	White
	4392901	Biscuit/Bisque

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White
	4392900	Biscuit/Bisque

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key