



French Door Bottom Mount Refrigerator


MODELS:

WRF560SMYW05 (White)

WRF560SMYB05 (Black)

WRF560SMYM05 (Stainless Steel)

CABINET PARTS




CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10641015	Service and Wiring Sheet
	W10727388	Energy Guide
	W10360467	Use and Care Guide
	2225623	Icemaker Service Sheet
2		Hinge, Top
	W10546298	Left Hand
	W10546299	Right Hand
3		Roller, Front
	W10359256	Left Hand
	W10359255	Right Hand
4	W10569758	Filter, Water
5	W10352217	Clamp, Tube
6	2262176	Screw
7	489497	Screw
8		Cover, Toe Grille
	W10339257	White
	W10353930	Black
	W10353932	Grey
9	489442	Screw
10	W10141622	Brake, Roller

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
11	W10449880	Tube, Filter Inlet
12	549193	Clamp, Power Cord
13	489497	Screw
14		Hinge, Center
	W10770878	Left Hand
	W10770877	Right Hand
15	W10450363	Shim, Center Hinge
16	W10001260	Screw
17		Rail, Center (Not Serviced)
18		Fitting, Water Tube (NOT SERVICED)
19	W10346257	Housing, Water Filter
20		Corner Filler
	W10283959	White
	W10283960	Black
	W10283961	Grey
21		Grille
	W10300127	White
	W10353933	Black
	W10353935	Grey
22	W10331226	Drum, Toe Grille

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
23		Cover, Hinge
	W10465765	Left Hand (White)
	W10465764	Right Hand (White)
	W10465771	Left Hand (Black)
	W10465770	Right Hand (Black)
	W10465768	Left Hand (Grey)
	W10465767	Right Hand (Grey)
24	W10449611	Tube, Filter Outlet
25	W10306392	Cover, Water Filter
26	W10601149	Fitting, Water Tube
27	W10636716	Cover, Unit
28		Cabinet (Not a Serviceable Part)
29	1106508	Gasket, Seal
30	2174706	Clip, Roller


LINER PARTS



LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	14	W10384183	Thermistor, Refrigerator Compartment	26	W10336009	Cup, Screw
2	2197380	Grommet	15	488208	Screw	27	W10314195	Shield, Heat
3	W10468762	Gasket, Evaporator Cover	16	W10300900	Cover, Evaporator	28	W10321162	Bracket, Fan Motor
4	W10448448	Assembly, Multiflow	17	W10317182	Tower, Freezer	29	489478	Screw
5	W10469878	Housing, Light	18	W10383615	Thermistor, Freezer Evaporator	30	2254454	Bracket, Evaporator Fan Rear
6	W10798439	Container, Water Reservoir	19	1118894	Switch, Rocker Arm	31	W10313917	Housing, Freezer Lighting
7	12466105	Switch, Light	20	W10413160	Cover, Water Reservoir	32	W10313918	Lens, Light
8	W10487766	Assembly, Freezer Wire	21	W10689396	UI Assembly	33	W10440814	Socket, Light
9	W10360550	Cover, Control Housing	22	W10438761	Thermistor, Freezer	34	W10809515	Bulb, Light
10	W10464673	Motor, Fan	23	W10425252	Cover, Thermistor	35	W10745484	Damper, Electronic Control
11	2200509	Blade, Fan	24	W10330850	Grille, Air Filter Bottom	36	W10474774	Cover, Damper Housing
12	W10435577	Housing, Control	25	W10315189	Filter, Air	37	W10314204	Housing, Damper
13	W10356895	Tower, Multiflow Air						


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Refrigerator Door (Includes #8)	5		Badge, Whirlpool	11	W10462299	Caddy, Condiment
	W10393587	Left Hand (White)		W10481434	White	12	W10326335	Bin, Shallow
	W10353181	Right Hand (White)		W10481433	Grey	13		Flipper Mullion Assembly
	W10413522	Left Hand (Black)	6	W10470155	Closure, Door		W10624451	White
	W10413518	Right Hand (Black)	7	W10308869	Bin, Medium		W10624448	Black
	W10413524	Left Hand (Stainless)	8		Gasket, RC		W10624450	Grey
	W10413519	Right Hand (Stainless)		W10353189	Beige	14	12990302	Screw
2	2189202	Bracket, Door Stop		W10413465	Black	15	W10170540	Screw
3	489276	Screw		W10413468	Grey	16	W10397055	Bracket, Door Stop
4		Thimble	9		Handle Assembly	17	939101	Screw Anchor
	W10366270	White		W10686459	White			
	W10334042	Thimble, Top (Black)		W10686442	Black			
				W10686482	Stainless			
			10	W10317224	Compartment, Utility			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Freezer Door (Includes Items 2 & 3)	2		Thimble	4		Handle Assembly
	W10433606	White		W10366270	White		W10357241	White
	W10433607	Black		W10334042	Thimble, Top (Black)		W10389516	Black
	W10433608	Stainless	3		Gasket, FC		W10357240	Stainless
				W10465758	Beige	5	W10170540	Screw
				W10465761	Black			
				W10465762	Grey			


UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10300116	Baseplate	20	W10236396	Strap, Compressor	40	2263990	Tie, Wire
2	2319835	Grommet, Condenser	21	W10174384	Strap, Bale	41	2258429	Heat Probe
3	W10342567	Condenser	22	W10466213	Tray, Drain	42	489478	Screw
4	W10436849	Heater, Defrost	23	W10349514	Cover, Condenser Bottom	Following Parts Not Illustrated		
5	W10321158	Assembly, Evaporator	24	W10637509	Assembly, Unit Wire			
6	8533961	Screw	25	W10139483	Blade, Fan	978025	Valve, Access	
7	W10314195	Shield, Heat	26	VS20001	Tube, Process	978026	Valve, Access	
8	W10519112	Valve, Drain	27	488500	Screw	978027	Valve, Access	
9	W10314199	Tube, Drain	28	W10445423	Compressor	978028	Valve, Access	
10	W10248621	Clip, Condenser	29	W10669573	Drier	978029	Valve, Access	
11	W10424230	Assembly, Low Voltage Wire	30	W10590083	Capacitor	978030	Valve, Access	
12	W10547719	Control, Electronic	31	2315541	Bracket, Condenser Fan	876764	Valve, Access	
13	W10370696	Enclosure, Electronic Control	32	W10530280	Motor, Condenser	REFRIGERANT CHARGE 4.25 oz (R-134A)		
14	10835903SP	Grommet, Compressor	33	W10815861	Clip, Bottom Cover			
15	W10448874	Device, Start	34	1114718	Clip, Wiring			
16	W10313215	Cover, Electronic Control	35	8281232	Screw			
17	W10475495	Roller	36	W10510988	Tube, Suction			
18	2179826	Axle, Rivet	37	2219077	Clip, Harness			
19	8533859	Screw	38	2215468	Insulation, Sound			
			39	W10314197	Bracket, Evaporator			


SHELF PARTS



SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10486290	Assembly, Full Shelf (30")	11	W10513681	Glass, Pantry Cover	21	W10802342	Shaft, Rack
2	W10502933	Assembly, 2/3 Flip Shelf	12	W10397907	Assembly, Pantry Deli Pan	22	W10277361	Collar, Gear
3	W10468557	Rail, Track (Center)	13	W10397908	Rail Pantry (Left Hand)	23		Adaptor, Freezer
4	W10313893	Shelf, 2/3 Flip	14	W10414530	Rail, Pantry (Right Hand)		W10397636	Left Hand
5	W10468556	Rail, Track (Right Hand)	15	W10278139	Roller		W10397635	Right Hand
6	W10468555	Rail, Track (Left Hand)	16	W10346771	Filter, Produce Preserver	24	W10378263	Pan, Ice
7	W10370327	Pan, Crisper (16")	17	W10507470	Assembly, Pantry Cover Support			
8	W10317184	Pan, Crisper (8")	18	W10555437	Bin, Upper Freezer			
9	W10408748	Holder, Produce Filter	19	W10257246	Axle, Roller			
10	W10356844	Control, Humidity	20	W10317289	Basket, Lower Freezer			

ICEMAKER PARTS



ICEMAKER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10329003	Clamp, Tube	11	W10435665	Cup, Water Fill	21	489136	Screw
2	628320	Bracket, Icemaker Mounting	12	627843	Ejector	22	W10223929	Assembly, Module and Motor
3	628379	Clip, Thermal Fuse	13	W10699925	Stripper, Ice	100	W10632400	Assembly, Icemaker
4	2181939	Insert, Tube	14	2194712	Support, Housing			
5	W10498995	Valve, Inlet	15	2315522	Retainer, Thermostat			
6	W10496649	Tube, Water	16	628397	Thermostat (Also Order 542369 Cement Alumilastic)			
7	488208	Screw	17	W10001280	Screw			
8	W10289690	Cover, Icemaker	18	489276	Screw			
9	489478	Screw	19	W10474785	Arm, Shut Off			
10	628228	Assembly, Mold and Heater (Also Order 542638)	20	W10309400	Assembly, Ice Maker Wire			

OPTIONAL PARTS

FOLLOWING PARTS NOT ILLUSTRATED

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	W10413645A	Filter, Water (1/4 turn)
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	511873	White Porcelain (2 oz.)
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	606755	Bag
	503695	Cork, Sealer
	8003RP	Kit, Water Inlet

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350942	White Primer
	350939	Enamel, Black
	350930	White
	4392901	Biscuit/Bisque

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	4392900	Biscuit/Bisque

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key