




30" GAS DOUBLE OVEN RANGE

MODELS:

WGG745S0FE01 (Black Ice)
WGG745S0FH01 (White Ice)
WGG745S0FS01 (Stainless)

COOKTOP PARTS




COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10841342	Guide, Use & Care
	W10575961	Instructions, Installation
	W10647745	Sheet, Tech
	9762761	Tips, Safe Cooking (English)
	W10065852	Tips, Safe Cooking (French)
	W10776010	Insert, Grill Pan
2		Kit, Burner Cap
	W10299236	Black
3		Cooktop (Includes Hinges)
	W10785917	Black
	W10785916	White
4	W10406878	Head, Burner (17.5K)
		(Left Front)
	W10406243	Head, Burner (6K)
		(Left Rear & Right Rear)
	W10406797	Head, Burner (Right Front)
	W10336094	Head, Burner (Center)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5		Knob, Control
	W10850036	Stainless
6	W10518258	Bracket, Cooktop Support
7	8016P022-60	Glide, Main Top
8		Set, Grate
	W10814166	Black
9		Panel, Manifold
	W10828392	Black
	W10828396	White
	W10823297	Stainless
10	W10333445	Base, Burner (Fish Burner Only)
11		Kit, Burner Cap (Fish Burner Only)
	W10171140	Black
12		Endcap, Manifold
	W10719582	Black (Left)
	W10719581	Black (Right)
	W10719580	White (Left)
	W10719579	White (Right)
	W10823301	Stainless (Left)
	W10823299	Stainless (Right)
13	3196160	Screw
14	W10850043	Bezel

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
15		Hinge, Grate (Not Serviced)
		FOLLOWING PARTS NOT ILLUSTRATED
	W10745674	Harness, Main
	W10409840	Harness, EOL (MRC)
	W10408058	Harness, Spark
	W10745683	Harness, Sensor & Locks
	7111P017-60	Clamp, Wire
	8019P026-60	Clip, Wire

CONTROL PANEL PARTS




CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Support, Backguard
	W10319109	Black (Left)
	W10319110	White (Left)
	W10319111	Black (Right)
	W10319112	White (Right)
2	7101P338-60	Screw
3		Console
	W10318551	Black
	W10318552	White
	W10318550	Stainless

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	7101P633-60	Screw (Black)
	7101P636-60	Screw (White)
5	W10828153	Control
6		Assembly, Membrane (Including Bracket)
	W10826681	Black
	W10826682	White
	W10840440	Stainless
7	W10278697	Shield, Vent
8	7101P434-60	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
9	W10776098	Cover, Backguard
10	W10309232	Insulation, Wire Cover

MANIFOLD PARTS




MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10319002	Tubing, Broil
2	W10643268	Holder, Orifice (17K)
		(Left Front)
	W10643269	Holder, Orifice (5K)
		(Left Rear)
	W10643270	Holder, Orifice (10K)
		(Right Front)
	W10643271	Holder, Orifice (5K)
		(Right Rear)
	W10643272	Holder, Orifice (7K)
		(Center)
3	W10368614	Valve, Shut Off
4	W10546238	Valve/Regulator
5	W10664240	Harness, Switch
6	W10324738	Ignitor, Gas
7	W10806878	Assembly, Manifold
8	W10718180	Valve (17K)
		(Left Front & Right Front)
	W10718182	Valve (5K)
		(Left Rear & Right Rear)
	W10718181	Valve (10K)
9	7103P030-60	Nut, Wing

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
10	W10315768	Burner, Broiler
11	W10407912	Burner, Bake
12	W10342662	Orifice, Bake
		(Upper)
	W10342661	Orifice, Bake
		(Lower)
13	7432P143-60	Ignitor, Bake
14	W10298865	Shield, Bake
15	W10292293	Fitting, Broiler
16	4005F421-45	Cover, Ignitor Wire
17	7103P195-60	Nut, Mounting
18	7101P426-60	Screw
19	W10295997	Screw, Valve
20	W10272528	Baffle, Bake
21	W10631502	Grommet, Valve Stem
22	3601F358-45	Baffle, Broil Burner
23	8273062	Screw
24	W10524331	Tubing (Supply Regulator to Shutoff)
25	7101P653-60	Screw
26	W10642388	Tubing (Supply Shutoff To Manifold)
27	W10272520	Bracket, Orifice
28	W10319059	Bracket, Spark Module
29	W10295996	Bracket, Saddle Valve

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
30	W10217535	Screw
31	W10324366	Holder, Electrode Extension
32	W10636384	Extension, Electrode
33	7431P053-60	Module, Spark
34	7101P434-60	Screw
35	7101P502-60	Screw
36	W10565365	Electrode, Spark
	W10637673	Electrode, Fish
37	W10276466	Bracket, Manifold (Bottom)
		Following Parts Not Illustrated
	W10591270	Kit, LP Conversion
	W10324646	Insulation, Orifice

CHASSIS PARTS




CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10319038	Shield, Gemini
2	W10237689	Spacer, Side Panel
3	W10267456	Screw, Shoulder
4		Assembly, Side Panel
	W10330375	Black
	W10330376	White
5	3801F656-51	Bracket, Anti-Tip
6	W10319000	Gasket, Gemini Oven
7	W10260703	Shield Support, Lower Oven
8	7101P507-60	Foot, Leveler
9	W10105790	Bumper & Screw
10	7430P044-60	Sensor, Oven
11	W10268558	Cover, Lower Wire
12	7101P635-60	Screw (Black)
13	W10261387	Cover, Main Wire
14	W10311326	Assembly, Flue (Upper)
	W10272519	Assembly, Flue (Lower)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
15	W10668728	Back, Main
16	W10321446	Assembly, Outlet Flue (Upper)
	W10321445	Assembly, Outlet Flue (Lower)
17	4449040	Screw
18	W10319087	Bracket, U Channel
19	7101P485-60	Screw, Anti-Tip Kit
20	W10324643	Support, Insulation
21	W10454648	Assembly, Light
22	W10683517	Lock, Rear Mount
23	W10538516	Shield, Side Insulation
24	W10357697	Bracket, Side Panel
25	W10318928	Gasket, Oven Door
		(Upper)
	W10269069	Gasket, Oven Door
		(Lower)
26	7101P426-60	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
27	W10410463	Cover, Hinge (Left)
	W10410461	Cover, Hinge (Right)
28	W10272546	Bottom, Oven
29	311255	Bulb, Oven Light
30	8285593	Cover, Connector
		INSULATION
	W10344586	Insulation, Floor
	W10318910	Insulation, Wrapper
		(Upper)
	W10318918	Insulation, Back
		(Upper)
	W10318911	Insulation, Wrapper
		(Lower)
	W10204081	Insulation, Back
		(Lower)

UPPER DOOR PARTS




UPPER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10485720	Lining, Door
2	W10272707	Glass, Inner
3	W10272708	Frame, Glass
4	W10292297	Screw
5	W10485723	Retainer, Insulation
6	W10321271	Insulation, Door
7	W10289077	Receiver, Hinge

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8		Assembly, Door
	W10675404	Black Ice
	W10675403	White Ice
9	W10485733	Hinge, Door (Left)
	W10485732	Hinge, Door (Right)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
10		Standoff, Handle
	W10410341	Black
	W10429492	White
11		Handle, Door
	W10254687	Stainless
12		Assembly, Door
	W10845039	Stainless


LOWER DOOR PARTS



LOWER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Handle, Door	5	W10272594	Frame, Glass	12	W10321285	Insulation, Door
	W10254687	Stainless	6		Standoff, Handle	13	W10272329	Receiver (Left)
2		Assembly, Door		W10410341	Black		W10272328	Receiver (Right)
	W10675400	Black Ice		W10429492	White	14		Badge
	W10675399	White Ice	7	9757706	Glass, Inner		W10481433	Grey
3	W10294695	Bracket, Handle	8	W10335434	Hinge, Door (Left)		W10481434	White
		(Black Ice & White Ice Models Only)		W10335433	Hinge, Door (Right)	15		Assembly, Door
	W10575689	Bracket, Handle	9	W10272698	Lining, Door		W10845037	Stainless
		(Stainless Models Only)	10	W10292297	Screw	16	7109P084-60	Washer, Fiber
4	W10317886	Screw	11	W10340464	Retainer, Insulation			

INTERNAL OVEN PARTS



INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10179152	Rack, Oven	4	W10631504	Nut, Acorn	7	4449154	Screw
2	W10631506	Motor, Convection	5	W10274268	Insulation, Convection Motor	8	4448988	Cover, Fan
3	W10631503	Blade, Fan	6	W10339476	Plate, Insulation	9	W10249980	Element, Convection (120 VAC)

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		REFINISHING MATERIAL
	242756	Oven Liner Touch Up Paint
		INSULATION
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")
		PAINT, TOUCH-UP (1/2oz.)
	72017	White
	72032	Black
	4392899	Biscuit/Bisque PAINT, SPRAY
	350930	White
	285006	Black
	4392901	Biscuit/Bisque
	350956	Almond
	350938	Gray Primer
	350942	White Primer
		PAINT, BULK (1 qt.)
	799344	White (Uncut) ACCESSORIES
	31463A	Protectant, Cooktop
	31617A	Cleaner, Grate & Drip Pan
	WA906B	Scraper, Cooktop
	31605	Kit, Cooktop Care
	W10391473	Pad, Cooktop Cleaning
	W10355016	Cleaner, Stainless Steel
	W10275756	Cleaner, Granite
	W10355051	Cleaner, Cooktop
	W10123240	Rack, Broiler Pan & Roasting
	W10355049	Wipes, Stainless Steel Cleaning
	W10355010	Cleaner, Kitchen & Appliance
	4396923	Broiler Pan and Grid