




36" GAS COOKTOP

MODELS:

WCG55US6HB00 (Black)

WCG55US6HW00 (White)


COOKTOP, BURNER AND GRATE PARTS



COOKTOP, BURNER AND GRATE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	8286814	Head, Burner (Left Front & Left Rear)	13		Hinge, Grate (Not Serviced)
	W11116971	Instructions, Installation		8286815	Head, Burner (Right Front & Center)			FOLLOWING PARTS NOT ILLUSTRATED
	W10672375	Instructions, Undercounter Install		8286813	Head, Burner (Right Rear)		W10868535	Harness, Main
	W11120470	Guide, Use & Care			Grommet		W10392003	Cord, Power
	W11168236	Instructions, LP Conversion	9				W10132200	Relief, Strain
2		Cooktop		W10625915	Black		313438	Clip, Harness
	W11131857	Black		W10614849	Grey		3801F935-51	Bracket, Tie Down
	W11131861	White	10	8286921	Screw, Burner Rail (M4)		7101P062-60	Screw (For Tie Down Bracket)
3		Kit, Burner Cap	11	W10652710	Orifice (Left Front & Left Rear)		W11173306	Kit, LP Conversion
	W10597133	Black						
4		Kit, Grate		W10409144	Orifice (Right Front)			
	W11047088	Black		W10652711	Orifice (Right Rear)			
5	8286863	Spring, Electrode		W10609592	Orifice (Center)			
6		Knobs, Cooktop						
	W11084622	Black						
	W11084621	White						
7	W10594402	Holder, Orifice (9.1K) (Left Front & Left Rear)	12	W10541842	Wiring, Electrode (Left Front, Right Front & Center)			
	W10597159	Holder, Orifice (12K) (Right Front)		W10541843	Wiring, Electrode (Left Rear & Right Rear)			
	W10594399	Holder, Orifice (5K) (Right Rear)						
	W10609591	Holder, Orifice (15K) (Center)						

BURNER BOX, GAS VALVES AND SWITCH PARTS



BURNER BOX, GAS VALVES AND SWITCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8287057	Screw, Valve Bracket	5	W10140571	Seal, Switch Shaft	13	W10566308	Tubing, Gas Burner (Right Front)
2	W10594396	Assembly, Manifold	6	W10614951	Panel, Front	14	W10566307	Tubing, Gas Burner (Right Rear)
3	W10594392	Valve, Single (Left Front)	7	W10449143	Regulator, Pressure	15	W10566302	Tubing, Gas Burner (Center)
	W10594391	Valve, Single (Left Rear & Center)	8	W10594429	Bracket, Orifice Holder	16	7101P426-60	Screw
	W10594393	Valve, Single (Right Front)	9	W10475149	Module, Spark (5+0)			OPTIONAL PARTS (NOT INCLUDED)
	W10597156	Valve, Single (Right Rear)	10	W10735657	Box, Burner		W10685483	Griddle
4	8287055	Bracket, Single Valve	11	W10566305	Tubing, Gas Burner (Left Front)			Kit, Grates
			12	W10566306	Tubing, Gas Burner (Left Rear)		W10594443	Gray