




FRENCH DOOR BOTTOM MOUNT REFRIGERATOR

MODELS:

KRMF706EBS01 (Black Stainless)

KRMF706ESS01 (Stainless Steel)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	15		Hinge, Center	30	W10577369	Cover, Unit
		Tech Sheet		W10691674	Black	31	M0108107	Clamp, Tube
	W10844356	English		W10691675	Grey	32	12990302	Screw
	W10844357	French	16	W10336736	Cover, Roller	33	W10913008	Tube, Water
	W10730912	Owners Manual	17		Cover, Corner	34	W10705239	Retainer, Door
	W11112988	Energy Guide		12587703B	Black	35		Cabinet (Not a Servicable Part)
2	W10624574	Supply, Power		12587703AP	Grey			
3	W10734555	Block, Pivot	18	W10394076	Valve, Water	36	549193	Clamp, Power Cord
4	W10505487	Gasket	19		Assembly, Roller	37	W10141645	Screw
5	W10811365	Board, Control		W10515763	Left Hand	38		Cover, Top Hinge
6	W10415341	Gasket, HV Box		W10515762	Right Hand		W10709867	Black
7	A3076901	Plug, Button	20	W10709365	Screw		W10709866	Grey
8	W10141622	Brake, Roller	21	W10908701	Bushing, Hinge	39		Hinge, Center
9	12992602	Screw	22		Grille, Toe		W10691700	Black
10		Hinge, Top		W10707422	Black		W10691701	Grey
	W11027247	Left Hand		W10707958	Grey			
	W11027248	Right Hand	23	12992601	Screw			
11	W10673840	Screw (Stainless)	24	12990702	Screw			
12		Cover, Top Hinge	25	W10141645	Screw			
	W10781438	Black	26	12990511	Screw			
	W10781436	Grey	27	W10788814	Supply, LED Power			
13	W10277839	Lid, HV	28	W10754591	Cover, Control Box			
14	W10731474	Screw	29	W10565413	Switch, Light			


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	18	W10503486	Enclosure, Evaporator	35	W10738349	Assembly, Evaporator Cover
2	W10826118	Housing, Water System	19	W10525237	Pan, Drain	36	W10465948	Gasket, Evaporator Enclosure
3	W10736144	Tube, Fill	20	W10785113	Trim, Icebox	37	W10510863	Gasket, Drain Tube
4	W10711460	Reservoir, Water (Also Order Wire Tie Part 8567668)	21	W10833801	Fan, Icebox	38	W10320706	Gasket, Rear Return
5	W10341329	Valve, Dual Water	22	W11035765	Assembly, Evaporator	39	W10280988	Gasket, Rear Supply
6	W11165806	Housing, Water Filter	23	W10843339	Assembly, LED Module	40	W10392172	Gasket, Fan
7	W10811115	Enclosure, Water Valve	24	W10799016	Motor, Evaporator Fan (Includes Wire Harness)	41	W10749499	Assembly, Air Tower
8	W10754145	Cover, Waterbox	25	W10754348	Assembly, Icebox Fascia (Includes Heater)	42	W10843828	Harness, LED Wire (Includes LED lights)
9	2223877	Latch, Push	26	C3680310V	Switch, Light	43	W10673048	Jumper, Fascia Heater
10	W10754143	Door, Filter Access	27	W10470981	Gasket, Damper	44	W10723352	Waterline
11	W10680605	Filter, Water	28	W10280983	Insulation	45	W10722983	Connector, Water Tube
12	W10315189	Filter, Air	29	W10389152	Support, Fan	46	W10713934	Bracket, Connector
13	W10674102	Waterline, Valve To Hinge	30	W10749701	Assembly, Icebox Adapter	FOLLOWING PARTS NOT ILLUSTRATED		
14	W10820065	Heater, Fill Tube	31	W10503491	Retainer, Damper			
15	12990518	Screw	32	W10503492	Support, Damper	W10821278	Assembly, Dual Valve Box Wire	
16	W10598013	Cover, Icebox	33	W10248595	Damper, Electronic Control			
17	W10811681	Assembly, Icebox (Foamed)	34	W10438957	Cover, Thermistor			


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	8	12990504	Screw	14	W10503218	Assembly, Drain Funnel
2	A3189392	Gasket, Foam	9	W10280385	Thermistor	15	M0500703	Seal
3	W10843353	Assembly, LED Light Module	10	W10363507	Shroud, Evaporator Fan	16	B8381501	Gasket, Drain
4	W10736933	Assembly, Evaporator Cover (Freezer)	11	12986101	Blade, Fan	17	W10698555	Cover, Thermistor
5	12990501	Screw	12	W10905511	Grommet, Fan Motor			
6	12956601	Clip, Fan Motor	13	W11039078	Motor, Evaporator (Includes Harness Thermistor, and Defrost Thermostat)			
7	W10565415	Switch, Light						


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator (Includes Item 2)	10		Bumper, Door	25	W10567563	Gasket, Ice Chute
	W10634613	Black Stainless		W10407187	Black	26	W10646867	Vent, Thermistor
	W10634612	Stainless		W10407188	Grey	27	W10563323	Door, Emitter
2		Gasket, Door	11	W10331749	Pin, Door	28	W10663692	Tube, Water
	W10873946	Black	12	W10460893	Screw	29		Closer, Door
	W10873944	Grey	13	W10737419	Trivet, 2 Liter		W10714907	Left Hand
3	W10238319	Screw	14	W10737416	Bucket, Gallon		W10714908	Right Hand
4	W10564705	Door, Ice	15	12993001	Screw	30		Door, Refrigerator
5		Bracket, Stopping	16	W10567561	Gasket, Ice Door			(Includes Item 2)
	W10708583	Black	17	W10737415	Frame, Bin		W10634619	Black Stainless
6		Mullion, Door	18	W10518658	Board, Receiver Circuit		W10634618	Stainless
	W10752977	Black	19	W10563326	Cover, Receiver			FOLLOWING PARTS NOT ILLUSTRATED
	W10752974	Grey	20	2198635	Spring, Door		8558100	Wrench, 3/32" Hex
7	12990204	Screw	21	W10563309	Cover, Emitter			
8		Handle, Door	22	W10563328	Slide, Icemaker Shut Off			
	W10680044	Stainless	23	W10832970	Board, Emitter Circuit			
9	12990504	Screw	24	W10562839	Retainer, Ice Chute			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer (Includes Item 17)	7	12990518	Screw	15	W10738961	Assembly, Center Pan (Freezer)
	W10634625	Black Stainless	8	W10738962	Assembly, Upper Pan (Freezer)	16		Stop, Pan
	W10634624	Stainless	9	W10709748	Clip, Shaft		W10585151	Left Hand
2		Handle, Door	10	W10562492	Divider, Lower		W10585150	Right Hand
	W10687115	Stainless	11	W10469177	Support, Pan	17		Gasket, Door
3	W10460893	Screw	12	W10738960	Assembly, Pan Front		W10248748	Black
4	W10503522	Shaft	13	489443	Screw (Stainless)		W10248749	Grey
5		Assembly, Bracket	14		Adapter, Upper Pan	18	W10518672	Badge
	W10795771	Left Hand		W10619221	Left Hand	19	W10643690	Axle, Roller
	W10795769	Right Hand		W10619220	Right Hand	20	W10248555	Roller, Pan
6	W10634640	Assembly, Lower Pan (Freezer)						

UNIT PARTS




UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10141625	Screw
2	2188935	Blade, Fan
3	W10570074	Baseplate
4	12990511	Screw
5	W10776916	Extension, Drain
6	W10634642	Assembly, 3 Way Valve
7	W10303521	Sleeve
8	W10660727	Tray, Evaporator
9	W10622701	Screw
10	12729128	Heater, Defrost
11	W10710090	Assembly, Inverter Box
12	W10248621	Clip, Condenser
13	12477102	Roller
14	12992101	Screw
15	10835903	Grommet
16	W10758093	Condenser
17	W10391376	Bracket, Valve

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
18	W10342573	Tray, Drip
19	W10142255	Screw
20	W10248589	Assembly, Evaporator
21	W10709318	Coil, 3 Way Valve
22	W10909387	Motor, Condenser Fan
23	10428101	Clip, Heater
24	W10672162	Assembly, Unit Wire (Includes Power Cord)
25	W10286069	Drier
26	W10756020	Compressor
27	W10491355	Gasket, Airdam
28	12477202	Axle, Roller
29	W10406719	Shroud
30	W10626970	Assembly, Suction Tube
31	W10278140	Cover, Condenser (Bottom)
32	W10815861	Clip, Bottom Cover

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
33	W10236396	Strap, Compressor
34	W10141518	Screw
35	W10142294	Screw
36	2169104	Sealer, Insulation
		FOLLOWING PARTS NOT ILLUSTRATED
	978025	Valve, Access (1/4")
	978026	Valve, Access (5/16")
	978027	Valve, Access (3/8")
	978029	Valve, Access (5/8")
	978030	Valve, Access (3/4")
	876764	Valve, Access (3/16")
		REFRIGERANT CHARGE
		6.00 oz. (R-134A)


SHELF PARTS



SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10737428	Assembly, Tuck Shelf	13	98006631	Screw	37		Handle, Door
2		Assembly, Secondary Mullion	14	W10704335	Clip, Drawer Body		W10680045	Stainless
	W10849115	Black	15	W10664603	Screw	38	W10460893	Screw
	W10849118	Grey	16	W10719660	Ladder, Side	39	W10843353	Assembly, LED Light Module
3	W10325002	Screw	17	W10732765	Clip, Glide Door	40	W10512203	Harness, Side Adapter
4	W10801137	Assembly, Crisper	18	W10730610	Drawer, Pantry	41		Interface, User
5	W11088993	Assembly, Lighted Shelf	19	W10719661	Ladder, Center		W10769076	Stainless
6	W10847515	Assembly, Crisper Cover	20	12991401	Screw	42	W10826105	Assembly, Produce Preserver
7		Door, Pantry (Includes Item 8)	21	W10666373	Screw	43	W10847369	Support, Front
	W10733264	Black Stainless	22	W10638123	Guide, Crisper	44	W10634636	Assembly, Herb Bin
	W10733263	Stainless	23	W10709891	Divider, Pantry Pan	45	W10847589	Assembly, Pantry Center Adapter
8		Gasket, Pantry	24	W10899596	Assembly, Floor	46		Door, Pantry (Includes Item 8)
	W10712392	Black	25	C3680310V	Switch, Light		W10738905	Black Stainless
	W10685868	Grey	26	12466104	Switch, Rocker		W10738904	Stainless
9	W10756314	Assembly, Shelf	27	W10737605	Screw			
10		Adapter, Pantry	28	W10549991	Thermistor			
	W10718060	Left Hand	29	W10711821	Cover, Connector			
	W10718059	Right Hand	30	W10493547	Support, Crisper Rear			
11	W10788795	Roller	31	W10893770	Glass, Crisper			
12		Glide, Compact (Also Order Items 27 and 35)	32	12702901	Pad, Glide			
	W10847525	Left Hand	33	W10634635	Assembly, Secondary Mullion Bin			
	W10735385	Right Hand	34		Assembly, Mullion Cover			
				W10733545	Black			
				W10733546	Grey			
			35	W10737730	Nut, Rivet			
			36	W10731491	Cover, Side Adapter			


DISPENSER FRONT PARTS



DISPENSER FRONT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	5	W10654548	Assembly, Seperator	11	W10403752	Switch, Limit
2		Assembly, User Interface	6	W10435760	Guide, Ice	12	W10712476	Assembly, Switch Jumper Wire
	W10852741	Black	7		Tray, Drip			
				W10654552	Black			
3		Wall, Dispenser False	8		Ring, Trim			
	W10654549	Black		W10654551	Chrome			
4		Assembly, Pad	9	W10470750	Assembly, LED			
	W10663646	Black	10	W10663682	Spring, Torsion			

ICEMAKER AND ICE CONTAINER PARTS



ICEMAKER AND ICE CONTAINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10272364	Screw	5	W10347114	Shaft, Motor	9	W11109572	Assembly, Icemaker
2	W10664669	Assembly, Ice Chute Plate	6	W10215646	Motor, Dispenser	10	W10291905	Gasket
3	2198628	Seal	7	8281163	Screw (Stainless)			
4	W10347120	Clip, Retainer	8	W10564750	Assembly, Ice Container			

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	W10917540	Midnight Grey
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	20000008	Cleaner, Stainless Steel
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key