



30" ELECTRIC BUILT-IN COOKTOP


MODELS:

WCE55US0HB00 (Black)

WCE55US0HW00 (White)

WCE55US0HS00 (Stainless)

COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	9		Knob, Control	13	4455917	Bracket, Cooktop Mounting
	W11178304	Instructions, Installation		W11130625	Black	14	3400093	Screw
	W10351318	Instructions, Undercounter Install		W11130629	White	15	7101P426-60	Screw
	W11161549	Guide, Use & Care	10	W10578768	Switch, Infinite (Left Front & Right Rear)	16	7101P309-60	Screw
2		Cooktop		W10843843	Switch, Infinite (Left Rear)	17	W11172719	Plate, Switch
	W11120971	Black		W10437092	Switch, Infinite (Right Front)	18	W11175477	Rail, Vertical
	W11120973	White				19	W11171776	Rail, Horizontal Rear
	W11120972	Stainless						FOLLOWING PARTS NOT ILLUSTRATED
3		Trim, Front Stainless (Not Serviced)	11	8273994	Element (1200W) (Left Front & Right Rear)	W11111805		Harness, Main
4	W11172720	Shield, Switch				3400015		Screw, Grounding
5	W10225448	Spring, Element		8273993	Element (1800W) (Left Rear)	3192439		Seal, Limiter
6	W11171777	Rail, Horizontal Front				8008P068-60		Grommet, Wire (Black)
7		Grommet		W10275049	Element (2500/1200W) (Right Front)	W10324729		Grommet, Wire (Gray)
	W10293874	Black				8286642		Tape, Foam
	W10372006	Grey				W11161211		Insulation, Cooktop (Knob)
8		Box, Burner (Not Serviced)	12	3183956	Seal, Switch Cover			

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		ACCESSORIES
	WA906B	Scraper, Cooktop
	W10355051	Cleaner, Cooktop
	31464	Cleaner, Cooktop
	31463	Protectant, Cooktop
	242905	Kit, Canning Unit
	31605	Kit, Cooktop Care