




**30" ELECTRIC FREESTANDING RANGE  
(Radiant Elements)**

**MODELS:**

AER6303MFS2 (Stainless)


# COOKTOP PARTS



# COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5	8273993	Element (1800W) (Left Front and Right Rear)	8	W10306542	Bracket, Anti-Tip
	W11047681	Instructions, Installation				9	7101P485-60	Screw, Anti-Tip Kit
	W10881062	User Instructions		8273994	Element (1200W) (Right Front and Left Rear)			FOLLOWING PARTS NOT ILLUSTRATED
	W10842026	Sheet, Tech					W11134840	Harness, Wire (Main)
	W10873903	Diagram, Wiring	6	3196169	Screw		W11171894	Harness, Cooktop (Left)
2	W10225448	Spring, Element	7	W10607641	Bracket, Cooktop (Left)		W11134551	Harness, Cooktop (Right)
3	W10691223	Pan, Radiant Element		W10607642	Bracket, Cooktop (Right)			
4		Cooktop						
	W10853124	Black						


# CONTROL PANEL PARTS



# CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	4	3148952	Switch, Infinite (Yellow)	7		Knobs
	W11130372	Black (Left)					W10844802	Stainless
	W11130379	Black (Right)			(Right Front and Left Rear)	8	W10134247	Shield, Heat
2	W10525121	Bracket, Console Mounting		3148953	Switch, Infinite (Green)	9	3400882	Screw
3		Panel, Console			(Left Front and Right Rear)	10	8272473	Cover, Upper Rear
	W11157018	Stainless				11		Electronic, Control (LCX)
			5	W10695491	Bracket, Control		W11204487	Black
			6	3196178	Screw			


# CHASSIS PARTS



# CHASSIS PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10289077	Receiver, Hinge	14	W10137382	Clip, Panel	25	W10571723	Bulb, Halogen 40 Watts
2	W10134285	Tube, Vent	15	W10390007	Assembly, Base Rail (Right)	26	W10281322	Kit, Bare Wire Adapter Block
3		Panel, Side		W10390008	Assembly, Base Rail (Left)	27	3196154	Screw
	W10162245	Black				28	W10910404	Counterweight
4	W10031780	Screw	16	W10058460	Foot, Leveling	29	W11034869	Screw
5	W10129032	Seal, Door	17	3196548	Fuse, Thermal			FOLLOWING PARTS NOT ILLUSTRATED
6	9757340	Element, Broil	18	3196172	Screw		W10333344	Insulation, Flue
7	W11111743	Element, Bake	19	W10404688	Clip, Oven Support		8273263	Insulation, Wrap
8	W10326122	Cover, Terminal Block	20	3186034	Bracket, Service		8272611	Insulation, Back
9	3196169	Screw	21	W10245259	Block, Terminal			
10	W10268578	Rack, Oven	22	W10289149	Back, Main			
11	W10341186	Assembly, Front Foot	23	W10181986	Sensor, Oven			
12	W10067840	Screw	24	W11175594	Assembly, Light			
13	8054068	Retainer, Insulation						

# DOOR PARTS






# DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Top
	W10310922	Black
2	3196165	Screw
3		Handle, Door
	W10144883	Stainless
4	9761344	Liner, Door
5	W10031790	Screw
6	W10620754	Glass, Inner
7	9761505	Retainer, Insulation

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10299225	Hinge, Active
	W10299227	Hinge, Door (Passive)
9		Badge
	W10846752	Stainless
10		Trim, Side
	W10746436	Black (Left)
	W10746435	Black (Right)
11	W10327235	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
12		Glass Assembly, Outer Door
	W11170209	Stainless
13	W10544179	Strap, Door
14	W10200660	Screw

# DRAWER AND BROILER PARTS



# DRAWER AND BROILER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front	3	W10462910	Bracket, Mounting Drawer	4	W10674708	Glide, Drawer Rear
	W10330070	Stainless					W10674705	Glide, Drawer Front
2	W10688022	Drawer, Storage				5	3196165	Screw

# OPTIONAL PARTS

## REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

## INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

## PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	8212473	Universal Silver
	511873	White Porcelain (2 oz.)

## PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	206922	Primer (White)

## PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

## ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	241430	Aluminum Foil
	3191048	Glass Cleaner
	4396923	Grid, Broiler Pan and