




SIDE BY SIDE REFRIGERATOR

MODELS:

WRSA71CIHN00 (Sunset Bronze)

WRSA71CIHZ00 (Stainless)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	15		Hinge, Bottom (Freezer)	26	W10279882	Tube, Filter Inlet
	W10669500	Use and Care Guide		W11126848	Grey	27	W10279884	Tube, Filter Outlet
	W10858356	Tech Sheet	16		Hinge, Bottom (Refrigerator)	28	W10370680	Fitting, Drain
	W11173776	Energy Guide		W11084346	Grey	29	12957702	Lid, HV Box
2	2150304	Roller	17		Closer, Door (Refrigerator)	30	W10887255	Control, Electronic
3	W10297485	Screw		W10877804	Grey	31		Cabinet (Not A Serviceable Part)
4	12477102	Roller	18	W10141645	Screw	32	W10247993	Box, Control
5	12477202	Axle, Roller	19	549193	Clamp, Power Cord	33	2223388	Clip, Axle Retainer
6	981125	Rivet, Roller	20	W10257238	Cover, Unit	34	W10341320	Assembly, Dual Water Valve
7	W10379525	Tube, Drain	21		Filler, Wrapper	35	W10691732	Tube, Water
8	W10900758	Bracket, Foot		12587703AP	Grey	36	W10141625	Screw
9	W10141622	Brake, Roller	22		Grille	37	W11175632	Locking Ring (1/4)
10	W10308751	Screw (Black)		W10713153	Grey		W11175631	Locking Ring (5/16)
11	W10498992	Valve, Inlet	23	W10142234	Screw	38	W10237915	Bracket, Water Valve
12		Hinge, Top (Freezer)	24		Closer, Door (Freezer)			
	W10901054	Grey		W10770893	Grey			
13		Hinge, Top (Refrigerator)	25	W10001250	Screw			
	W10901049	Grey						
14	W10308489	Screw (Grey)						


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	7	W10280385	Thermistor	13	W10893232	Cover, Light
2	W10735398	Filter, Water	8	W10425252	Cover, Thermistor	14	2162085	Socket, Light
3	W10300482	Cover, Water Filter	9	W10394053	Housing, Water Filter	15	W10366790	Reservoir
4	W11175955	Assembly, Air Diffuser	10	W10457603	Cover, Air Filter	16	W11125625	Lamp, LED
5	W10457601	Cover, Air Diffuser	11	W10271543	Connector, Water Tube	17	W10269099	Lens, Light
6	W11032814	Switch, Rocker Arm	12	W10134764	Socket, Light			


REFRIGERATOR SHELF PARTS



REFRIGERATOR SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10508311	Shelf, Snack Pan	5	W10508334	Assembly, Cover	9	W10292504	Pan, Crisper
2	W11034716	Handle, Trim	6	W10256846	Pan, Snack	10	W10256854	Pan, Meat
3	W10282883	Slide, Humidity	7	W10628713	Roller, Pan	11	W10773885	Assembly, Shelf
4	W10282880	Housing, Humidity	8	W10628712	Axle, Roller	12	W11084209	Handle, Trim


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	6	W10260983	Pan, Freezer (Also Order Item 7)	11	2162085	Socket, Light
2	W10527863	Assembly, Cover	7	W10628713	Roller, Pan	12	W11125625	Lamp, LED
3	W10773886	Shelf, Glass Upper	8	W10628712	Axle, Roller	13	W10269101	Lens
4	W10280386	Thermistor	9	W11034724	Trim, Handle	14	W10425252	Cover, Thermistor
5	W10773887	Shelf, Glass Lower	10	W10847853	Switch, Light			


MOTOR AND ICE CONTAINER PARTS



MOTOR AND ICE CONTAINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10774957	Container, Ice (Complete)	8	W10291905	Gasket	16	W10646076	Assembly, Wire Jumper Switch
2	W10693542	Assembly, Latch	9	W11130444	Assembly, Ice Maker	17	W10400435	Gasket, Foam
3	2220458	Coupling, Bottom	10	W11117906	Motor, Dispenser	18	W10765378	Assembly, Motor Box
4	W10258544	Shaft, Drive	11	W10669473	Cover, Container	19	W10166854	Gasket
5	W10754509	Spring, Coupling	12	W10691248	Plate, Switch			
6	W11240062	Assembly, Mounting Plate	13	W10666871	Rocker, Switch			
7	2305382	Boot, Rubber	14	W11032814	Switch, Rocker Arm			
			15	W10749467	Filler, EPS Icemaker Cover			


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator (Includes Item 5)	5		Gasket, Door	9		Closer, Upper Cam Door
	W11091615	Sunset Bronze		W10249916	Grey		W10257203	Grey
	W11091610	Stainless	6		Handle	10	W11204458	Screw
2	W10710203	Bin, Gallon Door		W10874780	Stainless	11	W10888898	Bracket, Door Stop
3	W10296816	Screw	7	2200086	Thimble, Top	12	W10884773	Badge
4	W10451873	Bin, Shallow Door	8		Cover, Door Stop	13	W10010140	Set Screw (Silver)
				W10789147	Grey			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer (Includes Item 4 and Dispenser Front Parts)	2		Handle	5	W10010140	Set Screw (Silver)
	W11089022	Sunset Bronze		W10874780	Stainless	6	W10430639	Bin, Door
	W11089011	Stainless	3	2200086	Thimble, Top	7	W10323148	Cover, Wire
			4		Gasket, Door	8	W10850872	Wire, Jumper
				W10249917	Grey			


DISPENSER PARTS



DISPENSER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Wall, Dispenser False	8	4449745	Screw	13		Tray, Drip
	W11084899	Sunset Bronze	9		Ring, Trim		W11084898	Sunset Bronze
	W10276226	Satina		W11087882	Chromium Frost		W10276225	Satina
2		Grate, Drip Tray	10	W11125625	Lamp, LED	14		Cover, Front
	W10276209	Stainless	11	W11174483	Assembly, User Interface (Includes Light Feature)		W10458867	Black
3	W10174827	Bracket, Ice Door				15	W10386778	Assembly, Water Fitting
4	W10435760	Guide, Ice	12		Pad, Ice and Water	16	W10691730	Tube, Water
5	W10205978	Motor, Dispenser		W10370582	Grey			
6	W10781994	Assembly, Separator						
7	W10346124	Support, Ice Door						


AIR FLOW PARTS



AIR FLOW PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10251462	Scroll, Fan	8	2169142	Blade, Fan	14	W10388268	Cover, Evaporator
2	W10260421	Retainer, Fan Motor	9	W10240370	Gasket, Evaporator Cover	15	W10260382	Cover, Light
3	W10260380	Duct, Upper Air	10	2176759	Grommet, Motor	16	W11125625	Lamp, LED
4		Bi-Metal Defrost (Not Serviced)	11	W10369602	Clip, Evaporator Cover	17	2162085	Socket, Light
5	W10260378	Duct, Freezer Air	12	W10242409	Assembly, Evaporator Fan Wire (Includes Bi-Metal Defrost)	18	W10331728	Clip, Air Duct
6	W10001260	Screw				19	W11205489	Foam
7	2315549	Motor, Fan	13	W10142292	Screw			

UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10271541	Connector, Union	19	W10714793	Tray, Evaporator (Includes Gasket)	32	W10771114	Drier
2	2225834	Blade, Fan						FOLLOWING PARTS NOT ILLUSTRATED
3	W10240365	Assembly, Condenser	20	W10274575	Shield, Heat		978025	Valve, Access (1/4")
4	W10142255	Screw	21	2169104	Insulation, Sound Deadening		978026	Valve, Access (5/16")
5	2212996	Strap, Bale	22	W10670174	Assembly, Unit Wire		978027	Valve, Access (3/8")
6	W10171469	Screw	23	W10277704	Basepan		978029	Valve, Access (5/8")
7	W10277958	Connector, Water	24	W10242407	Cord, Power		978030	Valve, Access (3/4")
8	W10303521	Sleeve	25	W10251467	Baffle, Air		876764	Valve, Access (3/16")
9	W10142287	Screw	26	W10495967	Heater, Defrost			REFRIGERANT CHARGE
10	W10815861	Clip, Bottom Cover	27	W10284726	Cover, Unit Bottom			5.0 oz. (R-134A)
11	W11117259	Tube, Suction	28	W10253005	Compressor (Also Order 876765 Tube Kit)			
12	W10248621	Clip, Condenser	29	10835903	Grommet			
13	W10236396	Strap, Compressor	30	W10197428	Device, Combination Start (Start Relay and Overload)			
14	2325479	Tube, Process	31	W10350564	Capacitor			
15	2205813	Tie, Wire						
16	2188822	Evaporator						
17	2161324	Clip, Defrost Heater						
18	W10909387	Motor, Condenser Fan						

OPTIONAL PARTS (NOT INCLUDED)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
				799344	White (Uncut)
	350942	White Primer		4392900	Biscuit/Bisque
	350939	Enamel, Black		8171358	Graphite
	350930	White			
	4392901	Biscuit/Bisque			
	8171357	Graphite			

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque
	80051	Graphite

PAINT, BULK (1 QT.)

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	W10300794	Kit, Handle Installation
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	4318168	Sealer
	8003RP	Kit, Water Inlet

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key