
2.1 CUBIC FOOT MICROWAVE HOOD

MODELS:


WMH75021HZ2 (Stainless)
WMH75021HV2 (Black Stainless)

© 2019 Whirlpool Corporation
Part No. W11345283 Rev. A

CONTROL PANEL PARTS




Literature Parts



CONTROL PANEL PARTS

Illus. No.	Part No.	Description
1		Literature Parts
	W11199602	Installation Instructions
	W11047548	Use and Care Guide
	W11265245	Quick Reference Guide
	W11268412	Tech Sheet
2		Board, Control (With Cover)
	W11334569	Black


DOOR PARTS



DOOR PARTS

Illus. No.	Part No.	Description
1		Door, Complete (Includes Control)
	W11334571	Stainless
	W11334570	Black Stainless
2	W10643974	Stopper, Door


INTERIOR AND VENTILATION PARTS



INTERIOR AND VENTILATION PARTS

Illus. No.	Part No.	Description
1	W10631826	Chassis
2	8206232	Lamp, 40 Watt
3	W10525853	Bracket, Smart Pop
4	W10535950	Filter, Grease
5	W10571126	Plate, Bottom
6	W10240330	Assembly, Lamp Glass and Holder
7	W10510237	Spacer, Smart Pop
8		Switches, Interlock
		(Not Serviced, Order Interlock Assemblies)
9	W11187757	Assembly, Interlock (Includes Switches)
10	W10533480	Holder, NTC
11	W10533502	Cover, Cooling Fan
12	W10533501	Housing, Cooling Fan
13	W10210871	Holder, Lamp
14	W10605897	Capacitor, Hood Motor
15	W10536989	Thermistor, PCBA
16	W10510235	Tube, Smart Pop Sound
17	W10510234	Terminal, Smart Pop
18	W11259891	Resistor, Cement
19	W10533503	Wheel, Cooling Fan
20	W11169357	Motor, Cooling Fan
21	W10631700	Air Guide, Magnetron
22	W10476901	Thermostat, Cavity 125/-35 Celcius
23	W11087316	Transformer, High Voltage
24	W10633730	Bracket, Capacitor
25	W10561770	Capacitor, High Voltage
26	W11222648	Diode, High Voltage
27	W10510233	Terminal, PCBA Smart Pop
28	W10540715	Bracket, Top Cavity
29	W10533481	Deflector, Air
30	W10540718	Bracket, Cavity
31	W10508748	PCBA, Smart Pop


AIR FLOW PARTS



AIR FLOW PARTS

Illus. No.	Part No.	Description
1	W10631697	Deflector, Air
2	8206382	Cover, Lamp
3	W10557536	Sensor, Humidity
4	4393681	Lamp, Cavity 30 Watt
5	W10533116	Plate, Air Deflector
6	W10726505	Motor, Fan
7	W10556824	Housing, Damper
8	8206230	Filter, Charcoal
9	W10571180	Seal, Foam
10	W10598693	Thermostat, Magnetron
11	W10531724	Glass, Lamp
12	W10210878	Socket, Cavity Lamp
13	W10533096	Baseplate, Air Guide
14	W10533484	Cover, Duct (Right)
15	W10531156	Board, Filter
16	W10810142	Socket, Motor Wire
17	W10533111	Outlet, Cavity (Back)
18	W10754514	Magnetron
19	W10629803	Shield, Finger (Includes Seal)
20	W10570207	Outlet, Cavity (Front)
21	W10138793	Fuse


TURNTABLE PARTS



TURNTABLE PARTS

Illus. No.	Part No.	Description
1	W10533497	Cover, Waveguide
2	W10740485	Hook, Microwave (Left Front & Right Front)
3	W10749119	Hook, Microwave (Left Rear)
4	W10531726	Turntable
5	W11193601	Ring, Turntable
6	W11193599	Driver, Turntable
7	W10642989	Motor, Turntable
8	W10637159	Rack, Microwave
9	8184109	Seal, Waterproof
10	W10749120	Hook, Microwave (Right Rear)

CABINET AND INSTALLATION PARTS



CABINET AND INSTALLATION PARTS

Illus. No.	Part No.	Description
1	W11025649	Plate, Mounting
2	W10748710	Damper
3	W10654511	Cord, Power
4		Case, Outer
	W11178713	Black
5		Grille, Vent
	W10701699	Black
6	W10625423	Cover, Fan Motor
7		Holder, Vent Left Side
	W10703285	Black
	W10703284	Stainless
8		Holder, Vent Right Side
	W10703283	Black
	W10703282	Stainless
9	W11122643	Assembly, Mounting Nut
		MISCELLANEOUS PARTS
	W10728970	Hardware, Installation
	W10190020	Template, Upper (English & Spanish)
	W10190018	Template, Upper (English & French)
	8169704	1/4-20x3" Panhead Screw
	W11185430	Harness, Main
	W10834334	Harness, Lamp and Turntable Motor
	W10539840	Harness, PCBA Ground Wire
	W10508746	Harness, Smart Pop
	W10508741	Wire, Door Control Cable