
AUTOMATIC WASHER

MODELS:

WFW3090GW0 (White)

© 2019 Whirlpool Corporation
Part No. W10913951 Rev. D


CONSOLE AND CABINET PARTS



CONSOLE AND CABINET PARTS

Illus. No.	Part No.	Description
1		Literature Parts
	W10856086	Use and Care Guide
	W10858389	Tech Sheet
	W10912027	Energy Guide
	W10858332	Quick Start Guide
2		Top
	W10565648	White
3	W11133415	Panel, Rear
4	W10525749	Clip, Drain Hose
5		Cabinet
	W10697253	White
6		Panel, Front
	W10721766	White
7		Panel, Toe
	W10564940	White
8	W10685844	Clip, Front Panel
9	W10632440	Retainer, Front Panel
10	W10866069	Lock, Door
11	W10590587	Cable-Door Lock, Emergency Open
12	W10644894	Foot, Leveling
13	W10583233	Bracket, Control
14	W10877360	Bracket, Cross Top
15	W10890713	Screw
16	W10917459	Harness, Main
17	W10658184	Channel, Cable
18		Assembly, Console
	W10778832	White
19		Handle, Drawer
	W10778836	White
20		Assembly, Timer Knob
	W10869886	Knob, Inner
	W10681351	Knob, Outer
21	W10852941	User Interface
22	251921305003	Screw
23	251914602042	Screw
24	W10840664	Timer/CCU (Complete)
25	W10868081	Plug, Transport Bolt
26	W10891902	Bolt, Transport
27	W10367632	Filter, RFI
28	W10849440	Power Cord
29	461972493421	Strain Relief, Power Cord
30	W10893953	Screw
31	461971019321	Clamp, Cable
32	W11091051	Screw
33	251926500053	Screw


DOOR PARTS



DOOR PARTS

Illus. No.	Part No.	Description
1	W10564923	Door, Outer Trim Ring
2	W10564947	Door, Inner Trim
3	W10765495	Door, Glass
4	W10564912	Door, Inner
5	W10564917	Strike, Door
6	W10758313	Screw
7	W10564919	Hinge, Door
8	461971424051	Bushing, Hinge (Outer)
9	251921201061	Screw


PUMP PARTS



PUMP PARTS

Illus. No.	Part No.	Description
1	W10846320	Pump
2	W10506380	Filter, Pump
3	W10512064	Screw
4	W10735354	Hose, Pump - Equalization
5	251971304004	Clamp
6	251971303031	Clamp
7	461971409193	Hose, Tub - Pump
8	461974081951	Ball, ECO
9	251971304005	Clamp
10	W10597311	Sensor, Pressure
11	W10676317	Hose, Pressostat
12	W10853581	Tank, Equalization
13	W10596633	Hose, Equalization - Pump
14	461974646281	Hose, Connector
15	W10887723	U-Bend


DISPENSER PARTS



DISPENSER PARTS

Illus. No.	Part No.	Description
1	W10580651	Dispenser, Lid (Assembly)
2	W10580668	Housing, Dispenser
3	W10580677	Siphon, Softener (Only)
4	W10868280	Drawer, Pre-Wash Detergent (No Bleach)
5	W10868281	Drawer, HE Detergent (Only)
6	251971300008	Clamp
7	461971409182	Hose, Dispenser - Tub
8	W10846345	Valve, Double
9	251912400003	Screw
10	251971304018	Clamp
11	W10887741	Hose
12	251925500045	Screw

TUB AND DRIVE PARTS



TUB AND DRIVE PARTS

Illus. No.	Part No.	Description
1	461971409631	Counterweight, Top
2	461971409681	Screw
3	W10816225	Spring, Suspension (Includes Retainer Clips)
4	461971421191	Counterweight, Front
5	W10761129	Bellow
6	461971408821	Retainer, Bellow - Tub
7	W10764497	Tub
8	W10597314	Lifter
9	W10847365	Heating Element
10	461971068751	Sensor NTC
11	W10884881	Shield, Heat
12	251924500002	Screw
13	461971415451	Damper Assembly
14	W10884517	Stator
15	W10780181	Screw
16	W10706381	Rotor
17	W10655372	Bolt, Rotor

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

Illus. No.	Part No.	Description
	72017	White

PAINT, PRESSURIZED SPRAY (12 OZ.)

Illus. No.	Part No.	Description
	350930	White
	350938	Gray Primer

PAINT, BULK (1 QT.)

Illus. No.	Part No.	Description
	799344	White (Uncut)

ACCESSORY PARTS

Illus. No.	Part No.	Description
	W10135699	Affresh® Washer Cleaner
	W10882520	Stack Kit, Compact Washer/Dryer
	89503	Hose, Inlet (5' Hose)