



SIDE BY SIDE REFRIGERATOR

MODELS:


WRS588FIHW00 (White)

WRS588FIHB00 (Black)

WRS588FIHV00 (Black Stainless)

WRS588FIHZ00 (Stainless Steel)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	15		Hinge, Bottom (Freezer)	24		Closer, Door (Freezer)
	W10787932	Use & Care Guide		W11088197	White		W10770896	White
	W11090558	Wiring Sheet		W11088196	Black		W10770895	Black
	W11090738	Energy Guide		W11088194	Grey		W10770893	Grey
2	2150304	Roller				25	W10001250	Screw
3	W10297485	Screw	16		Hinge, Bottom (Refrigerator)	26	W10279882	Tube, Filter Inlet
4	12477102	Roller		W10666898	White	27	W10279884	Tube, Filter Outlet
5	12477202	Axle, Roller		W11084348	Black	28	W10370680	Fitting, Drain
6	981125	Rivet, Roller		W11084346	Grey	29	12957702	Lid, HV Box
7	W10379525	Tube, Drain				30	W10887254	Control, Electronic
8	W10900758	Bracket, Foot	17		Closer, Door (Refrigerator)	31		Cabinet (Not A Serviceable Part)
9	W10141622	Brake, Roller		W10738913	White			
10	W10308750	Screw (White)		W10738914	Black	32	W10247993	Box, Control
	W10308751	Screw (Black)		W10738911	Grey	33	2223388	Clip, Axle Retainer
11	W10498992	Valve, Inlet	18	W10141645	Screw	34	W10876364	Tube, Water
12		Hinge, Top (Freezer)	19	549193	Clamp, Power Cord	35	W10811572	Insulating tube
	W10901051	White	20	W10333887	Cover, Unit	36	W10341320	Assembly, Dual Water Valve
	W10901052	Black	21		Filler, Wrapper			
	W10901054	Grey		12587703W	White	37	W10782424	Locking Ring (5/16)
13		Hinge, Top (Refrigerator)		12587703B	Black		W10782423	Locking Ring (1/4)
	W10901046	White		12587703AP	Grey			
	W10901047	Black	22		Grille	38	W10237915	Bracket, Water Valve
	W10901049	Grey		W10713160	White	39	W10141625	Screw
14	W10142283	Screw (White)		W10713158	Black			
	W10308487	Screw (Black)		W10713153	Grey			
	W10308489	Screw (Grey)	23	W10142234	Screw			


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	7	W10280385	Thermistor	13	W10893232	Cover, Light
2	W10735398	Filter, Water	8	W10425252	Cover, Thermistor	14	2162085	Socket, Light
3	W10300482	Cover, Water Filter	9	W10394053	Housing, Water Filter	15	W10366790	Reservoir
4	W10869522	Assembly, Air Diffuser	10	W10269099	Lens, Light	16	W10820003	Lamp, LED
5	W10457601	Cover, Air Diffuser	11	W10271543	Connector, Water Tube			
6	W10656773	Switch, Light	12	W10457603	Cover, Air Filter			


REFRIGERATOR SHELF PARTS



REFRIGERATOR SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10463648	Shelf, Snack Pan	5	W10463650	Assembly, Cover	9	W10278653	Pan, Crisper
2	W11084209	Handle, Trim	6	W10256770	Pan, Snack	10	W10256774	Pan, Meat
3	W10282883	Slide, Humidity	7	W10628713	Roller, Pan	11	W11034716	Handle, Trim
4	W10282880	Housing, Humidity	8	W10628712	Axle, Roller	12	W11039726	Shelf Assembly


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	7	W10628713	Roller, Pan	14	W10425252	Cover, Thermistor
2	W11089023	Assembly, Cover	8	W10628712	Axle, Roller	15	W11050578	Lens
3	W11039724	Shelf Assembly, Upper	9	2155597	Socket, Light	16	W10322653	Pan, Freezer Upper Includes 7 & 8
4	W10280386	Thermistor	10	W10656771	Switch, Rocker Arm			
5	W11039725	Shelf Assembly, Lower	11	2162085	Socket, Light			
6	W10322649	Pan, Freezer Lower Includes 7 & 8	12	W10820003	Lamp, LED			
			13	W10656772	Switch, Rocker Arm			

MOTOR AND ICE CONTAINER PARTS




MOTOR AND ICE CONTAINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10774957	Ice Container (Complete)
2	W10693542	Assembly, Latch
3	2220458	Coupling, Bottom
4	W10258544	Shaft, Drive
5	W10754509	Spring, Coupling
6	W10293211	Assembly, Mounting Plate
7	2198628	Seal

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10291905	Gasket
9	2212370	Washer
10	W10225313	Motor, Dispenser
11	W10669473	Cover, Container
12	W10798411	Assembly, Ice Maker
13	W10166854	Gasket
14	W10765378	Assembly, Motor Box
15	W10646076	Assembly, Wire Jumper Switch

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
16	W10691248	Plate, Switch
17	W10666871	Rocker, Switch
18	W10749467	Filler, EPS Icemaker Cover
19	W10400435	Gasket, Foam
20	W10656772	Switch, Rocker Arm


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator (Includes Item 5)	2	W10710203	Bin, Gallon Door	6		Handle
	W11038913	White	3	W10170540	Screw		W11045527	White
	W11038911	Black	4	W10884773	Badge		W11045528	Black
	W11038910	Black Stainless	5		Gasket, Door		W10917722	Black Stainless
	W11037738	Stainless		W10247884	Beige		W11045530	Stainless
				W10249912	Black	7	2200086	Thimble, Top
				W10249916	Grey	8	W10296804	Screw


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer (Includes Item 8 And Dispenser Front Parts)	5	W10460893	Screw	11	W10010140	Set Screw (Silver)
	W11038922	White	6	W10430639	Bin, Door	12		Cover, Door Stop
	W11038915	Black	7	W10296816	Screw		W10632059	White
	W11038917	Black Stainless	8		Gasket, Door		W10632060	Black
	W11037733	Stainless		W10247885	Beige		W10632062	Grey
2		Handle		W10249913	Black	13	W10605341	Wire Assembly, Heater
	W11045527	White		W10249917	Grey			
	W11045528	Black	9		Closer, Upper Cam Door			
	W10917722	Black Stainless		W10248015	White			
	W11045530	Stainless		W10257204	Black			
3	2200086	Thimble, Top		W10257206	Grey			
4	W10296804	Screw	10	W10247907	Bracket, Door Stop			


DISPENSER PARTS



DISPENSER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Dispenser, False Wall	9		Ring, Trim	13		Tray, Housing
	W10254254	White		W10276265	White		W10254258	White
	W10254255	Black		W10335549	Black		W10254259	Black
	W10276226	Satina		W11087882	Chromium Frost		W10276225	Satina
2		Grate, Drip Tray	10	W10238083	Assembly, LED	14		Cover, Front
	W10276209	Stainless	11	W11038873	User Interface Assembly		W10458867	Black
3	W10174827	Bracket, Ice Door	12		Pad, Ice and Water	15	W10386778	Assembly, Water Fitting
4	W10435760	Guide, Ice		W10370583	White			
5	W10205978	Motor, Dispenser		W10370577	Black			
6	W10781994	Assembly, Separator		W10370582	Grey			
7	W10346124	Support, Ice Door						
8	4449745	Screw						


AIR FLOW PARTS



AIR FLOW PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10251462	Scroll, Fan	8	2169142	Blade, Fan	13	W10142292	Screw
2	2223733	Retainer, Fan Motor	9	W10240370	Gasket, Evaporator Cover	14	W10388269	Cover, Evaporator
3	W11040868	Duct, Upper Air	10	W10449920	Grommet, Motor	15	W10260382	Cover, Light
4		Bi-Metal Defrost (Not Serviced)	11	W10369602	Clip, Evaporator Cover	16	W10820003	Lamp, LED
5	W10260384	Air Duct Freezer	12	W10679946	Assembly, Evaporator Fan Wire (Includes Bi-Metal Defrost)	17	2162085	Socket, Light
6	W10001260	Screw				18	W10331728	Clip, Air Duct
7	W10556724	Motor, Fan						

UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10271541	Connector, Union	14	2325479	Tube, Process	27	W10278140	Cover, Condenser (Bottom)
2	2225834	Blade, Fan	15	2205813	Tie, Wire	28	W10653004	Compressor
3	W10276899	Condenser	16	W10239732	Evaporator	29	2169104	Sealer, Insulation
4	W10142255	Screw	17	2161324	Clip, Defrost Heater			REFRIGERANT CHARGE
5	2183042	Grommet	18	W10909387	Motor, Condenser Fan			5.3 oz. (R-134A)
6	W10171469	Screw	19	W10703218	Tray, Evaporator			
7	W10277958	Connector, Water	20	W10260424	Heat Shield			
8	W10303521	Sleeve	21	W10771114	Drier			
9	W10142287	Bolt	22	W10679948	Assembly, Unit Wire			
10	W10815861	Clip, Bottom Cover	23	W10680691	Baseplate			
11	W10219381	Tube, Suction	24	W10242407	Cord, Power			
12	W10248621	Clip, Condenser	25	W10251467	Baffle, Air			
13	W10710090	Assembly, Inverter Box	26	W10495968	Heater, Defrost			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350942	White Primer
	350939	Enamel, Black
	350930	White
	4392901	Biscuit/Bisque
	8171357	Graphite

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque
	80051	Graphite

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	4392900	Biscuit/Bisque
	8171358	Graphite

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	W10300794	Handle Installation Kit
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	4318168	Sealer
	8003RP	Kit, Water Inlet

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key