




24" Undercounter Wine Center

MODELS:

WUW55X24HS01 (Stainless)

WINE CENTER PARTS



WINE CENTER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	16	W10782231	Cover, Fan	35		Handle, Door
	W10739679	Use & Care Guide	17	W11296649	Sensor (White Connector)		W10874342	Stainless
	W10792630	Energy Guide				36	W10782239	Gasket, Door
2		Cabinet (Not a Servicable Part)	18	W11404833	Control Kit	37	W10782244	Plate, Switch
			19	W10782194	LED Light	38	W10782241	Axis, Door
3	W11290639	Drier Filter	20	W10782222	Cover, Sensor	39	W11255595	Stop, Door
4	W10782176	Power Cord	21	W11104121	Washer	40	W10782254	Fan Assembly, Condenser
5	W11290643	Water Tray	22	W10782255	Cover, Condenser Fan	41	W10792640	Stud, Handle
6	W11297348	Compressor	23	W11255160	Cover, Condenser	42	W11104118	Screw
7	W11290646	Cover, PCB	24	W10782251	Condenser	43	W11104122	Spring, Washer
8	W11406123	Sensor (Yellow Connector)	25	W11255169	Cover, Rear	44	W11255778	Foam
9	W11334740	Main PCB	26	W10782249	Leg			FOLLOWING PARTS NOT ILLUSTRATED
10	W10782193	Hinge, Upper Right	27	W11255162	Support, Front			
	W10782260	Hinge, Upper Left	28	W10782256	Slide, Rail		W10782192	Pin, PCB
11	W11255249	Hinge, Lower Right	29	W10782243	Switch		W11406131	Starter
	W11255250	Hinge, Lower Left	30	W10782242	Support, Switch		W11406133	Protector
12	W11255346	Cover, Rear	31	W11290657	Sensor (Red Connector)		W10266810	Aluminum Tape
13	W10782261	Screw	32	W11255338	Grille			REFRIGERANT CHARGE
14	W10782196	Evaporator	33	W11255347	Rack Assembly			1.23oz. R600a
15	W10782230	Fan Motor (With Blade)	34	W11323327	Door Assembly			