KitchenAid®

5 QT. STAND MIXER
ARTISAN TILT HEAD


MODELS:

KSM150TBAQ0 (Aqua Sky)
KSM150TBCU0 (Contour Silver)
KSM150TBER0 (Empire Red)
KSM150TBQG0 (Liquid Graphite)

11/12/2019

Part No. W11415032 Rev. A


COLOR VARIATION PARTS



COLOR VARIATION PARTS

Illus. No.	Part No.	Description
1		Motor Housing
	W10193501	Aqua Sky
	W10350463	Contour Silver
	240291-21	Empire Red
	W10513207	Liquid Graphite
2		Trim Band
	9706630	Black/Silver
3		End Cover
	W10193496	Aqua Sky
	W10350456	Contour Silver
	240253-22	Empire Red
	W10512234	Liquid Graphite
4		Planetary
	W10193498	Aqua Sky
	W10350465	Contour Silver
	240286-23	Empire Red
	W10512355	Liquid Graphite
5		Lower Gearcase
	W10193504	Aqua Sky
	W10350459	Contour Silver
	240350-84	Empire Red
	W10513075	Liquid Graphite
6		Pedestal
	W10193507	Aqua Sky
	W10350457	Contour Silver
	9702304	Empire Red
	W10512279	Liquid Graphite


BASE AND PEDESTAL UNIT PARTS



BASE AND PEDESTAL UNIT PARTS

Illus. No.	Part No.	Description
1		Literature Parts
	W11118281	Use & Care Guide
2	W11298367	Shield, Pouring
3	W10672617	Beater, Flat (Coated)
4	W10245282	Bowl, 5 Quart
5	3400020	Screw
6	W10191926	Cap, Bowl Screw
7	9709707	Foot
8	9704329	Whip, Wire
9	W10674618	Hook, Dough (Coated)
10	9709055	Latch
11		Latch, Link and Lever Assembly
	24452	Black
12	110679	Screw
13	116241	Washer, Spring
14	8533912	Washer
15	W10572158	Screw
16	24450	Link, Latch
17		Lever, Latch
	9709280	Black
18	16910	Pin, Hinge
19		Pedestal
		(Refer to Color Variation Parts Page)
20	W10713675	Bowl, 3 Quart


CASE, GEARING AND PLANETARY UNIT PARTS



CASE, GEARING AND PLANETARY UNIT PARTS

Illus. No.	Part No.	Description
1		Gearcase Motor Housing (Refer to Color Variation Parts Page)
2	W10753041	Cap, Attachment Hub
3		Thumb Screw
	9709194	Black
4		Band, Trim (Refer to Color Variation Parts Page)
5	W10323373	Washer, Fiber
6	W10112253	Gear, Worm
7	240308	Bracket, Worm Gear and Bearing
8	9705444	Pin, Grooved
9	240210-2	Gear, Pinion and Shaft
10	W11175140	Gear, Attachment Hub
11	W11175138	Gear, Center Bevel Pinion
12	240026	Shaft, Vertical Center
13	240018-1	Pin, Agitator Shaft
14	9705443	Pin, Grooved
15	4162324	Gasket, Transmission
16	67500-55	"O" Ring
17	W10323378	Washer
18		Lower Gear Case (Refer to Color Variation Parts Page)
19	9708651	Screw
20	243368	Shaft, Agitator
21	9703438	Ring, Retaining
22	9704677	Pin, Groove
23	241877	Screw
24		Cover, End (Refer to Color Variation Parts Page)
25	3400617	Screw
26	3400022	Screw
27	240309-2	Worm Gear Bracket and Gear Assembly
28	4160474	Shaft, Center Agitator Assembly
29	8533914	Washer, Lock
30	9708652	Screw
31	W11134949	Screw
32	W10903540	Gear, Pinion
33	9706090	Washer
34		Planetary (Refer to Color Variation Parts Page)
35	240285	Ring, Planetary Drip (Standard)
36	89411	Screw
37	W10903534	Gear, Internal

MOTOR AND CONTROL UNIT PARTS



MOTOR AND CONTROL UNIT PARTS

Illus. No.	Part No.	Description
1	110679	Screw
2	116241	Washer, Spring
3		Lever, Speed Control Assembly
	9709276	Black
4	3183680	Spring, Control Plate
5	9704324	Washer, Ball Bearing (Front)
6	W10788171	Armature & Bearing Assembly, 120 Volt
7	W10323376	Washer, Spacing
8	16998	Stud, Governor Drive
9	3180526	Bearing and Bracket Assembly
10	240775-1	Seal, End
11	W10131078	Nut
12	3180238	Washer, Felt
13	240769	Screw, Stator
14	W10068270	Washer, Lock
15	W10898250	Link, Speed
16	240205	Spring, Flat
17	W10315774	Field Assembly, 120 Volt
18	241356	Sleeve, Motor Stud
19	W10380496	Brush, Cap and Spring
20	9707926	Screw, Set
21	4162546	Brush Holder Assembly
22	3179908	Housing, Brush Holder
23	240680	Insert, Brush Holder
24	116286	Spring, Seat-Cap
25	116287	Spring, Cap
26		Cap, Brush Holder
	3184212	Black
27	W10068260	Screw
28	W10119326	Control Plate Assembly
29	W10330804	Governor Assembly
30	W10325124	Phase Control, 120 Volt
31		Cord, Power
	W11197451	Black
32	3184609	Screw