



REFRIGERATOR


MODELS:

WRT112CZJW00 (White)

WRT112CZJB00 (Black)

WRT112CZJZ00 (Stainless)


CABINET PARTS



CABINET PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	7	489341	Washer, Plastic	18		Plug, Hole
	W10520278	Service and Wiring Sheet	8	W11183254	Pin, Hinge (Bottom)		W10520304	White
	W11331641	Use and Care Guide	9	W11173998	Hinge, Center		W10520307	Grey
	W11383865	Energy Guide	10	W11175787	Shim, Center Hinge		W10520305	Black
2	W11191773	Assembly, Top Hinge	11	W10919908	Shim, Bottom Hinge	19	W10498976	Valve, Inlet
3	W10399311	Shim, Top Hinge	12	W11217747	Assembly, Bottom Hinge	20	W11265079	Fitting, Water Tube
4	489497	Screw	13	R-30039	Screw, Leveler	21	1106508	Gasket, Seal
5		Hinge Cover	14	W11176400	Leg, Leveler	22	W10329003	Clamp, Tube
	W11266756	White	15	2181944	Tube, Water	23	2181939	Insert, Tube
	W11266758	Black	16		Rail, Center (Not Serviced)			
	W11266757	Grey	17		Cabinet (Not Serviced)			
6	487576	Washer, Plastic						

LINER PARTS




LINER PARTS


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not Serviced)	8	W11288284	Cover, Evaporator Front	13	W11235113	Wire Assembly, Ice Maker
2	W11235950	Cover Assembly, Back	9	W11249471	Knob, Control	14	W10425252	Cover, Thermistor
3	W11179125	Foam	10	W11235949	Front, Assembly	15	W10520963	Button
4	W11117547	Assembly, Fan Motor	11	W11254945	Assembly, Electronic Control	16	W10520965	Spring
5	489468	Washer	12	W11215218	Wire Assembly (Includes Thermal Fuse)	17		Thermistor (Not Serviced)
6	W11262026	Control, Damper						
7	W11236030	Wedge, Front						

SHELF PARTS

FREEZER



REFRIGERATOR



SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10435530	Frame, Humidity Control
2	W11295868	Assembly, Crisper


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	W10431229	Control, Humidity
4	W11248340	Shelf, Glass

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	W11248335	Shelf, Glass
6	W11367385	Shelf, Bottom Glass

DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator	7	W11247924	Door Bin, Freezer	14		Thimble, Top
	W11309091	White	8	W11247889	Door Bin, Refrigerator		W10492018	White
	W11314912	Black	9		Endcap		W10334042	Black
	W11315264	Stainless			Left Hand		W11289190	Gray
2		Gasket, Refrigerator Door		W11246845	White			
	W11235133	White		W11246847	Black			
	W11235134	Black		W11246818	Grey			
	W11250318	Grey			Right Hand			
3		Door, Freezer		W11246852	White			
	W11309075	White		W11246854	Black			
	W11315307	Black	10	2189202	Bracket, Door Stop			
	W11315308	Stainless	11		Plug, Hole			
4		Gasket, Freezer Door		W11255553	Grey			
	W11235127	White	12	W10397055	Bracket, Door Stop			
	W11235130	Black	13	489442	Screw			
	W11250314	Grey						
5	W11291426	Bin, Bottle						
6	W10884775	Black						

UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10378704	Plate, Compressor Support	13	W11107829	Drier	25	W11264206	Condenser, Top Protection
2	2263990	Tie, Wire	14	10835903	Grommet	26	W11377937	Condenser, Side Protection (Right)
3	W11246374	Condenser	15	W11350837	Start Device	27	W11377938	Condenser Side Protection (Left)
4	2174739	Tube, Process	16	W10303628	Clamp, Power Cord	28		Thermistor (Not Serviced)
5	W11232468	Tube, Suction	17	W10475495	Roller			REFRIGERANT CHARGE
6	W11225065	Compressor	18	2179826	Axle, Rivet			40.8 Grams (R-600a)
7	W11179127	Heat Shield	19	W10261299	Wedge, Evaporator			
8	W10646247	Extension, Drain Tube	20	W11186306	Evaporator Assembly (with defrost heater)			
9	W11264207	Condenser, Bottom Protection	21	W11262991	Tray, Water			
10	2215468	Insulation, Sound	22	326020544	Support, Condenser			
11	W11342284	Cover, Terminal Board	23	W11358319	Assembly, Capacitor			
12	W11248029	Assembly, Power Cord	24	489442	Screw			

OPTIONAL PARTS

PAINTE, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	W10134625	Apollo Grey

PAINTE, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key

ICE MAKER FIELD INSTALLABLE

PAINTE, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350942	White Primer
	350930	White
	285006	Black

Illus. No. Part No. Description

	W11424126	Complete Icemaker Kit (Includes Icemaker, Bin & Shelf)
	W11416492	Icemaker Kit (Includes Fill Tube and Screws)
	W11403893	Pan, Ice
	W11403892	Shelf, Wire