




27" ELECTRIC DRYER

MODELS:

WED75HEFW0 (White)

TOP AND CONSOLE PARTS




Literature Parts

TOP AND CONSOLE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	3	W10637538	Harness, Wiring (Main)	9		IML Assembly
	W10804688	Use and Care Guide	4		Panel, Console		W10825126	White
	W10806847	Tech Sheet		W10391519	White	10	693995	Screw
	W11101374	Installation Instructions	5	W10636058	Water Channel	11	3390647	Screw
	W10804668	Quick Start Guide	6	W10208198	Bracket, Console	12	W10489172	Screw
			7		Assembly, Timer Knob	13	8536939	Clip, Spring
2		Top		W10783726	Chrome	14		Badge
	W10208383	White	8	W10540654	Cable, User Interface		W10387117	White


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10316167	Cover, Terminal Block	12	W10242878	Bracket, Motor Mounting	23	W10208250	Strike, Door
2	W10504381	Pad, Foam	13	W10468057	Assembly, Pulley	24	3390647	Screw
3	W10773242	Screw	14	279318	Terminal, Brass and Tinned (Includes Terminal Block Screw Kit)	25	3387242	Seal, Front Panel
4	3397659	Block, Terminal				26	343641	Screw
5	W10847946	Board, Control	15	W10288126	Screw	27	W10806758	Assembly, Motor
6	3357011	Screw	16	489463	Screw	28	8565046	Base, Cabinet
7		Panel, Side	17	W10259611	Bracket, Control	29	8066184	Pulley, Motor
	W10468495	White	18		Panel, Front	30	3387610	Belt, Drive
8	3392100	Foot, Dryer		W10363953	White	31	W10487431	Panel, Rear
	279810	Foot, Optional (Extended Length Package Of 2) (Not Included)	19	W10350906	Assembly, Door Switch	32	279393	Screw Kit, Terminal Block
9	W10121316	Clamp, Motor Mount	20	W10512946	Washer, Tri Ring			FOLLOWING PARTS NOT INCLUDED
10	W10446781	Spring, Idler	21	W10208382	Bracket, Rear			
11	3389420	Screw	22	W10547287	Assembly, Idler			
							W10323246	Kit, 4-Way Vent


BULKHEAD PARTS



BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10359271	Shaft, Drum Roller - Right Hand Thread	17	W11162462	Bulkhead, Rear	32	W10693363	Fuse, Thermal (91C)
2	3390647	Screw	18	3387459	Washer	33	8577274	Thermistor
3	W10672683	Assembly, Outlet Grill and Housing	19	W10359272	Shaft, Drum Roller - Left Hand Thread	34	3387223	Sensor, Electrode
4	W10298258	Harness, Sensor	20	W10512946	Washer, Tri Ring	35	W10211896	Assembly, Lint Duct
5	697354	Assembly, Air Duct	21	W10314171	Roller, Support	36	8544769	Housing Slot, Heater Box
6	W10211950	Seal, Housing Outlet	22	W10342188	Exhaust Pipe	37	W10211915	Wheel, Blower
7	W10521118	Seal, Drum	23		Lint Screen	38	W10653662	Pad, Foam
8	3934666	Nut, Hex		W10516085	White	39	W10672682	Grill, Outlet
9	W10211901	Assembly, Collar	24	697770	Seal, Plate Cover	40	W10211899	Seal, Blower Cover
10	W10794806	Screw	25	W10508188	Assembly, Drum (Complete)	41	W10416098	Baffle, Drum
11	8544776	Flange, Heater Box	26	W10219342	Screw	42	8557403	Thermostat, High Limit
12	W10344699	Collar, Duct	27	W10521122	Seal, Drum Front	43	W10673493	Bulkhead, Front
13	W10414388	Clip, Lint Duct	28	8066099	Bracket, Heater Box	44	W10211911	Housing, Blower
14	W10836011	Heater Element	29	693995	Screw			
15	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)	30	8544770	Housing Tab, Heater Box			
16	W10001120	Nut, Hex (Left Hand Thread)	31	280148	Kit, Thermal Cut-Off (Includes Thermostat)			

DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Inner Door	5	W10208401	Assembly, Spring Catch	10		Door, Inner
	W10811035	White					W10424957	White
2	W10208414	Assembly, Door Hinge	6	W10772469	Cover, Door Catch	11	W10288126	Screw
3	W10208398	Cap, Hinge	7	W10329710	Seal, Glass	12	W10208254	Assembly, Door Catch
4	W10208415	Hinge, Base	8	W10823368	Glass, Door	13	W10208252	Bracket, Glass
			9	W10772479	Door Assembly, Outer			

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORY PARTS|THE FOLLOWING POWER CORD CAN BE ORDERED. IMPORTANT: CHECK LOCAL WIRING CODE REQUIREMENTS TO SEE IF ONE OF THESE MEETS YOUR NEEDS.

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	PT220L	4', 30 Amp, 3 Wire, Dryer Cord
	PT400L	4', 30 Amp, 4 Wire, Dryer Cord
	PT600L	6', 30 Amp, 4 Wire, Dryer Cord

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	W10446202	Chrome Shadow

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350938	Gray Primer

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	8529894	Kit, Hold Down
	W10298318	Kit, Stack
	80047	Kit, Dryer Repair
	W10322470A	Dry Rack