




30" GAS RANGE WITH SPEEDHEAT BURNER

MODELS:

WFG515S0JW1 (White)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4		Cooktop	11	7101P485-60	Screw, Anti-Tip Kit
	W11382349	Installation Instructions		W11418090	White			FOLLOWING PARTS NOT ILLUSTRATED
	W11404074	Use and Care Guide	5		Panel, Manifold			
	W11351202	Tech Sheet		W11089574	White	W10797422		Harness, Main
	W11352106	Wiring Diagram	6		Knob, Control	W10753750		Harness, Bake/Broil
2		Kit, Burner Cap		W11023142	White	W10334923		Clip, Gas Wiring
	W11395131	Black (Set of 4)	7		Kit, Grate (Set of 2)	3196520		Clip, Wire
3	W11352018	Spreader, Flame (Left Front & Right Front)		W11241653	Black	3196896		Clip, Wire
	W11352020	Spreader, Flame (Left Rear)	8	W10673618	Screw	313438		Clip, Harness
	W11352021	Spreader, Flame (Right Rear)	9	3196557	Screw			
			10	W11379945	Bracket, Anti-Tip			


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	7	8523412	Bracket, Rear Cooktop	15	W10797001	Bracket, Ignitor
	W11130371	White (Left)	8	W10198745	Cover, Upper	16	W10110488	Module, Spark
	W11130378	White (Right)	9	W10192841	Shield, Heat	17	3196165	Screw
2	8053505	Shield, Heat	10	W10184370	Cover, Back			
3		Panel, Control	11	3196169	Screw			
	W11156377	White	12		Control, Range (LCC190)			
4	W10762981	Bracket, Mounting		W11342924	White			
5	W10920631	Module, Spark DSI	13	3196178	Screw			
6	W10516123	Bracket, Console Mounting	14	W10695491	Bracket, Control			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10153186	Box, Flue	16	W10390008	Base Rail Assembly (Left)	28	W11175594	Light Assembly
2	8272747	Shield, Flue				29	W10571723	Bulb, Halogen 40 Watts
3	W11379351	Box-Burner, Gas Sealed		W10390007	Base Rail Assembly (Right)	30	9761013	Front Door Latch Assembly
4		Panel, Side	17	W11370462	Rod, Door Switch	31	W10078370	Rod, Push Latch
	W10575396	White	18	W10031780	Screw	32	W10107820	Rear Door Latch Assembly
5	W10137382	Clip, Panel	19	3400080	Screw	33	W10674705	Glide, Drawer Front
6	8523249	Bracket, Manifold	20	W10268578	Rack, Oven	34	3196178	Screw
7	W10362924	Screw	21	W10658354	Seal, Door	35	W10379120	Screw
8	3196560	Screw	22	W10435470	Brace, Main Back			FOLLOWING PARTS NOT ILLUSTRATED
9	W10341186	Front Foot Assembly	23	W11379353	Retainer, Insulation (Left)			
10	W10058460	Foot, Leveling		W11379943	Retainer, Insulation (Right)		8524099	Insulation, Wrap
11	3195097	Bottom, Oven	24	3196560	Screw		W10180437	Insulation, Back
12	W10586204	Sensor	25	W10624590	Cord, Power			
13	8053967	Baffle, Burner Oven	26	W10289077	Receiver, Hinge			
14	8053969	Shield, Heat	27	W10627802	Switch, Door			
15	8053968	Shield, Lower						


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10295997	Screw, Valve	9	W10224921	Bracket, Aegis	24	W11428831	Electrode (Left Front, Left Rear)
2	W10295996	Bracket, Saddle Valve	10	3196385	Screw			
3	W11345008	Orifice Holder Assembly (15K) (Left Front)	11	3400016	Screw		W11428858	Electrode (Right Front, Right Rear)
	W11345009	Orifice Holder Assembly (9.5K) (Left Rear)	12	8054078	Burner, Broiler			FOLLOWING PARTS NOT ILLUSTRATED
	W11345011	Orifice Holder Assembly (15K) (Right Front)	13	W10184491	Spreader, Flame (Oven)		W11414603	LP Conversion Kit
	W11345010	Orifice Holder Assembly (5K) (Right Rear)	14	9758078	Burner, Bake		W10566537	LP Bake and Broil Kit
4	W10215439	Tubing (Manifold to Regulator)	15	W11370883	Regulator		W10400495	Orifice, LP Bake
5	W10812380	Harness, Switch	16	W10333842	Electrode, Broil		W10465080	Orifice, LP Broil
6	9758079	Electrode, Bake	17	W10420040	Tube, Broiler Supply		W10182767	Tie, Manifold Wire
7	W11347743	Manifold Assembly	18	W11435700	Fitting, Broiler			
8	W11352012	Valve, Gas (Left Front and Right Front)	19	W11428753	Orifice (15K) (Left Front and Right Front)			
	W11352013	Valve, Gas (Left Rear)		W10849720	Orifice (10K) (Left Rear)			
	W11352015	Valve, Gas (Right Rear)		W10849719	Orifice (5K) (Right Rear)			
			20	W10137062	Spreader, Flame (Broiler)			
			21	3196265	Screw			
			22	W10362924	Screw			
			23	W10827923	Spring, Electrode			

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Handle and Vent Assembly
	W11039084	White
2		Trim, Lower
	8523175	White
3	W10480830	Screw
4	9761344	Liner, Door
5	W10031790	Screw
6	W11044424	Glass, Inner
7	W10316950	Frame, Glass

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10278991	Insulation, Door Strip
9	9761357	Retainer, Insulation
10	W10299226	Hinge, Active
11		Glass, Outer Door
	W10409945	White
12		Trim, Door
	8523172	White (Left)
	8523166	White (Right)
13	W10327235	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
14	W11379944	Strap, Door
15	W10299227	Hinge, Door (Passive)
16	W10884775	Badge
17	W10200660	Screw

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front	3	W10462911	Bracket, Mounting	6		Rivet, Push
	W11123977	White	4	W10674708	Glide, Drawer Rear		3196814	White
2	W10688022	Drawer, Storage	5	3196169	Screw			

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	4392899	Biscuit/Bisque
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	W10355016	Cleaner, Stainless Steel
	W10355049	Wipes, Stainless Steel Cleaning
	W10275756	Cleaner, Granite
	31617A	Cleaner, Grate & Drip Pan
	4396096RB	Griddle
	4396923	Grid, Broiler Pan and
	W10123240	Rack, Broiler Pan & Roasting
	4396927	Rack, Oven (Split)