




30" GAS FREESTANDING SELF CLEAN CONVECTION RANGE

MODELS:

WFG775H0HB1 (Black)

WFG775H0HW1 (White)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	6		Panel, Manifold	14		Hinge, Grate (Not Serviced)
	W11404107	Installation Instructions		W10867880	Black			
	W11404100	Use & Care Guide		W10867879	White	15	W11043399	Griddle
	W11096111	Tech Sheet (English)	7		Knob	16		Bezel
	W11096115	Wiring Diagram (English/French)		W10912202	Black		W10912201	Black
	W11100300	Wiring Diagram (Spanish)		W10918417	White		W10918523	White
2		Burner Cap Kit	8		Grate Kit			FOLLOWING PARTS NOT ILLUSTRATED
	W11352138	Black (Set of 4)		W10865170	Black		W10887353	Harness, Main
3	W10067840	Screw	9	W10673618	Screw		W10753750	Harness, Bake/Broil
4	W11367106	Burner Kit	10	W11379946	Manifold Panel Bracket		W10334923	Clip, Gas Wiring
5		Cooktop	11	W11379358	Rear Gas Cooktop Bracket		313438	Clip, Harness
	W11418087	Black	12	W11379945	Bracket, Anti-Tip		7111P017-60	Clamp, Wire
	W11418088	White	13	7101P485-60	Screw, Anti-Tip Kit		3196896	Clip, Wire
							3196520	Clip, Wire


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	4	W10920631	Module, Spark DSI	11	W10856361	Bracket, Control
	W11213290	Black (Left)	5	W10198745	Cover, Upper	12	W10475149	Module, Spark (5+0)
	W11213292	Black (Right)	6	W10192841	Shield, Heat	13	W10797001	Bracket, Ignitor
	W11213291	White (Left)	7		Control, Electronic (LCX)	14	W10901802	Panel, Backer
	W11213293	White (Right)				15		Bracket, Eye Brow
2	W10516123	Bracket, Console Mounting		W10885939	Black		W11051312	Black
			8	W10762981	Bracket, Mounting		W11051311	White
3		Console	9	W10184251	Cover, Back	16	3196169	Screw
	W10869986	Black	10	3196178	Screw	17	W10551614	Spreader, Clip-Spring
	W10869987	White						


CHASSIS PARTS



CHASSIS PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10314347	Assembly, Flue	17	W10362924	Screw	32	3196560	Screw
2	9758701	Spacer, Door	18	W10323077	Diffuser, Flame	33	W10389555	Fan, Convection
3	W10273002	Bracket, Oven Support	19	3196178	Screw	34	W10346154	Cover, Convection
4		Panel, Side	20	W10273005	Back, Main	35	W10362924	Screw
	W10162245	Black	21	W10162385	Gasket, Door	36	W10289145	Rack, Oven (Gull-Wing)
	W10575396	White	22	W10031780	Screw	37	W10531060	Rack, Oven
5	W10158780	Cover, Rear Fan	23	W10273195	Shield, Heat	38	3196165	Screw
6	W10627802	Switch, Door	24	W11370463	Rod, Door Switch			FOLLOWING PARTS NOT ILLUSTRATED
7	W10137382	Clip, Panel	25	W10624590	Cord, Power			
8	W10919715	Gasket	26	W10035900	Support, Oven Bottom			
9	W10289077	Receiver, Hinge	27	W11379356	Pan, Bake		4820F015-59	Insulation, Strap
10	W10058460	Foot, Leveling	28	W11175594	Light Assembly		W10526208	Insulation, Wrap
11	W10211368	Bottom, Oven	29	W10571723	Bulb, Halogen 40 Watts		W10526209	Insulation, Main Back
12	W10586204	Sensor						
13	3601P356-45	Baffle, Bake Burner	30	W10341186	Front Foot Assembly			
14	3196178	Screw	31	W10390008	Base Rail Assembly (Left)			
15	W10435470	Brace, Main Back						
16	W11040249	Assembly, Flue (Upper)		W10390007	Base Rail Assembly (Right)			


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10295997	Screw, Valve	8	W11352012	Valve, Gas (Left Front and Right Front)	19	3196385	Screw
2	W11331179	Orifice Holder Assembly (18K) (Left Front)		W11352013	Valve, Gas (Left Rear and Center)	20	3400016	Screw
	W11345009	Orifice Holder Assembly (9.5K) (Left Rear)		W11352015	Valve, Gas (Right Rear)	21	W11428831	Electrode (Left Front and Left Rear)
	W11345011	Orifice Holder Assembly (15K) (Right Front)	9	W10224921	Bracket, Aegis		W11428858	Electrode (Right Front, Right Rear, Center)
	W11345010	Orifice Holder Assembly (5K) (Right Rear)	10	W10439242	Burner, Broiler	22	W10827923	Spring, Electrode FOLLOWING PARTS NOT ILLUSTRATED
	W11345012	Orifice Holder Assembly (8K) (Center)	11	W10680035	Burner, Bake		W11415424	LP 5 Orifice Conversion Kit
			12	W10720102	Valve, Gas		W10566535	LP Conversion Kit (Bake/Broil)
			13	W10324262	Igniter, Bake		W10182767	Tie, Manifold Wire
			14	W10306050	Tube, Broil Supply (Broiler Fitting To Valve)			
3	W10295996	Bracket, Saddle Valve	15	W10776437	Fitting, Broil			
4	W10510125	Tubing, Main Supply	16	W10333842	Electrode, Broil			
5	W10783317	Switch, 5 Burner Manifold Harness	17	W11428754	Orifice (18K) (Left Front)			
6	3601P336-45	Baffle, Broil Burner		W10849720	Orifice (10K) (Left Rear)			
7	W11418925	Manifold Assembly		W11428753	Orifice (15K) (Right Front)			
				W10849719	Orifice (5K) (Right Rear)			
				W11429345	Orifice (8K) (Center)			
			18	3196178	Screw			


DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Vent, Trim	9		Glass Assembly, Outer Door	14	W10294851	Rail, Door
	W10880611	Black				15	W10317886	Screw
	W10880612	White		W10871829	Black	16		Standoff, Handle
2	W10477496	Screw		W10871830	White		W10917796	Black
3		Handle, Door	10		Trim, Side		W10917797	White
	W11022643	Black		W10334004	Black	17	W10772958	Insulation, Door
	W11022644	White		W10334003	White	18	W10884775	Badge
4	W10297318	Liner, Door	11	W10327235	Screw			
5	W10031790	Screw	12		Trim, Bottom			
6	W10300487	Glass, Inner		W10334031	Black			
7	W10294853	Bracket, Glass Liner		W10333990	White			
8	W10440013	Hinge, Door (Active)	13	W10031780	Screw			

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front	3	W10688022	Drawer, Storage	6		Handle, Door
	W10330047	Black	4	W10441804	Slide, Drawer (Left)		W11022643	Black
	W10330046	White		W10441805	Slide, Drawer (Right)		W11022644	White
2	3196169	Screw	5	W10318026	Bracket, Mounting	7	W10498399	Screw

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	206922	Primer (White)

INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)