



COMMERCIAL ELECTRIC DRYER


MODELS:

CEM2745FQ1 (White)

TOP AND CONSOLE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	16	W10863354	Panel, Rear (Console)	29	W11365290	Plate, Adapter
	W10867001	Installation Instructions	17	3390647	Screw	30	W10461200	Case, Meter
	W10296776	Wiring Diagram	18	W11121427	Harness, Main	31	8576631	Coin Chute
	W10860154	Installation Instructions, Coin Kit	19	98139	Screw	32	W11269277	Assembly, Service Door
			20	W10521398	Timer & Harness Assembly	33	3954812	Cushion, Meter Case
2	W10139100	Screw	21	W10177791	Harness, Timer	34	W10510149	Bezel - PTS
3	W10461070	Bracket Control	22	339805	Screw	35	3349065	Bolt
4	W10461094	Console	23	3387974	Timing Cam, 3-Pin (60 Minutes)	36	3400029	Nut
5	W10286180	Cover, Terminal Block		339855	Timing Cam, 4-Pin (45 Minutes)	37	W10386302	Screw
6	W10133502	Indicator Lights Assembly		343777	Timing Cam, 6-Pin (30 Minutes)			ESD 270 New Jersey Dr. Fort Washington, PA 19034 1-800-523-1510 info@esdcoin.com
7	W10492415	Knob	24	385421	Funnel, Coin			
8	W10492412	White	25	W10860203	Money Box W/Lock			
9	3347825	Plate, Mounting	26		Key (Service Door) (When Ordering, Specify Vendor and Key Number)			
10	98445	Screw		W10114740	777 Lock and Key, Complete			
11	W10845275	Fascia						
12	W10662107	Lamp, Indicator	27	W11113382	777 Lock and Key, Complete			
13	W10327105	Switch, Cycle Selection	28	90406	Nut, Cage			
14	W10424310	Switch, Push to Start						
15	8533971	Screw						


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3393008	Screw	19	W10291934	Clip	38	3388229	Retainer
2	8066134	Switch Assembly	20	3398948	Wire, Jumper (Broken Belt Switch)	39	W10344193	Pulley-Idler Assembly
3	3391846	Clip, Front Panel	21		Assembly, Hinge & Pin	40	8066120	Lever, Belt Switch
4	3390647	Screw		W10279703	Silver	41	3406109	Switch, Door
5	3394881	Switch, Belt	22	3392538	Assembly, Door Catch	42	98129	Screw
6	3397659	Block, Terminal	23	3391943	Boot, Foot	43	697215	Panel, Toe White
7		Cabinet	24	693152	Bumper	44	3387242	Seal, Front Panel
	W11161907	White	25	697773	Screw	45	342055	Screw
8	W10561321	Foot, Dryer	26	W10131123	Nut, "U"	46	W10116360	Handle, Door
	279810	Foot, Optional (Extended Length Package Of 2) (Not Included)	27	W10396031	Motor	47	W10323061	Door, Rear
9	660658	Clamp, Motor	28	3394341	Pulley, Motor	48	W10139210	Screw
10	W10446781	Spring, Idler	29	345670	Lock Top	49	W10322546	Door, Front
11	3389420	Screw	30	W10131172	Belt, Drive	50	W10879744	Screw
12	696144	Strike, Door	31	3390735	Seal, Door	51	489463	Screw DRYER EXHAUST KIT NOT INCLUDED
13	3393657	Restrainer, Belt	32	3387118	Bracket, Motor			
14	3391915	Screw	33	3392186	Washer			
15		Panel, Front	34	279318	Terminal, Brass and Tinned (Includes Terminal Block Screw Kit)		W10323246	Kit, 4-Way Vent
	W10192882	White						
16	W10167612	Wire, Belt Switch	35	279393	Screw Kit, Terminal Block			
17	356674	Cone, Wedge	36	343641	Screw			
18		Plug, Hinge	37	W10773242	Screw			
	W10191265	White						

BULKHEAD PARTS



BULKHEAD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10359271	Shaft, Drum Roller - Right Hand Thread	15	W10345456	Clip, Spring	27	W10521118	Seal, Drum
2	90767	Screw	16	W10001120	Nut, Hex (Left Hand Thread)	28	W10131836	Thermostat
3	693995	Screw	17	W11162462	Bulkhead, Rear	29	8066099	Bracket, Heater Box
4	W10135254	Housing, Blower	18	3387459	Washer	30	697557	Bulkhead, Front
5	W11104018	Assembly, Air Duct	19	W10359272	Shaft, Drum Roller - Left Hand Thread	31	695240	Screw
6	8066086	Plug, Drum Hole	20	W10512946	Washer, Tri Ring	32	3391914	Thermostat HL-295/215
7	697814	Seal, Drum Front	21	W10314171	Roller, Support	33	W10692558	Grill, Outlet
8	3934666	Nut, Hex	22	W10178809	Thermostat 155~F Electronic	34	3392519	Fuse, Thermal (91C)
9	8066224	Pipe, Exhaust	23	W10685669	Assembly, Outlet Housing	35	697770	Seal, Plate Cover
10	8572105	Clip, Exhaust	24	279973	Kit, Thermal Cut-Off (Includes Thermostat)	36	W10049370	Screen, Lint
11	489463	Screw	25	W10545923	Assembly, Drum	37	W10349492	Wheel, Blower
12	W10891205	Assembly, Weld Heater Box	26	W10219342	Screw	38	3387230	Screw
13	3390647	Screw				39	3357011	Screw
14	W10832958	Element, Heater				40	697693	Baffle, Drum
						41	8066168	Assembly, Lint Duct

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	4392067	Kit, Dryer Repair
	8522199	Kit, Dryer Vent Testing

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350938	Gray Primer

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)