




30" GAS FREESTANDING SELF CLEAN RANGE

MODELS:

AGR6603SFB1 (Black)
AGR6603SFW1 (White)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4		Cooktop	13	W11194809	Electrode
	W11177375	Installation Instructions		W11133661	Black			(Left Front, Right Front, Left Rear)
	W11122565	Guide, Use & Care	5		Panel, Manifold		W10515459	Electrode
	W10873899	Tech Sheet		8523855	Black			(Right Rear)
	W10873901	Wiring Diagram		8523854	White	14	8273062	Screw
2		Set, Burner Cap	6		Knob, Control			Following Parts Not Illustrated
	W10183375	Black		W10844795	Black		W10842520	Harness, Main
3	W10515455	Assembly, Burner (17.5K)		W10844794	White		W10753750	Harness, Bake/Broil
		(Left Front, Right Front)	7		Grate Kit		W10809927	Harness, Cooktop
	W10515454	Assembly, Burner (9.5K)	8	3400701	Screw		3196896	Clip, Wire
		(Left Rear)	9	3196557	Screw		3196520	Clip, Wire
	W10515453	Assembly, Burner (6K)	10	8523249	Bracket, Manifold		W10334923	Clip, Gas Wiring
		(Right Rear)	11	W11379945	Bracket, Anti-Tip		313438	Clip, Harness
			12	7101P485-60	Screw, Anti-Tip Kit		7111P017-60	Clamp, Wire


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	4	W10920631	Module, Spark DSI	11		Control, Range
	W11130372	Black (Left)	5	W10516123	Bracket, Console Mounting		W10845611	Black
	W11130379	Black (Right)					W10837804	White
	W11130371	White (Left)	6	8523412	Bracket, Rear Cooktop	12	3196178	Screw
	W11130378	White (Right)	7	W10198745	Cover, Upper	13	W10516463	Bracket, DSI
2	W10110488	Module, Spark	8	W10192841	Shield, Heat	14	W10695491	Bracket, Control
3		Panel, Console	9	W10184370	Cover, Back	15	8053505	Shield, Heat
	W11157104	Black	10	3196169	Screw	16	W10797001	Bracket, Ignitor
	W11157106	White						


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10295997	Screw, Valve	8	W10279614	Valve, Gas (Left Rear)	20	W10170509	Orifice, Natural (14.2K)
2	W10295996	Bracket, Saddle Valve		W10247744	Valve, Gas (Right Rear)			(Left Front, Right Front)
3	W11157537	Assembly, Orifice Holder (Left Front)		W10279615	Valve, Gas (Left Front, Right Front)		W10170508	Orifice, Natural (9.5K) (Left Rear)
	W10473929	Assembly, Orifice Holder (Left Rear)					W10170506	Orifice, Natural (5K) (Right Rear)
	W11157536	Assembly, Orifice Holder (Right Front)	9	9758079	Electrode, Bake	21	W10137062	Spreader, Flame (Broiler)
	W10474163	Assembly, Orifice Holder (Right Rear)	10	3196265	Screw			FOLLOWING PARTS NOT ILLUSTRATED
4	W10215439	Tubing (Manifold to Regulator)	11	3196385	Screw		W10170534	Kit, LP Conversion
5	W10812380	Harness, Switch	12	8054078	Burner, Broiler		W10566537	LP Bake and Broil Kit
6	W10224921	Bracket, Aegis	13	W10184491	Spreader, Flame (Oven)		W10400495	Orifice, LP Bake
7	W10812382	Assembly, Manifold	14	9758078	Burner, Bake		W10465080	Orifice, LP Broil
			15	W10602001	Regulator			
			16	W10333842	Electrode, Broil			
			17	W10420040	Tube, Broiler Supply			
			18	W10592836	Fitting, Broiler			
			19	3400016	Screw			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10153186	Box, Flue	14	W10390008	Base Rail Assembly (Left)	25	W11175594	Light Assembly
2	8272747	Shield, Flue				26	W10571723	Bulb, Halogen 40 Watts
3	W11379351	Box-Burner, Gas Sealed		W10390007	Base Rail Assembly (Right)	27	3196560	Screw
4		Panel, Side	15	W10362924	Screw	28	W10674705	Glide, Drawer Front
	W10162245	Black	16	W10031780	Screw	29	W10627802	Switch, Door
	W10575396	White	17	W10416100	Back, Main	30	9761013	Front Door Latch Assembly
5	3196178	Screw	18	W10658354	Seal, Door	31	9757239	Rod, Door Switch
6	3196169	Screw	19	W10435470	Brace, Main Back	32	W10078370	Rod, Push Latch
7	W10341186	Front Foot Assembly	20	9761449	Retainer, Insulation (Left)	33	W10107820	Rear Door Latch Assembly
8	W10058460	Foot, Leveling		9761448	Retainer, Insulation (Right)			FOLLOWING PARTS NOT ILLUSTRATED
9	3195097	Bottom, Oven	21	W10137382	Clip, Panel		8524099	Insulation, Wrap
10	W10586204	Sensor	22	W10624590	Cord, Power		W10180437	Insulation, Back
11	8053967	Baffle, Burner Oven	23	W10289077	Receiver, Hinge			
12	8053969	Shield, Heat	24	W10379120	Screw			
13	8053968	Shield, Lower						


DRAWER AND BROILER PARTS



DRAWER AND BROILER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10268578	Rack, Oven	5		Panel, Drawer Front
2	W10688022	Drawer, Storage		W11123976	Black
3	W10462911	Bracket, Mounting		W11123977	White
4		Rivet, Push	6	W10674708	Glide, Drawer Rear
	3196813	Black	7	3196165	Screw
	3196814	White			

DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Top Vent	9	9761357	Retainer, Insulation	13	W10327235	Screw
	W10310922	Black	10	W10299227	Hinge, Door (Passive)	14	3196165	Screw
	W10310920	White			(Left)	15	W11379944	Strap, Door
2	W10200660	Screw		W10299226	Hinge, Active	16	W10031780	Screw
3		Handle, Door			(Right)	17		Trim, Bottom
	W10323589	Black	11		Glass, Outer Door		8523177	Black
	W10323588	White		W10886896	Black		8523175	White
4	9761344	Liner, Door		W10851723	White	18	W10316950	Frame, Glass
5	W10031790	Screw	12		Trim, Door Side			
6	W11044424	Glass, Inner		W10746436	Black (Left)			
7		Badge		W10746435	Black (Right)			
	W10846751	Black		8523172	White (Left)			
	W10849465	White		8523166	White (Right)			
8	W10278991	Insulation, Door Strip						

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

INSULATION

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	206922	Primer (White)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4396923	Grid, Broiler Pan and