



UNDERCOUNTER DISHWASHER


MODELS:

WDF520PADB9 (Black)

WDF520PADW9 (White)

WDF520PADM9 (Stainless)


DOOR AND PANEL PARTS



DOOR AND PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4		Panel, Front (Includes Nameplate)	6	W10884775	Badge
	W11380970	Energy Guide				7	W10519755	Insulation, Toe Panel
	W11384187	Owners Manual		W10629470	Black	8		Fastener
	W11266092	Tech Sheet		W10629471	White		W10503548	Black
2		Arm, Hinge		W10629473	Stainless		W10503549	White
	W10274922	Left Hand	5		Access Panel	9	8268961	Sleeve, Friction
	W10274921	Right Hand		W10369023	Black	10	489470	Screw
3	W10803537	Stiffener, Door		W10369025	White	11	W10315897	Insulation, Front Panel


CONTROL PANEL AND LATCH PARTS



CONTROL PANEL AND LATCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly (Includes Insert)	4	W10629497	Light Pipe	11	W10629551	Tab, Control
	W10629482	Black	5	W11096645	Screw	12	3400061	Screw
	W10629483	White	6	W10629499	Button Tree			
	W10629485	Stainless	7	W10574864	Latch Assembly (Includes Switch)			
2	W10825638	Box, Connector	8	W10834738	Control, Electronic			
3		Handle Pocket	9	W10825369	Brace, Connector			
	W10629511	Black	10	W10485367	Clip, Panel			


INNER DOOR PARTS



INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10348409	Screw	6	8269259	Gasket, Vent	11	W10274923	Seal, Console/Door
2	W10524920	Cap, Rinse Aid	7	W10671924	Bezel, Vent	12	W10462232	Bracket, Dispenser
3	W10713291	Inner Door Assembly (Also Order Item 6)			(Also Order Item 6)			
			8	W10671905	Dispenser Assembly			
4	W10482094	Cover, Dispenser	9	W10832780	Wiring Harness			
5	W10329609	Vent Assembly (Also Order Item 6)	10	W10177098	Screw			


FILL, DRAIN AND OVERFILL PARTS



FILL, DRAIN AND OVERFILL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	370445	Clamp, Hose	6	371505	Clamp, Hose	10	304231	Screw
2	W10769066	Inlet Hose	7	W11130744	Fill Valve Assembly	11	W10195039	Switch, Overfill Control
3	W10195536	Inlet, Water (Also Order Item 4)	8	W10292152	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)	12	W10316267	Standpipe, Overfill
4	8531323	Gasket				13	W10346525	Float & Retainer Assembly
5	W10508676	Nut, Inlet (Also Order Item 4)	9	W10545278	Drain loop with check valve assembly	14	W10195037	Lever, Overfill Switch


TUB AND FRAME PARTS



TUB AND FRAME PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10349289	Tub Assembly (Includes Heater Assembly)	11	3400892	Screw	21	W10732961	Bracket, Heater Support
2	W10321574	Shield, Thermostat	12	8268991	Cover, Terminal Box	22	W10441445	Heater Element Assembly
3	W10524469	Seal, Tub	13	W10866979	Shield, Tub Sound			(Includes Heater Washer & Nut)
4	W10341745	Screw	14	W10539489	Clip, Thermostat			NOTE: If heater element is removed, it must be replaced.
5	3367670	Screw	15	3371618	Thermostat			
6	8269145	Bracket, Undercounter	16	W10544004	Strike, Latch			
7	W10304231	Support, Bottom	17	W10819539	Sound Insulation, Bottom			
8	W10619352	Leveler, Leg	18	3400014	Screw, Grounding	23	W10477552	Nut, Heater Element
9	W10337934	Spring, Door Balance	19	8268990	Bushing, Door Spring			
10	8575897	Wheel Assembly	20	3378128	Washer, Pronged Cup			


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10455271	Cover, Outlet	7	W10789806	Filter Cup Assembly	15	W10805386	Motor
2	W10482462	Sump With Seal (Also Order Items 13 & 16)	8	W10537634	Pump, Drain			(Also Order Items 13 & 16)
			9	8269144	Hose, Drain	16	W10445975	Hose Assembly (Includes 2 Clamps)
3	W10463906	Screen	10	W10348407	Screw	17	W10491331	Sprayarm
4	W10195086	Motor, Isolator	11	370445	Clamp, Hose			
5	W10837401	Sump & Motor Assembly	12	W10723295	Indicator, Optical Wash			
6	W10372113	Tab, Sump	13	W11182008	Grommet			
			14	W10169167	Clamp, Hose			


UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11462355	Feed Tube Assembly	3	W10498900	Sprayarm
2	W10165274	Screw	4	W10340681	Manifold


UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10826745	Dishrack, Upper	4	8565925	Stop, Track (Non-Removable)	6	W10380410	Cupshelf, Small
2	W10845760	Mount, Wheel Assembly	5	W10306228	Track, Spacer	7	W10082861	Stop, Track (Removable)
3	3385089	Track, Dishrack						

LOWER RACK PARTS



LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8539225	Dishrack, Lower	3	W10918493	Silverware Basket Assembly	5	W10629537	Lid, Silverware Basket (Center)
2	8268645	Wheel & Transport Assembly	4	W10629533	Lid, Silverware Basket (Side)	6	W10671904	Clip, Silverware Basket

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORIES

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		SIDE PANEL KITS
	8171656	White
	8171657	Black
	8171658	Biscuit/Bisque
	8171659	Stainless Steel
		MOISTURE BARRIER KIT
	4396277	Barrier Kit
		DRAIN HOSE
	3385556	12 Ft.
		Handle Assembly
	W10702080	Black
	W10702081	White

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	4392900	Biscuit/Bisque

POWER CORD KIT

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4317824	Power Cord Kit (Included Cord & Misc. Hardware)

ANTI-TIP KIT

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	8171477	Floor Mount Kit
	8212560	Side Mount Kit

DISHRACK REPAIR

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		TINE TIP REPAIR KIT (Enough for Two Complete Racks)
	4396838	White
	4396840	Grey
	4396854	Silver Atlantis
		VINYL TOUCH-UP (4oz)
	676453	White
	676455	Grey
	4396853	Silver Atlantis