
1.1 CUBIC FOOT COMPACT MICROWAVE HOOD

MODELS:

WML55011HW6 (White)
WML55011HB6 (Black)
WML55011HS6 (Stainless)

© 2020 Whirlpool Corporation
Part No. W11508187 Rev. A


CONTROL PANEL PARTS



CONTROL PANEL PARTS

Illus. No.	Part No.	Description
1		Literature Parts
	W11359126	Installation Instructions
	W11396506	Use and Care Guide
	W11398325	Tech Sheet
2		Control Panel, Left
	W11219784	White
	W11220414	Black
	W11220420	Stainless
3		Control Panel, Right
	W11206154	White
	W11206155	Black
	W11206156	Stainless
4		Cover, Top
	W11109987	White
	W11083285	Black
5	W11389852	PCBA, User Interface
6	W11083284	Backer, Control
7	W11418917	PCBA, Appliance Control Unit


DOOR PARTS



DOOR PARTS

Illus. No.	Part No.	Description
1		Door, Complete
	W11206158	White
	W11206159	Black
	W11206157	Stainless
2	W10884775	Badge


INTERIOR AND VENTILATION PARTS



INTERIOR AND VENTILATION PARTS

Illus. No.	Part No.	Description
1	W11378281	Thermostat, Cavity
2	W11440761	Plate, Chassis
3	W10492278	Diode, High Voltage
4	W11088345	Cover, Cooling Fan
5	W11088354	Wheel, Cooling Fan
6	W11088352	Housing, Cooling Fan
7	W11325927	Motor, Cooling Fan
8	W11088358	Air Guide, Magnetron
9	W10531156	Board, Filter
10	W10138793	Fuse
11	W10313274	Bracket, Noise Filter
12	W11334531	Transformer, High Voltage
13	W11164809	Chassis, Transformer
14	W10536989	Thermistor, PCBA
15	W11196080	Capacitor, High Voltage
16	W11095808	Bracket, Capacitor
17	W11159942	Plate, Bottom
18	W11479930	Assembly, Interlock (Includes Switches)
19	W11284565	Filter, Charcoal
20	W11206152	Filter, Grease
21	W11086295	Reflector, Lamp
22	W11384716	Lamp, LED
23	W11206153	Assembly, Glass Holder
24	W11044953	Motor, Door Eject


AIR FLOW PARTS



AIR FLOW PARTS

Illus. No.	Part No.	Description
1	W11108230	Outlet, Cavity (Back)
2	W11095827	Air Deflector, Right
3	W11391783	PCBA, Hood Control
4	W11095824	Outlet Deflector, Right
5	W11405832	Capacitor, Hood Motor
6	W11086272	Chassis, Fan
7	W11095794	Deflector, Cooling Fan
8	W11095804	Hood Deflector, Right
9	W11098921	Base, Cavity Lighting
10	W11409092	Motor, Hood (300 CFM)
11	W11096432	Hood Deflector, Back
12	W11039275	Hood Motor, Single
13	W11095830	Air Guide, Left
14	W11405836	Seal, Lighting
15	W11086300	Housing, Cavity Lighting
16	W11306551	Holder, Lamp
17	W11384716	Lamp, LED
18	W11095814	Divider, Air
19	W11099491	Holder, Wire
20	W11095828	Channel, Hood Back
21	W11323215	Housing, Tranformer
22	W11186948	Foil, Lamp
23	W11115131	Magnetron
24	W11126543	Seal, Rubber
25	W11378280	Thermostat, Magnetron


TURNTABLE PARTS



TURNTABLE PARTS

Illus. No.	Part No.	Description
1	W11401221	Turntable
2	W11126541	Seal, Waveguide
3	W11193296	Cover, Waveguide
4	W11387723	Ring, Turntable
5	W11387721	Driver, Turntable
6	W11096347	Seal, Waterproof
7	W10466420	Motor, Turntable

CABINET AND INSTALLATION PARTS



CABINET AND INSTALLATION PARTS

Illus. No.	Part No.	Description
1	W11187358	Cord, Power
2	W11086258	Plate, Mounting
3	W10748710	Damper
4		Cover, Exhaust
	W11165209	White
	W11127064	Black
5		Case, Outer
	W11446922	White
	W11446923	Black
	W11446952	Stainless
6		Cover, Vent (Long)
	W11164798	White
	W11163586	Black
	W11095767	Stainless
7	W11360416	Backplate, Oven
8		Grille, Vent (Long)
	W11164793	White
	W11163558	Black
	W11086309	Stainless
9		Grille, Vent (Light Access)
	W11164786	White
	W11163552	Black
	W11095781	Stainless
10		Grille, Vent (Short)
	W11164816	White
	W11163562	Black
	W11086310	Stainless
		FOLLOWING PARTS NOT ILLUSTRATED
	W10821385	Hardware, Installation
	W11421368	Harness, Main
	W11266688	Harness, User Interface
	W11101065	Harness, Left Touch Control
	W10916210	Harness, Right Touch Control
	W11300413	Harness, Communication
	W11187937	Harness, PCBA Ground Wire
	W11479911	Harness, Door Motor SIgnal