





1.9 CUBIC FOOT MICROWAVE HOOD

MODELS:

WMH78019HW6 (White)
WMH78019HW06 (White)
WMH78019HB6 (Black)
WMH78019HB06 (Black)


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	2		Board, Control (With Cover)
	W10823835	Installation Instructions		W11466758	White
	W11037870	Use and Care Guide		W11466759	Black
	W11519159	Tech Sheet			

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Complete (Includes Control)
	W11196122	White
	W11196118	Black

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
2	W10643448	Stopper, Door
3	W11095740	Housing, Antenna


INTERIOR AND VENTILATION PARTS



INTERIOR AND VENTILATION PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11350931	Chassis	12	W10571453	Insulation, Side	25	W10561770	Capacitor, High Voltage
2	W10892536	Lamp, Halogen	13	W10533107	Deflector, Air	26	W11222648	Diode, High Voltage
3	W10525853	Bracket, Smart Pop	14	W11405831	Capacitor, Motor	27	W10510233	Terminal, PCBA Smart Pop
4	W10535950	Filter, Grease	15	W10536989	Thermistor, PCBA	28	W10259248	Cover, Thermostat
5	W10571126	Plate, Bottom	16	W10510235	Tube, Smart Pop Sound	29	W11268275	Thermostat, Convection
6	W10240330	Assembly, Lamp Glass and Holder	17	W10510234	Terminal, Smart Pop	30	8206223	Clip
7	W10510237	Spacer, Smart Pop	18	W11259891	Resistor, Cement	31	W11381433	PCBA, Smart Pop
8		Switches, Interlock (Not Serviced, Order Interlock Assemblies)	19	W10458325	Actuator	32	W10631701	Air Guide, Magnetron
9	W11187757	Assembly, Interlock (Includes Switches)	20	W10533480	Holder, NTC	33	W11169357	Motor, Cooling Fan
10	W11051821	Thermostat	21	W10533502	Cover, Cooling Fan	34	W10533503	Wheel, Cooling Fan
11	W10540718	Bracket, Cavity	22	W10533501	Housing, Cooling Fan	35	W10533486	Valve, Door
			23	W11465624	Transformer, High Voltage			
			24	W10633730	Bracket, Capacitor			

AIR FLOW PARTS




AIR FLOW PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11300398	Deflector, Air
2	8206382	Cover, Lamp
3	W10557536	Sensor, Humidity
4	4393681	Lamp, Cavity
5	W10533487	Plate, Air Guide
6	W11409088	Motor, Fan
7	W10712444	Housing, Damper
8	8206230	Filter, Charcoal
9	W10571180	Seal, Foam
10	W10654514	Thermostat, Cavity

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
11	W10557537	Sensor, Convection
12	W10210878	Socket, Cavity Lamp
13	W11382018	Baseplate, Air Guide
14	W11293488	Cover, Right Duct
15	W10531156	Board, Filter
16	W10810142	Socket, Motor Wire
17	W10533112	Outlet, Cavity (Back)
18	W11188557	Magnetron

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
19	W10533483	Duct, Cavity (Rear)
20	W10570209	Duct, Cavity (Front)
21	W10715053	Shield, Finger
22	W10531724	Glass, Lamp
23	W10758886	Assembly, Air Guide Grill
24	W10138793	Fuse
25	W10591803	Thermostat, Magnetron


TURNTABLE PARTS



TURNTABLE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11361167	Cover, Waveguide	5	W10679313	Ring, Turntable	11	W10568148	Seal, Turntable Block
2	W10740485	Hook, Microwave (Left Front & Right Front)	6	W10337248	Driver, Turntable	12	W10573936	Hook, Microwave (Left Rear & Right Rear)
3	W10857800	Steamer	7	W10466420	Motor, Turntable			
4	W11358813	Turntable	8	W10637931	Rack, Microwave			
			9	8184109	Seal, Waterproof			
			10	W10440082	Rack, Convection			

CABINET AND INSTALLATION PARTS



CABINET AND INSTALLATION PARTS

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11025649	Plate, Mounting
2	W10748710	Damper
3	W10654511	Cord, Power
4		Case, Outer
	W11446920	White
	W11446919	Black
5		Grille, Vent
	W10701700	White
	W10701701	Black
6	W10571554	Assembly, Convection Motor and Fan
7	W10740434	Duct, Cooling (Upper)
8	W10533489	Duct, Cooling (Bottom)
9	W10570212	Air Duct, Turntable Motor
		Following Parts Not Illustrated
	W10571450	Insulation, Back
	W10571451	Insulation, Top
	W10571454	Insulation, Bottom
		MISCELLANEOUS PARTS
	W10821385	Hardware, Installation
	W10190020	Template, Upper (English & Spanish)
	W10190018	Template, Upper (English & French)
	8169704	1/4-20x3" Panhead Screw
	W11298100	Harness, Main
	W10539840	Harness, PCBA Ground Wire
	W10508741	Wire, Door Control Cable
	W10902486	Cable, Door Control
	W10509362	Cable, Touch Sensor