




## **MICROWAVE**

### **MODELS:**

WMH78519LZ00 (Stainless)

WMH78519LV00 (Black Stainless)


# CONTROL PANEL PARTS



# CONTROL PANEL PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>        | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>  | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>           |
|-----------------------------|-----------------|---------------------------|-----------------------------|-----------------|---------------------|-----------------------------|-----------------|------------------------------|
| 1                           |                 | Literature Parts          | 2                           |                 | Cover, Control      | 5                           | W11627690       | PCBA, Appliance Control Unit |
|                             | W11496338       | Installation Instructions |                             | W10571112       | White               |                             |                 |                              |
|                             |                 |                           |                             | W10478239       | Black               | 6                           | W10540721       | Seal, Control                |
|                             | W11603630       | Use and Care Guide        | 3                           | W10533504       | Duct, Cooling Front |                             |                 |                              |
|                             | W11603638       | Quick Reference Guide     | 4                           | W10540727       | Background, Control |                             |                 |                              |
|                             | W11603648       | Tech Sheet                |                             |                 |                     |                             |                 |                              |

# DOOR PARTS




# DOOR PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>         |
|-----------------------------|-----------------|----------------------------|
| 1                           |                 | Door, Complete             |
|                             | W11643350       | Stainless                  |
|                             | W11644419       | Black Stainless            |
| 2                           | W10476546       | Bracket, Door              |
| 3                           | W10770971       | Bracket, Door Cable        |
| 4                           | W11320318       | Cable, Door User Interface |
| 5                           | W10897612       | Frame, Inner               |
| 6                           |                 | Frame, Back Decorating     |
|                             | W10476550       | Black                      |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>      |
|-----------------------------|-----------------|-------------------------|
| 7                           | W11643345       | Cover, PCBA             |
| 8                           | W11600911       | Glass, Outer Door       |
| 9                           | W10643448       | Stopper, Door           |
| 10                          | W10891969       | Body, Door (With Glass) |
| 11                          | W11381432       | PCBA, Touch Sensor      |
| 12                          | W11206127       | Frame, Door             |
| 13                          |                 | Assembly, Outer Door    |
|                             | W10899866       | Stainless               |
|                             | W10909829       | Black Stainless         |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>   |
|-----------------------------|-----------------|----------------------|
| 14                          | W11602074       | Holder, PCBA         |
| 15                          | W11623075       | PCBA, User Interface |
| 16                          | W10909200       | Handle, Pocket Door  |
| 17                          |                 | Cover, Screw         |
|                             | W10542546       | Black                |
| 18                          | W10770972       | Holder, Door Cable   |


# INTERIOR AND VENTILATION PARTS



# INTERIOR AND VENTILATION PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                                                | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>        | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>       |
|-----------------------------|-----------------|-------------------------------------------------------------------|-----------------------------|-----------------|---------------------------|-----------------------------|-----------------|--------------------------|
| 1                           | W10908578       | Chassis                                                           | 12                          | W10533502       | Cover, Cooling Fan        | 25                          | W10561774       | Capacitor, High Voltage  |
| 2                           | W11409090       | Lamp, Halogen                                                     | 13                          | W10533501       | Housing, Cooling Fan      | 26                          | W11222648       | Diode, High Voltage      |
| 3                           | W10525853       | Bracket, Smart Pop                                                | 14                          | W11405831       | Capacitor, Motor          | 27                          | W10510233       | Terminal, PCBA Smart Pop |
| 4                           | W10535950       | Filter, Grease                                                    | 15                          | W10536989       | Thermistor, PCBA          | 28                          | W10259248       | Cover, Thermostat        |
| 5                           | W10571126       | Plate, Bottom                                                     | 16                          | W10510235       | Tube, Smart Pop Sound     | 29                          | W11268275       | Thermostat, Convection   |
| 6                           | W10240330       | Assembly, Lamp Glass and Holder                                   | 17                          | W10510234       | Terminal, Smart Pop       | 30                          | 8206223         | Clip                     |
| 7                           | W10510237       | Spacer, Smart Pop                                                 | 18                          | W11259891       | Resistor, Cement          | 31                          | W11381433       | PCBA, Smart Pop          |
| 8                           |                 | Switches, Interlock<br>(Not Serviced, Order Interlock Assemblies) | 19                          | W10533486       | Valve, Door               | 32                          | W10631701       | Air Guide, Magnetron     |
| 9                           | W11187757       | Assembly, Interlock (Includes Switches)                           | 20                          | W10533107       | Deflector, Air            | 33                          | W11169357       | Motor, Cooling Fan       |
| 10                          | W10458325       | Actuator                                                          | 21                          | W10540718       | Bracket, Cavity           | 34                          | W10245194       | Holder, Fuse             |
| 11                          | W10533480       | Holder, NTC                                                       | 22                          | W10533503       | Wheel, Cooling Fan        | 35                          | W10138793       | Fuse                     |
|                             |                 |                                                                   | 23                          | W11249660       | Transformer, High Voltage |                             |                 |                          |
|                             |                 |                                                                   | 24                          | W10556823       | Bracket, Capacitor        |                             |                 |                          |


## AIR FLOW PARTS



# AIR FLOW PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>    | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>           |
|-----------------------------|-----------------|--------------------|-----------------------------|-----------------|-----------------------|-----------------------------|-----------------|------------------------------|
| 1                           | W11300398       | Deflector, Air     | 11                          | W10557537       | Sensor, Convection    | 19                          | W10892383       | Duct, Cavity (Front)         |
| 2                           | 8206382         | Cover, Lamp        | 12                          | W10632409       | Baseplate, Air Guide  | 20                          | W10715053       | Shield, Finger               |
| 3                           | W10557536       | Sensor, Humidity   | 13                          | W11293488       | Cover, Right Duct     | 21                          | W10531724       | Glass, Lamp                  |
| 4                           | W11409090       | Lamp, Halogen      | 14                          | W10572027       | Board, Filter         | 22                          | W10758887       | Assembly, Airguide<br>Grille |
| 5                           | W10533487       | Plate, Air Guide   | 15                          | W10810142       | Socket, Motor Wire    | 23                          | W10138793       | Fuse                         |
| 6                           | W11409088       | Motor, Fan         | 16                          | W10533112       | Outlet, Cavity (Back) | 24                          | W10591803       | Thermostat,<br>Magnetron     |
| 7                           | W10712444       | Housing, Damper    | 17                          | W10754517       | Magnetron             | 25                          | W10565479       | Board, Door Control          |
| 8                           | 8206230         | Filter, Charcoal   | 18                          | W10533113       | Duct, Cavity (Rear)   |                             |                 |                              |
| 9                           | W10571180       | Seal, Foam         |                             |                 |                       |                             |                 |                              |
| 10                          | W10654514       | Thermostat, Cavity |                             |                 |                       |                             |                 |                              |


# TURNTABLE PARTS



# TURNTABLE PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                                 | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                             | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                   |
|-----------------------------|-----------------|----------------------------------------------------|-----------------------------|-----------------|------------------------------------------------|-----------------------------|-----------------|--------------------------------------|
| 1                           | W11361167       | Cover, Waveguide                                   | 6                           | W10466420       | Motor, Turntable                               | 11                          | 8184837         | Element, Grill Halogen               |
| 2                           | W10740485       | Hook, Microwave<br>(Left Front and Right<br>Front) | 7                           | 8184109         | Seal, Waterproof                               | 12                          | W10510203       | Heater, Quartz Grill                 |
| 3                           | W11358813       | Turntable                                          | 8                           | W10440082       | Rack, Convection                               | 13                          | W11594108       | Basket, Air Fry                      |
| 4                           | W10679313       | Ring, Turntable                                    | 9                           | W10568148       | Seal, Turntable Block                          | 14                          | W10637931       | Rack, Microwave<br>(Sold Separately) |
| 5                           | W10337248       | Driver, Turntable                                  | 10                          | W10573936       | Hook, Microwave<br>(Left Rear & Right<br>Rear) |                             |                 |                                      |

# CABINET AND INSTALLATION PARTS



# CABINET AND INSTALLATION PARTS

## Illus.

| <u>No.</u> | <u>Part No.</u> | <u>Description</u>                        |
|------------|-----------------|-------------------------------------------|
| 1          | W11025649       | Plate, Mounting                           |
| 2          | W10748710       | Damper                                    |
| 3          | W10654511       | Cord, Power                               |
| 4          |                 | Case, Outer                               |
|            | W11446919       | Black                                     |
| 5          |                 | Grille, Vent                              |
|            | W10701701       | Black                                     |
| 6          | W10571554       | Assembly, Convection<br>Motor and Fan     |
| 7          | W10740434       | Duct, Cooling (Upper)                     |
| 8          | W10533489       | Duct, Cooling (Bottom)                    |
| 9          | W10570212       | Air Duct, Turntable<br>Motor              |
|            |                 | FOLLOWING PARTS<br>NOT ILLUSTRATED        |
|            | W10571450       | Insulation, Back                          |
|            | W10571452       | Insulation, Top                           |
|            | W10892377       | Insulation, Bottom                        |
|            | W10571453       | Insulation, Side                          |
|            |                 | MISCELLANEOUS<br>PARTS                    |
|            | W10821385       | Hardware, Installation                    |
|            | W10190020       | Template, Upper<br>(English & Spanish)    |
|            | W10190018       | Template, Upper<br>(English & French)     |
|            | 8169704         | 1/4-20x3" Panhead<br>Screw                |
|            | W11302364       | Harness, Main                             |
|            | W11483628       | Harness, Hood Lamp<br>and Turntable Motor |
|            | W10539840       | Harness, PCBA<br>Ground Wire              |
|            | W10566563       | Harness, Smart Pop                        |
|            | W10508741       | Wire, Door Control<br>Cable               |
|            | W10670896       | Harness, Fade In /<br>Fade Out            |
|            | W10566562       | Cable, Fade In / Fade<br>Out              |