




Dishwasher

MODELS:

WDP730HAMZ1 (Stainless)


DOOR AND PANEL PARTS



DOOR AND PANEL PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4		Panel, Front (Includes 8 & 9)	8	W10692757	Barrel Nut, Front Panel
	W11650520	Energy Guide		W11528193	Stainless	9	W11504190	Light, Pipe
	W11532445	Owners Manual			Access Panel	10	3400071	Screw
	W11532444	Tech Sheet	5		(Includes Hardware)	11	W10315897	Insulation, Front Panel
2		Arm, Hinge		W10852733	Black	12	W10711884	Screw
	W11484017	Left Hand		W10853886	U-nut	13	W10519755	Insulation, Toe Panel
	W11484018	Right Hand	6			14	302868	Screw (Black)
3	W10803537	Stiffener, Door	7	8268961	Sleeve, Friction			


CONTROL PANEL AND LATCH PARTS



CONTROL PANEL AND LATCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly	3	W10825369	Brace, Connector	6	W10653840	Latch Assembly (Includes Switch)
	W11589973	Black	4	W11669441	Control, Electronic			
2	W10825638	Box, Connector	5	W10348408	Screw	7	W10177098	Screw


INNER DOOR PARTS



INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10348409	Screw	5	W11648151	Vent Assembly w/ Fan	9	W11595231	Wiring Harness
2	W11050927	Seal, Console/Door	6	W11476843	Screw	10	W11510780	Duct, Vent
3	W11631034	Inner Door Assembly	7	W11531479	Deflector, Vent	11	W11184028	Gasket, Vent
4	W10920683	Door Bottom, Seal	8	W10620296	Dispenser Assembly			


FILL, DRAIN AND OVERFILL PARTS



FILL, DRAIN AND OVERFILL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	370445	Clamp, Hose	6	371505	Clamp, Hose	10	304231	Screw
2	W10769066	Inlet Hose	7	W11669945	Fill Valve Assembly	11	W10195039	Switch, Overfill Control
3	W10195536	Inlet, Water (Also Order Item 4)	8	W10292152	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)	12	W10316267	Standpipe, Overfill
4	8531323	Gasket				13	W10346525	Float & Retainer Assembly
5	W10508676	Nut, Inlet (Also Order Item 4)	9	W10545278	Drain loop with check valve assembly	14	W10195037	Lever, Overfill Switch


TUB AND FRAME PARTS



TUB AND FRAME PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11502321	Tub Assembly	15	3371618	Thermostat	23	W10277003	Screw
2	W11656602	Shield, Thermostat	16	W10544004	Strike, Latch	24		Tub Mount, Third Level Rack
3	W11425053	Seal, Tub	17	3378128	Washer, Pronged Cup		W11504623	Left Hand
4	W10341745	Screw	18	3400014	Screw, Grounding		W11504624	Right Hand
5	W11296374	Screw	19	W10819539	Sound Insulation, Bottom	25	W11364953	Screw
6	8269145	Bracket, Undercounter	20	8268990	Bushing, Door Spring	26	489470	Screw
7	W11623675	Support, Bottom	21	W10732961	Bracket, Heater Support			
8	W10619352	Leveler, Leg	22	W10441445	Heater Element Assembly			
9	W10337934	Spring, Door Balance			(Includes Heater Washer & Nut)			
10	W10902242	Wheel Assembly						
11	3400892	Screw						
12	8268991	Cover, Terminal Box						
13	W10866979	Shield, Tub Sound			NOTE: If heater element is removed, it must be replaced.			
14	W11525335	Clip, Thermostat						


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10455271	Cover, Outlet	8	W10724439	Pump, Drain	16	W10445975	Hose Assembly (Includes 2 Clamps)
2	W10455268	Sump With Seal (Also Order Items 12 & 16)	9	8269144	Hose, Drain	17	W10491331	Sprayarm
3	W10463906	Screen	10	370445	Clamp, Hose	18	W10910428	Motor, Diverter
4	W10348407	Screw	11	W11525024	Sensor, Temperature	19	9741232	Screw
5	W11525550	Sump & Motor Assembly	12	W11182008	Grommet	20	W10476221	Disc, Diverter
6	W10372113	Tab, Sump	13	8269146	Clamp, Hose			
7	W10789806	Filter Cup Assembly	14	W10195086	Motor, Isolator			
			15	W11521436	Motor (Also Order Items 12 & 16)			


UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11499881	Feed Tube Assembly (Includes Items 2 & 3)	2	W11504677	Sprayarm, Third Level	4	W11533287	Manifold
			3	W11039888	Retainer	5	W11533286	Sprayarm, Upper
						6	W10165274	Screw


UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10847876	Dishrack, Upper	7	W11267702	Button, Adjuster Arm
2	W11186528	Tine Row, Fold Down	8		Rack Adjuster
3	3385089	Track, Dishrack		W11503620	Left Hand
4	W10082860	Stop, Track (Non-Removable)		W11503619	Right Hand
5	W11179794	Positioner	9	3379676	Wheel
6	W11179753	Clip, Pivot	10	W11180178	Leveler, Adjuster Arm
			11	W11509750	Clip, Adjuster Arm


LOWER RACK PARTS



LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10525646	Dishrack, Lower	3	W10179397	Silverware Basket Assembly	4	W10056272	Tine Row, Fold Down
2	W10082868	Wheel & Transport Assembly				5	W10078215	Retainer, Tine Row Combo

THIRD LEVEL RACK AND TRACK PARTS



THIRD LEVEL RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11441109	Track, Dishrack	3	W11048219	Wheel	4	W11084874	Track Stop, Front
2	W11507404	Rack, Third Level				5	W11084872	Track Stop, Rear

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		SIDE PANEL KITS
	8171657	Black
	8171659	Stainless Steel
		MOISTURE BARRIER KIT
	4396277	Barrier Kit
		DRAIN HOSE
	3385556	12 Ft.
	4317824	Power Cord Kit (Included Cord & Misc. Hardware)
	8171477	Floor Mount Kit
	8212560	Side Mount Kit