




ELECTRIC WALL OVEN

MODELS:

JJW3830LM01 (Floating Glass Black)


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	10	W10655463	Bracket, Blower (Left)	21	W10575307	Jumper Harness, Power Supply
	W11340513	Owner's Manual		W10655462	Bracket, Blower (Right)			FOLLOWING PARTS NOT ILLUSTRATED
	W11423731	Quick Start Guide						
	W11399179	Tech Sheet	11	4451758	Block, Foam		W11332799	Harness, Main
2		Assembly, Control Panel	12	W11179509	Tray, Electronic		W11249916	Harness, Signal
	W11301919	Black	13	W11166802	Divider, Chassis Back		W11264646	Harness, Door Latch
3	W11250487	Appliance Manager, Copernicus	14	W11168600	Cover, Chassis Top Front (30")		W10562910	Harness, EOL
4	W10489172	Screw	15	W11223325	Cover, 30 IN Chassis Top Back		W11409842	Antenna
5	W11397930	Blower					4450800	Screw, Grounding
6	W10351295	Bumper	16	W10728475	Gasket, Rubber		313438	Clip, Harness
7	W11339492	Screw (Black)	17	W10566973	Harness, Keypad (Left To Center)		W11132988	Strap, Lead Ground
8	7101P426-60	Screw	18	W10524350	Harness, Keypad (Right To Center)		4448664	Clamp, Conduit
9	7101P434-60	Screw					W10655464	Bracket, Harness
			19	W10568405	Assembly, Speaker		W11394923	Bag, Hardware
			20	W10668510	Housing			


OVEN PARTS



OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11165250	Duct, Chassis Back (Upper)	21	W11244446	Duct, Bottom Chassis	39	W11284709	Assembly, Light (Top)
2	W11085298	Tube, Vent	22	W11356753	Trim, Bottom Vent Black	40	W10169757	Bulb, Light
3	W11239070	Receiver, Hinge (Left)	23	W11135135	Support, Air Channel	41	W10169756	Lens, Light
	W11239072	Receiver, Hinge (Right)	24	W11390667	Spacer, Chassis Bottom Duct	42	W11256420	Base, Top Back Exhaust
4	W11558603	Spacer, Base	25	W11167419	Cover, Suction (Left)	43	W11256421	Cover, Top Back Exhaust
5	W11655005	Latch, Motorized		W11186675	Cover, Suction (Right)	44	W11256430	Base, Lower Back Exhaust
6	W11168071	Top, Chassis	26	8285593	Cover, Connector	45	W11256431	Cover, Lower Back Exhaust
7	W11205574	Assembly, Oven Light	27	7101P426-60	Screw	46	W11249635	Screw
8	W11245118	Foot, Base	28	W10472386	Lens, Light	47	W11256432	Deflector, Lower Back Exhaust
9	W10904163	Deflector, Blower	29	W11235460	Cover, Side Trim (Left)	48	W11404000	Screw
10	W10254050	Screw		W11235461	Cover, Side Trim (Right)	49	W11211345	Foam, U-Bracket
11	W11608108	Gasket	30	W11342780	Bracket, Top Front			FOLLOWING PARTS NOT ILLUSTRATED
12	W11256424	Cover, Vent Exhaust	31	W10472384	Bulb, Light	W11188284		Insulation, Wrap
13	W11165274	Side, Chassis	32	W11219304	Duct, Chassis Back (Lower)	W11244449		Insulation, Top Back
14		Back, Chassis (Not Serviced)	33	W11256423	Base, Vent Exhaust			
15		Liner, Oven (Not Serviceable)	34	W11186652	Bracket, U-Shape			
16	W11346074	Probe, Sensor	35	W11235482	Vent, Center 30"			
17	W11166315	Bumper and Screw	36	W11334857	Vent, Top 30 IN			
18	4449751	Thermostat (TOD)	37	W11245114	Foot, Chassis (Left)			
19	W11135103	Base, Chassis		W11245116	Foot, Chassis (Right)			
20		Assembly, Bottom Vent	38	W11344645	Hat Bracket, Vent			
	W11369884	Black						


UPPER OVEN DOOR PARTS



UPPER OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11304273	Air Divider Assembly	7		Door Assembly (Includes Hinges)	12	W11302803	Bracket, Glass (Left)
2	W11132942	Spacer, Handle		W11287485	Stainless	13	W11302802	Bracket, Glass (Right)
3	W10319024	Washer, Door	8		Assembly, Handle	14	W11302954	Bracket, Glass Reinforcement
4	W11317741	Nut		W11411894	Stainless	15	W10517428	Spacer, Vent
5	W11302773	Rail, Door (Left)	9	W11260091	Glass Cavity Assembly	16	694091	Screw
	W11302780	Rail, Door (Right)				17	W11290045	Screw
6	W11111221	Hinge, Door (Left)	10	3196183	Screw	18	W10443110	Screw
	W11111222	Hinge, Door (Right)	11	W11597415	Top Vent Trim Assembly			


LOWER OVEN DOOR PARTS



LOWER OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11304273	Air Divider Assembly	7		Door Assembly (Includes Hinges)	12	W11302803	Bracket, Glass (Left)
2	W11132942	Spacer, Handle		W11303867	Stainless	13	W11302802	Bracket, Glass (Right)
3	W10319024	Washer, Door	8		Assembly, Handle	14	W11302954	Bracket, Glass Reinforcement
4	W11317741	Nut		W11411894	Stainless	15	W10517428	Spacer, Vent
5	W11302773	Rail, Door (Left)	9	W11260091	Glass Cavity Assembly	16	694091	Screw
	W11302780	Rail, Door (Right)				17	W11290045	Screw
6	W11111221	Hinge, Door (Left)	10	3196183	Screw	18	W10443110	Screw
	W11111222	Hinge, Door (Right)	11	W11597415	Top Vent Trim Assembly			

INTERNAL OVEN PARTS



INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11238159	Element, Broil	9	W11313747	Assembly, Baffle	17	W10854021	Assembly, Convection Element
2	W11242906	Rack, Oven	10	W10853277	Shield, Convection	18	W11256305	Rack, Sliding
3	W10318198	Tray, Hidden Bake	11	W10663735	Element, Convection	19	9755542	Probe, Temperature
4	7101P434-60	Screw	12	W10236129	Screw	20	W10803141	Blade, Convection Fan
5	7101P426-60	Screw	13	W11235537	Reflector, Broil	21	W11433702	Nut, Acorn (LH)
6	W10282957	Crossbar, Hidden Bake Tray	14	W10588737	Shield, Broil Front		W10803140	Nut, Acorn (RH)
7	W11292248	Element, Bake	15	W11252826	Jack, Meat Probe	22	W10739592	Screw
8	W11200176	Assembly, Convection Motor	16	W11033111	Nut, Locking			

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		PAINT, TOUCH-UP (1/2oz.)
	72017	White
	72032	Black
		PAINT, SPRAY
	285006	Black
	350938	Gray Primer
		ADHESIVE
	482338	Sealer, Silastic
		ACCESSORY PARTS
	W10123240	Rack, Broiler Pan and Roasting
		Assembly, Bottom Vent
	W11369889	Stainless
		Trim, Tall Vent
	W11570325	Black