




Dishwasher

MODELS:

WDT540HAMZ4 (Stainless)


DOOR AND PANEL PARTS



DOOR AND PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5		Access Panel (Includes Hardware)	12		Access Panel & Insulation Assy
	W11650522	Energy Guide		W10441006	Black		W10369023	Black
	W11532445	Owners Manual	6	W10316572	Screw	13	W10519755	Insulation, Toe Panel
	W11532444	Tech Sheet	7	8268961	Sleeve, Friction	14	W10711884	Screw
2		Arm, Hinge	8	W10692757	Barrel Nut, Front Panel	15		Fastener
	W11484017	Left Hand	9	W11504190	Light, Pipe		W10503548	Black
	W11484018	Right Hand	10	3400071	Screw	16	W10884775	Badge
3	W10803537	Stiffener, Door	11	W10315897	Insulation, Front Panel	17	W11049903	Stud, Mounting
4		Panel, Front (Includes 6,8,9,16 & 17)				18		Handle
	W11528196	Stainless					W11554913	Stainless


CONTROL PANEL AND LATCH PARTS



CONTROL PANEL AND LATCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly	3	W10825369	Brace, Connector	6	W10653840	Latch Assembly (Includes Switch)
	W11504635	Black	4	W11516221	Control, Electronic			
2	W10825638	Box, Connector	5	W10348408	Screw	7	W10177098	Screw

INNER DOOR PARTS




INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10348409	Screw
2	W11050927	Seal, Console/Door
3	W11631034	Inner Door Assembly

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10920683	Door Bottom, Seal
5	W11574971	Vent Assembly
6	W11476843	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	W11531479	Deflector, Vent
8	W10620296	Dispenser Assembly
9	W11515203	Wiring Harness
10	W11184028	Gasket, Vent


FILL, DRAIN AND OVERFILL PARTS



FILL, DRAIN AND OVERFILL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	370445	Clamp, Hose	6	371505	Clamp, Hose	10	304231	Screw
2	W10769066	Inlet Hose	7	W11669945	Fill Valve Assembly	11	W10195039	Switch, Overfill Control
3	W10195536	Inlet, Water (Also Order Item 4)	8	W10786175	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)	12	W10316267	Standpipe, Overfill
4	8531323	Gasket				13	W10346525	Float & Retainer Assembly
5	W10508676	Nut, Inlet (Also Order Item 4)	9	W10545278	Drain loop with check valve assembly	14	W10195037	Lever, Overfill Switch


TUB AND FRAME PARTS



TUB AND FRAME PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10908439	Tub Assembly	12	8268991	Cover, Terminal Box	21	W10732961	Bracket, Heater Support
2	W11656602	Shield, Thermostat	13	W10866979	Shield, Tub Sound	22	W10441445	Heater Element Assembly
3	W11425053	Seal, Tub	14	W11525335	Clip, Thermostat			(Includes Heater Washer & Nut)
4	W10341745	Screw	15	3371618	Thermostat			NOTE: If heater element is removed, it must be replaced.
5	W11296374	Screw	16	W10544004	Strike, Latch			
6	8269145	Bracket, Undercounter	17	3378128	Washer, Pronged Cup			
7	W11623675	Support, Bottom	18	3400014	Screw, Grounding			
8	W10619352	Leveler, Leg	19	W10819539	Sound Insulation, Bottom	23	W10277003	Screw
9	W10337934	Spring, Door Balance				24	489470	Screw
10	W10902242	Wheel Assembly	20	8268990	Bushing, Door Spring			
11	3400892	Screw						


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10455271	Cover, Outlet	6	W10372113	Tab, Sump	13	8269146	Clamp, Hose
2	W10482462	Sump With Seal (Also Order Items 12 & 16)	7	W10789806	Filter Cup Assembly	14	W10195086	Motor, Isolator
3	W10463906	Screen	8	W10724439	Pump, Drain	15	W11521435	Motor (Also Order Items 12 & 16)
4	W10348407	Screw	9	8269144	Hose, Drain	16	W10445975	Hose Assembly (Includes 2 Clamps)
5	W11525546	Sump & Motor Assembly	10	370445	Clamp, Hose	17	W10491331	Sprayarm
			11	W11525024	Sensor, Temperature			
			12	W11182008	Grommet			


UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11540183	Feed Tube Assembly	4	W10340681	Manifold
2	W10165274	Screw	5	W10328508	Feed Tube Retainer
3	W10498900	Sprayarm			


UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10826746	Dishrack, Upper	4	W10082860	Stop, Track (Non-Removable)	6	W10380410	Cupshelf, Small
2	W10306228	Track, Spacer				7	3379676	Wheel
3	3385089	Track, Dishrack	5	W10845762	Mount, Wheel Assembly			

LOWER RACK PARTS



LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10300732	Dishrack, Lower
2	W10082868	Wheel & Transport Assembly
3	W10179397	Silverware Basket Assembly

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		SIDE PANEL KITS
	8171659	Stainless Steel
		MOISTURE BARRIER KIT
	4396277	Barrier Kit
		DRAIN HOSE
	3385556	12 Ft.
		Handle Assembly
	4317824	Power Cord Kit (Included Cord & Misc. Hardware)
	8171477	Floor Mount Kit
	8212560	Side Mount Kit