




COMMERCIAL GAS DRYER

MODELS:

CGSP2978JQ0 (White)


CONTROL PANEL AND SEPARATOR PARTS



CONTROL PANEL AND SEPARATOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11651084	Facia	16	W11223375	Assembly, Lock	30	W10163036	Bezel
2	W10386302	Screw	17	W10913660	Cam, Locking	31	W10807484	Harness, Collar
3	W10137769	Cover, Card Reader	18	W10160652	Bracket-Switch	32	W10188051	Jumper, Line Filter
4	W10145157	Retainer, Facia Cover	19	W10447152	Switch, Service Access	33	W10769481	Jumper, Coin Box
5	3400618	Screw	20	3400408	Screw	34	W10111027	Jumper, Transformer
6	W10133268	Cover, Display	21	3396795	Cover, Terminal Block	35	W10807493	Jumper, Lower to Collar
7	W10657185	Plate, Control Mounting	22	W10850065	Cover, Terminal Block	36	W10155270	Cable Tie
8	W10140652	Screw	23	3390814	Screw			Coin Mechanism Parts May Be Ordered From Whirlpool or Vendor Below:
9	W11582595	Control Board	24	W11332324	Power Cord			Greenwald Industries 212 Middlesex Ave Chester, CT 06412 1-800-221-0982 sales@greenwaldindustries.com
10	W11455510	Collar	25	W10773242	Screw			
11	W10133514	Standoff, Circuit Board	26	694415	Clip, Strain Relief			
12	W10139046	Nut	27	W11498818	Instructions, Installation (Card Reader)			
13	W10133285	Transformer 120Vac To 22.5Vac	28	W10239515	Harness, Card Reader			
14	W10306592	Filter, RFI	29	W10143462	Screw			
15	8533971	Screw						


LOWER CABINET AND FRONT PANEL PARTS



LOWER CABINET AND FRONT PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts (Located Behind Toe Panel)	15	696144	Strike, Door	37	W10322546	Door, Front
	W11647901	Installation Instructions	16	3387242	Seal, Front Panel	38	8283298	Jumper, Door Switch
	W11651038	Tech Sheet	17	3391915	Screw	39		Panel, Toe
	W11498818	Instructions, Installation (Card Reader)	18	8066134	Switch Assembly		697215	White
			19	8066120	Lever, Belt Switch	40	W10116360	Handle, Door
2	693152	Bumper	20	3394881	Switch, Belt	41	W10237959	Switch, Door
3	3390663	Screw	21	3398948	Wire, Jumper (Broken Belt Switch)	42	W10291934	Clip
4	3391846	Clip, Front Panel	22	W10167612	Wire, Belt Switch	43		Hinge & Pin Assembly
5		Plug, Hinge					W10279703	Silver
	W10191265	White	23	98129	Screw	44	98997	Clip
6	3387561	Clamp, Pipe	24	3390647	Screw	45	8529757	Bracket, Burner
7		Cabinet	25	W10323061	Door, Rear	46	W10576519	Seal, Deflector
	W11161907	White	26	3388229	Retainer	47	W11325273	Boot, Foot
9	660658	Clamp, Motor	27	W10396031	Motor	48	W11566859	Burner Assembly
10	W10446781	Spring, Idler	28	3393657	Restrainer, Belt	49	W10366705	Screw
11	3389420	Screw	29	3394341	Pulley, Motor	50	686590	Ignitor
12	W10344193	Pulley-Idler Assembly	30	W10131172	Belt, Drive	51	3387057	Screw
13	697773	Screw	31	342055	Screw	52	8281911	Valve, Gas (Complete) 60 Hz
14		Panel, Front	32	3387118	Bracket, Motor	53	343641	Screw
	W10192882	White	33	3389889	Bracket, Support	54	693995	Screw
			34	W10807483	Harness, Upper/Lower			DRYER EXHAUST KIT NOT INCLUDED
			35	3390735	Seal, Door			
			36	3392538	Assembly, Door Catch		W10470674	Kit, 4-Way Venting

UPPER CABINET AND FRONT PANEL PARTS



UPPER CABINET AND FRONT PANEL PARTS


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3390663	Screw	22	W10167612	Wire, Belt Switch	43	3400523	Bolt, Security
2	693152	Bumper	23	98129	Screw	44	3389889	Bracket, Support
3	3391846	Clip, Front Panel	24	W10116360	Handle, Door	45	342055	Screw
4	3391915	Screw	25	3389233	Bushing	46		Plug, Hinge
5	W10807483	Harness, Upper/Lower	26	3387118	Bracket, Motor		W10191265	White
6	3392538	Assembly, Door Catch	27	W10396031	Motor	47	98997	Clip
7		Cabinet	28	3393657	Restrainer, Belt	48	693995	Screw
	W11161907	White	29	3394341	Pulley, Motor	49	W10576519	Seal, Deflector
8	3387561	Clamp, Pipe	30	W10131172	Belt, Drive	50	8529757	Bracket, Burner
9	660658	Clamp, Motor	31		Panel, Front	51	W11566859	Burner Assembly
10	W10446781	Spring, Idler		W10192882	White	52	W10366705	Screw
11	3389420	Screw	32	696144	Strike, Door	53	686590	Ignitor
12	W10344193	Pulley-Idler Assembly	33	3387242	Seal, Front Panel	54	3387057	Screw
13	697773	Screw	34		Panel, Toe	55	8281911	Valve, Gas (Complete) 60 Hz
14		Hinge & Pin Assembly	35	697215	White Top	56	343641	Screw
	W10279703	Silver		3389351	White	57	3392100	Foot, Dryer DRYER EXHAUST KIT NOT INCLUDED
15	W10291934	Clip	36	W10322546	Door, Front			
16	3390647	Screw	37	W10323061	Door, Rear		W10470674	Kit, 4-Way Venting
17	3390735	Seal, Door	38	8283298	Jumper, Door Switch			
18	8066134	Switch Assembly	39	3388229	Retainer			
19	8066120	Lever, Belt Switch	40	W10117347	Cotter Pin			
20	3394881	Switch, Belt	41	W10237959	Switch, Door			
21	3398948	Wire, Jumper (Broken Belt Switch)	42	3979115	Bracket, Angle			

UPPER AND LOWER BULKHEAD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10865336	Assembly, Air Duct	15	697693	Baffle, Drum	31	697770	Seal, Plate Cover
2	8533971	Screw	16	W10219342	Screw	32	W10135254	Housing, Blower
3	W11162455	Bulkhead, Rear	17	8066086	Plug, Drum Hole	33	3392519	Fuse, Thermal (91C)
4	3390647	Screw	18	W10521118	Seal, Drum	34	W10131836	Thermostat
5	8578825	Bracket, Drum Light	19	W10692558	Grill, Outlet	35	W10193019	Thermostat, Electronic (155F)
6	3402841	Lens, Drum Light	20	3387230	Screw	36	693995	Screw
7	W10001120	Nut, Hex (Left Hand Thread)	21	695240	Screw	37	8066224	Pipe, Exhaust
8	3387459	Washer	22	W10685669	Assembly, Outlet Housing	38	8572105	Clip, Exhaust
9	W10512946	Washer, Tri Ring	23	W10049370	Screen, Lint	39	3391912	Thermostat, Hi Limit
10	W10359271	Shaft, Drum Roller - Right Hand Thread	24	697557	Bulkhead, Front	40	8573713	Cut-Off, Thermal
11	W10314171	Roller, Support	25	3357011	Screw	41	338906	Sensor, Radiant
12	W10359272	Shaft, Drum Roller - Left Hand Thread	26	697814	Seal, Drum Front	42	90767	Screw
13	3934666	Nut, Hex	27	8066168	Assembly, Lint Duct	43	8573824	Funnel, Burner
14	W10545923	Assembly, Drum	28	489463	Screw	44	3401707	Jumper, Wire
			29	W10345456	Clip, Spring			
			30	W10349492	Wheel, Blower			

BURNER ASSEMBLY PARTS

USE WITH TYPE 1 - NATURAL
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES



BURNER ASSEMBLY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11566859	Burner Assembly	11	694421	Screw, Coil	19	W10097610	Pipe, Gas Supply
2	688617	Tube, Burner	12	694538	Bracket, Coil	20	697441	Valve, Gas
3	694298	Bracket, Ignitor	13	694540	Coil, 60 Hz. (2 Terminal) (Main)	21	233076	Nut, Compression
4	686590	Ignitor				22	3393767	Pipe, Tail
5	W10366705	Screw	14	694539	Coil, 60 Hz (Split) (3 Terminal) (Pilot Position)			Following Parts Not Illustrated
6	343641	Screw						
7	3389871	Base, Burner					49572A	Conversion Kit (Type 1 and 2) to Type (4) L.P.G.
8	3387057	Screw	15	694424	Leak, Limiter			
9		Orifice, Burner	16	694423	Screw, Regulator Adjustment			
	3397656	Type 1 (Natural Gas)						
10	8281911	Valve, Gas (Complete) 60 Hz	17	694422	Spring, Regulator			
			18	239822	Plug, Pipe			

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	4392067	Kit, Dryer Repair
	285875	Kit, Security
	8522199	Kit, Dryer Vent Testing

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350938	Gray Primer

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)