




COMMERCIAL ELECTRIC DRYER

MODELS:

CESP2958JQ0 (White)


CONTROL PANEL AND SEPARATOR PARTS



CONTROL PANEL AND SEPARATOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11651081	Facia Console	19	W10159907	Assembly, Mounting Strap Weld	34	W10111027	Jumper, Transformer
2	W10386302	Screw	20	W10001120	Nut, Hex (Left Hand Thread)	35	W10807493	Jumper, Lower to Collar
3	W10133268	Cover, Display	21	W11109086	Box, Coin	36	279318	Terminal, Brass and Tinned (Includes Terminal Block Screw Kit)
4	W10657185	Plate, Control Mounting	22	W11109083	Assembly, Vault Body	37	279393	Screw Kit, Terminal Block
5	W10140652	Screw	23	W10133242	Assembly, Single Coin Drop	38	W10155270	Cable Tie
6	W11582595	Control Board	24	W10137319	Bolt, Hex Bar	39	W10169579	Kit-Coin Box, Security (To be serviced as a kit)
7	W10133514	Standoff, Circuit Board	25		Coin Optic Sensor Assembly	40	W11208380	Assembly, Lock (Bayonet)
8	W11455498	Collar		W10247389	White			Coin Mechanism Parts May Be Ordered From Whirlpool or Vendor Below:
9	W10139046	Nut	26	W10142655	Screw			Greenwald Industries 212 Middlesex Ave Chester, CT 06412 1-800-221-0982 sales@greenwaldindustries.com
10	W10133285	Transformer 120Vac To 22.5Vac	27	3397659	Block, Terminal			
11	W10827406	Relay, Motor	28	3400000	Screw			
12	8533971	Screw	29	W10850065	Cover, Terminal Block			
13	W11223375	Assembly, Lock	30	3396795	Cover, Terminal Block			
14	W10913660	Cam, Locking	31	3390814	Screw			
15	W10160652	Bracket-Switch	32	W10807485	Harness, Collar (Includes Motor Relay)			
16	W10447152	Switch, Service Access	33	W10773242	Screw			
17	3400408	Screw						
18	W10131838	Switch, Vault Service Door						


LOWER CABINET AND FRONT PANEL PARTS



LOWER CABINET AND FRONT PANEL PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts (Located Behind Toe Panel)	16	3388229	Retainer	33	W10576519	Seal, Deflector
	W11647901	Installation Instructions	17	98997	Clip	34	693152	Bumper
	W11651038	Tech Sheet	18	3390735	Seal, Door	35		Plug, Hinge
2	3391915	Screw	19	W10291934	Clip	W10191265		White
3	3390663	Screw	20	W10807486	Harness, Upper/Lower	36		Panel, Front
4	3391846	Clip, Front Panel	21		Hinge & Pin Assembly	W10192882		White
5	W10131172	Belt, Drive		W10279703	Silver	37	696144	Strike, Door
6	697773	Screw	22	8066134	Switch Assembly	38	3387242	Seal, Front Panel
7		Cabinet	23	3394881	Switch, Belt	39	3392538	Assembly, Door Catch
	W11161907	White	24	8066120	Lever, Belt Switch	40		Panel, Toe
9	660658	Clamp, Motor	25	98129	Screw		697215	White
10	W10446781	Spring, Idler	26	W10167612	Wire, Belt Switch	41	W10237959	Switch, Door
11	3389420	Screw	27	3398948	Wire, Jumper (Broken Belt Switch)	42	W10322546	Door, Front
12	W10116360	Handle, Door	28	W10396031	Motor	43	W10323061	Door, Rear
13	W10344193	Pulley-Idler Assembly	29	3394341	Pulley, Motor	44	W11378153	Cover, Terminal
14	342055	Screw	30	3393657	Restrainer, Belt	45	98139	Screw
15	W11325273	Boot, Foot	31	8283298	Jumper, Door Switch			DRYER EXHAUST KIT NOT INCLUDED
			32	3387118	Bracket, Motor	W10470674		Kit, 4-Way Venting


UPPER CABINET AND FRONT PANEL PARTS



UPPER CABINET AND FRONT PANEL PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	3390663	Screw	17	3391846	Clip, Front Panel	34	W10807486	Harness, Upper/Lower
2	3391915	Screw	18	3392538	Assembly, Door Catch	35	3390647	Screw
3		Plug, Hinge	19	W10291934	Clip	36	3979115	Bracket, Angle
	W10191265	White	20		Hinge & Pin Assembly	37	3400523	Bolt, Security
4	W10323061	Door, Rear		W10279703	Silver	38	8283298	Jumper, Door Switch
5	W10322546	Door, Front	21	8066134	Switch Assembly	39	3389233	Bushing
6	697773	Screw	22	3394881	Switch, Belt	40	W10117347	Cotter Pin
7		Cabinet	23	8066120	Lever, Belt Switch	41	W10237959	Switch, Door
	W11161907	White	24	98129	Screw	42		Panel, Front
8	W10576519	Seal, Deflector	25	W10167612	Wire, Belt Switch		W10192882	White
9	660658	Clamp, Motor	26	3398948	Wire, Jumper (Broken Belt Switch)	43	696144	Strike, Door
10	W10446781	Spring, Idler	27	W10396031	Motor	44	3387242	Seal, Front Panel
11	3389420	Screw	28	3393657	Restrainer, Belt	45	342055	Screw
12		Top	29	3394341	Pulley, Motor	46	3388229	Retainer
	3389351	White	30	W10131172	Belt, Drive	47	3392100	Foot, Dryer
13	W10344193	Pulley-Idler Assembly	31	3390735	Seal, Door	48	W11378153	Cover, Terminal
14		Panel, Toe	32	3387118	Bracket, Motor	49	98139	Screw
	697215	White	33	693152	Bumper			DRYER EXHAUST KIT NOT INCLUDED
15	W10116360	Handle, Door				W10470674		Kit, 4-Way Venting
16	98997	Clip						

UPPER AND LOWER BULKHEAD PARTS



UPPER AND LOWER BULKHEAD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11104018	Assembly, Air Duct	17	8066086	Plug, Drum Hole	35	W10193019	Thermostat, Electronic (155F)
2	8533971	Screw	18	W10521118	Seal, Drum	36	693995	Screw
3	W11162455	Bulkhead, Rear	19	W10692558	Grill, Outlet	37	8066224	Pipe, Exhaust
4	3390647	Screw	20	3387230	Screw	38	8572105	Clip, Exhaust
5	8578825	Bracket, Drum Light	21	695240	Screw	39	W10891205	Assembly, Weld Heater Box
6	3402841	Lens, Drum Light	22	W10685669	Assembly, Outlet Housing	40	279973	Kit, Thermal Cut-Off (Includes Thermostat)
7	W10001120	Nut, Hex (Left Hand Thread)	23	W10049370	Screen, Lint	41	3391914	Thermostat HL-295/215
8	3387459	Washer	24	697557	Bulkhead, Front	42	90767	Screw
9	W10512946	Washer, Tri Ring	25	3357011	Screw	43	8066099	Bracket, Heater Box
10	W10359271	Shaft, Drum Roller - Right Hand Thread	26	697814	Seal, Drum Front	44	W10832958	Element, Heater
11	W10314171	Roller, Support	27	8066168	Assembly, Lint Duct	45	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)
12	W10359272	Shaft, Drum Roller - Left Hand Thread	28	489463	Screw			
13	3934666	Nut, Hex	29	W10345456	Clip, Spring			
14	W10545923	Assembly, Drum	30	W10349492	Wheel, Blower			
15	697693	Baffle, Drum	31	697770	Seal, Plate Cover			
16	W10219342	Screw	32	W10135254	Housing, Blower			
			33	3392519	Fuse, Thermal (91C)			
			34	W10131836	Thermostat			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

	72017	White
--	-------	-------

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

	799344	White (Uncut)
--	--------	---------------

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

	350930	White
	350938	Gray Primer

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

	4392067	Kit, Dryer Repair
	285875	Kit, Security
	8522199	Kit, Dryer Vent Testing