




GAS RANGE

MODELS:

WFGS5030RS0 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	9		Panel, Manifold End Cap	18	W11352018	Spreader, Flame (Left Front and Right Front)
	W11642080	Owners Manual		W11641960	Stainless (Left)		W11352020	Spreader, Flame (Right Rear)
	W11639169	Tech Sheet		W11641959	Stainless (Right)		W11352021	Spreader, Flame (Left Rear)
	W11641568	Quick Start Guide	10	W11379945	Bracket, Anti-Tip	19	W11357363	Oval Burner Assembly
2		Burner Cap Kit	11	7101P485-60	Screw, Anti-Tip Kit			FOLLOWING PARTS NOT ILLUSTRATED
	W11395131	Black (Set of 4)	12	W11672010	Grate, Bumper		W11374168	Harness, Main
3	W11367107	Burner Kit	13	W11637551	Spring, Clip		W11448086	Harness, Bake and Broil
4		Cooktop	14	W11736687	Cooktop, Front Bracket		3196520	Clip, Wire
	W11279788	Black					313438	Clip, Harness
5		Panel, Manifold	15		Cooktop Frame		3196896	Clip, Wire
	W11457176	Stainless		W11736695	Black		W10182767	Tie, Manifold Wire
6		Knob, Control	16	9780274	Screw			
	W11632040	Stainless	17	W11366598	Spark, Module Bracket			
7		Grate Kit						
	W11368270	Black (Set of 3)						
8	W10673618	Screw						


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	4	W11736648	Bracket, Mounting (DSI)	8	W11290750	Bracket, Control
	W11327041	Black (Left)				9	W11350452	Spark Module
	W11327043	Black (Right)	5	W10818365	Module, Spark DSI	10	W11393670	Cover, Back
2	W11736649	Shield, Heat	6	3196178	Screw	11	3196169	Screw
3		Panel, Control	7		Panel, Lower	12		Control, Electronic (LCX)
	W11299266	Stainless		W11625443	Black		W11639407	Black


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11402213	Screw	7	W11279819	Manifold Assembly	18	3196265	Screw
2	W10827923	Electrode, Spring	8	W11279838	Valve, Single (Left Rear)	19	W10849722	Orifice (18K) (Right Front)
3	W11300869	Orifice Holder Assembly (15K) (Left Front)		W11279839	Valve, Single (Left Front, Right Front and Center)		W10907868	Orifice (Left Rear)
	W11300871	Orifice Holder Assembly (10K) (Left Rear)		W11279837	Valve, Single (Right Rear)		W10849719	Orifice (5K) (Right Rear)
	W11300879	Orifice Holder Assembly (18K) (Right Front)	9	W10224921	Bracket, Aegis		W10849716	Orifice (12K) (Center)
	W11300867	Orifice Holder Assembly (5K) (Right Rear)	10	3196385	Screw		W10849717	Orifice (15K) (Left Front)
	W11341174	Orifice Holder Assembly (12K) (Center)	11	3400016	Screw			FOLLOWING PARTS NOT ILLUSTRATED
4	W11384792	Tubing (Manifold to Regulator)	12	W10714060	Element, Broiler		W11368273	LP 5 Orifice Conversion Kit
5	W11637977	Harness, Igniter (Includes Switches)	13	W10184491	Spreader, Flame (Oven)		W10838304	Orifice, LP Bake
6	W11450459	Electrode, Bake	14	9758078	Burner, Bake			
			15	W10818355	Regulator			
			16	W11428831	Electrode (Left Front, Left Rear)			
				W11428858	Electrode (Right Front, Right Rear, Center)			
			17	W10362924	Screw			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11366110	Box, Flue	17	9757239	Rod, Door Switch	32	W10107820	Rear Door Latch Assembly
2	W11279866	Shield, Flue	18	W10031780	Screw	33	W10674705	Glide, Drawer Front
3	W10067840	Screw	19	3400080	Screw	34	3196178	Screw
4		Panel, Side	20	W10158780	Cover, Rear Fan	35	W11173792	Rack, Oven
	W11445467	Black	21	W11491751	Seal, Door	36	W11353930	Fan, Convection
5	W10137382	Clip, Panel	22	W10435470	Brace, Main Back	37	W11464547	Bracket, Front Frame
6	W11287215	Bracket, Manifold	23	W11379353	Retainer, Insulation (Left)	38	W11373155	Cover, Conv Fan
7	W10362924	Screw		W11379943	Retainer, Insulation (Right)	39	W10516115	Screw
8	3196560	Screw						FOLLOWING PARTS NOT ILLUSTRATED
9	W10341186	Front Foot Assembly	24	3196560	Screw			
10	W10058460	Foot, Leveling	25	W11661976	Cord, Power	W10818362		Insulation, Wrap
11	W11602073	Bottom, Oven	26	W10289077	Receiver, Hinge	W11407376		Insulation, Back
12	W10586204	Sensor	27	W11511828	Switch, Door			
13	8053967	Baffle, Burner Oven	28	W11634772	Light Assembly			
14	8053969	Shield, Heat	29	W10571723	Bulb, Halogen 40 Watts			
15	W11640074	Shield, Lower						
16	W10390008	Base Rail Assembly (Left)	30	9761013	Front Door Latch Assembly			
	W10390007	Base Rail Assembly (Right)	31	W10078370	Rod, Push Latch			

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Handle and Vent Assembly
	W11353054	Stainless
2	W10465158	Screw
3		Trim, Lower Door
	W11444043	Black
4	9761344	Liner, Door
5	W10031790	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	9758162	Glass, Inner
7	W10316950	Frame, Glass
8	W10278991	Insulation, Door Strip
9	W11380222	Retainer, Insulation
10	W10388635	Hinge, Door (Active)
11		Glass, Outer Door
	W11729636	Black

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
12		Trim, Door
	W10746436	Black (Left)
	W10746435	Black (Right)
13	W10327235	Screw
14	W11379944	Strap, Door
15	W10440013	Hinge, Door (Active)
16	W10884775	Badge
17	W10200660	Screw

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10674708	Glide, Drawer Rear	4		Panel, Drawer Front
2	W10688022	Drawer, Storage		W11190207	Stainless
3	W10462909	Bracket, Mounting	5	3196169	Screw

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4392899	Biscuit and Bisque
	72017	White
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	285006	Black
	350930	White

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	W10355016	Cleaner, Stainless Steel
	4396096RB	Griddle
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan and Roasting