




## **ELECTRIC RANGE**

### **MODELS:**

AER6603SFB6 (Black)


# COOKTOP PARTS



# COOKTOP PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>   | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>          | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                 |
|-----------------------------|-----------------|----------------------|-----------------------------|-----------------|-----------------------------|-----------------------------|-----------------|------------------------------------|
| 1                           |                 | Literature Parts     | 5                           | W10275048       | Element (3000 and 1400W)    | 8                           | W11379945       | Bracket, Anti-Tip                  |
|                             | W11469631       | Quick Start Guide    |                             |                 | (Left Front)                | 9                           | 7101P485-60     | Screw, Anti-Tip Kit                |
|                             | W11509598       | User Instructions    |                             | W10248261       | Element (1200W)             |                             |                 | FOLLOWING PARTS<br>NOT ILLUSTRATED |
|                             | W11393929       | Sheet, Tech          |                             |                 | (Left Rear and Right Front) |                             | W11452623       | Harness, Main                      |
| 2                           | W11600012       | Spring, Element      |                             | 8273993         | Element (1800W)             |                             | W11134603       | Harness, Cooktop (Left)            |
| 3                           | W11640572       | Pan, Radiant Element |                             |                 | (Right Rear)                |                             | W11134551       | Harness, Cooktop (Right)           |
| 4                           |                 | Cooktop              | 6                           | 3196169         | Screw                       |                             |                 |                                    |
|                             | W10853125       | Black                | 7                           | W10607641       | Bracket, Cooktop (Left)     |                             |                 |                                    |
|                             |                 |                      |                             | W10607642       | Bracket, Cooktop (Right)    |                             |                 |                                    |


# CONTROL PANEL PARTS



# CONTROL PANEL PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>        | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>          | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>        |
|-----------------------------|-----------------|---------------------------|-----------------------------|-----------------|-----------------------------|-----------------------------|-----------------|---------------------------|
| 1                           |                 | Endcap                    | 4                           | W10434452       | Switch, Infinite (Dual)     | 7                           |                 | Knobs                     |
|                             | W11130372       | Black (Left)              |                             |                 | (Left Front)                |                             | W10844801       | Black                     |
|                             | W11130379       | Black (Right)             |                             | 3148951         | Switch, Infinite            | 8                           | W10134247       | Shield, Heat              |
| 2                           | W10525121       | Bracket, Console Mounting |                             |                 | (Left Rear and Right Front) | 9                           | 3400882         | Screw                     |
| 3                           |                 | Panel, Console            |                             | 3148953         | Switch, Infinite (Green)    | 10                          | 8272473         | Cover, Upper Rear         |
|                             | W11157020       | Black                     |                             |                 | (Right Rear)                | 11                          |                 | Control, Electronic (LCX) |
|                             |                 |                           | 5                           | W10695491       | Bracket, Control            |                             | W11515098       | Black                     |
|                             |                 |                           | 6                           | 3196178         | Screw                       | 12                          | 3196165         | Screw                     |


# CHASSIS PARTS



# CHASSIS PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>            | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>              | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                       |
|-----------------------------|-----------------|-------------------------------|-----------------------------|-----------------|---------------------------------|-----------------------------|-----------------|------------------------------------------|
| 1                           | W10289077       | Receiver, Hinge               | 18                          | 3196172         | Screw                           | 36                          | W11464547       | Bracket, Front Frame                     |
| 2                           | W10134285       | Tube, Vent                    | 19                          | W10404688       | Clip, Oven Support              | 37                          | W11510560       | Barrier Rail, Rubber<br>(Left and Right) |
| 3                           |                 | Panel, Side                   | 20                          | 3186034         | Bracket, Service                | 38                          | W10031780       | Screw                                    |
|                             | W10162245       | Black                         | 21                          | W10245259       | Block, Terminal                 |                             |                 | FOLLOWING PARTS<br>NOT ILLUSTRATED       |
| 4                           | 3400029         | Nut                           | 22                          | W11034869       | Screw                           |                             | W10333344       | Insulation, Flue                         |
| 5                           | W11491751       | Seal, Door                    | 23                          | W10181986       | Sensor, Oven                    |                             | W10774939       | Insulation, Wrap                         |
| 6                           | 9757340         | Element, Broil                | 24                          | W11634772       | Light Assembly                  |                             | W11127325       | Insulation, Back                         |
| 7                           | W11111743       | Element, Bake                 | 25                          | W10571723       | Bulb, Halogen 40<br>Watts       |                             |                 |                                          |
| 8                           | W10326122       | Cover, Terminal Block         | 26                          | W10281322       | Kit, Bare Wire Adapter<br>Block |                             |                 |                                          |
| 9                           | 3196169         | Screw                         | 27                          | 3196154         | Screw                           |                             |                 |                                          |
| 10                          | W11173792       | Rack, Oven                    | 28                          | W11511828       | Switch, Door                    |                             |                 |                                          |
| 11                          | W10341186       | Front Foot Assembly           | 29                          | 9757239         | Rod, Door Switch                |                             |                 |                                          |
| 12                          | W10067840       | Screw                         | 30                          | W11092984       | Screen, Vent                    |                             |                 |                                          |
| 13                          | 8054068         | Retainer, Insulation          | 31                          | W10078380       | Rod, Latch                      |                             |                 |                                          |
| 14                          | W10137382       | Clip, Panel                   | 32                          | 9761013         | Front Door Latch<br>Assembly    |                             |                 |                                          |
| 15                          | W10390008       | Base Rail Assembly<br>(Left)  | 33                          | 3196560         | Screw                           |                             |                 |                                          |
|                             | W10390007       | Base Rail Assembly<br>(Right) | 34                          | W10107820       | Rear Door Latch<br>Assembly     |                             |                 |                                          |
| 16                          | W10058460       | Foot, Leveling                | 35                          | W10910404       | Counterweight                   |                             |                 |                                          |
| 17                          | 3196548         | Fuse, Thermal                 |                             |                 |                                 |                             |                 |                                          |

# DOOR PARTS




# DOOR PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>   |
|-----------------------------|-----------------|----------------------|
| 1                           |                 | Trim, Top            |
|                             | W10310922       | Black                |
| 2                           | W10168559       | Screw                |
| 3                           |                 | Handle, Door         |
|                             | W10323589       | Black                |
| 4                           | 9761344         | Liner, Door          |
| 5                           | W10031790       | Screw                |
| 6                           | 9758162         | Glass, Inner         |
| 7                           | W11380222       | Retainer, Insulation |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
| 8                           | W10299226       | Hinge, Active      |
| 9                           |                 | Glass, Outer       |
|                             | W11687921       | Black              |
| 10                          |                 | Trim, Side         |
|                             | W10746436       | Black (Left)       |
|                             | W10746435       | Black (Right)      |
| 11                          | W10327235       | Screw              |
| 12                          |                 | Trim, Lower        |
|                             | W11444043       | Black              |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>     |
|-----------------------------|-----------------|------------------------|
| 13                          | W11379944       | Strap, Door            |
| 14                          | W10200660       | Screw                  |
| 15                          | W10299227       | Hinge, Door (Passive)  |
| 16                          |                 | Badge                  |
|                             | W10846751       | Black                  |
| 17                          | W10316950       | Frame, Glass           |
| 18                          | W10278991       | Insulation, Door Strip |
| 19                          | W10031780       | Screw                  |

# DRAWER PARTS



# DRAWER PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>  | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>          | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>  |
|-----------------------------|-----------------|---------------------|-----------------------------|-----------------|-----------------------------|-----------------------------|-----------------|---------------------|
| 1                           |                 | Panel, Drawer Front | 3                           | W10688022       | Drawer, Storage             | 5                           | W10674708       | Glide, Drawer Rear  |
|                             | W11123900       | Black               | 4                           | W10462912       | Bracket, Mounting<br>Drawer |                             | W10674705       | Glide, Drawer Front |
| 2                           |                 | Rivet, Push         |                             |                 |                             | 6                           | 3196169         | Screw               |
|                             | 3196813         | Black               |                             |                 |                             |                             |                 |                     |

# OPTIONAL PARTS (NOT INCLUDED)

## REFINISHING MATERIAL

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>        |
|-----------------------------|-----------------|---------------------------|
|                             | 242756          | Oven Liner Touch Up Paint |

## INSULATION

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>               |
|-----------------------------|-----------------|----------------------------------|
|                             | 261514          | Insulation (1-1/2 x 24 x 120 in) |
|                             | 240132          | Insulation (2-1/2 x 22 x 120 in) |

## PAINT, TOUCH-UP (1/2OZ.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>      |
|-----------------------------|-----------------|-------------------------|
|                             | 72017           | White                   |
|                             | 72032           | Black                   |
|                             | 8212473         | Universal Silver        |
|                             | 511873          | White Porcelain (2 oz.) |

## PAINT, PRESSURIZED SPRAY (12 OZ.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|                             | 350930          | White              |
|                             | 285006          | Black              |
|                             | 206922          | Primer (White)     |

## PAINT, BULK (1 QT.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|                             | 799344          | White (Uncut)      |

## ACCESSORY PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>   |
|-----------------------------|-----------------|----------------------|
|                             | 3191048         | Glass Cleaner        |
|                             | 4396923         | Broiler Pan and Grid |