





ELECTRIC DRYER

MODELS:

WED560LHW2 (White)


TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4	W11255768	Channel, Water	10	W11314470	Assembly, Console (White)
	W11364660	Owners Manual	5	12990702	Screw	11	W10884773	Badge
	W11459719	Tech Sheet	6	W10208198	Bracket, Console	12	W11109747	Harness, Wiring (Main)
	W11457204	Wiring Diagram	7	W11231800	Seal			
	W11355749	Quick Start Guide	8	W10568405	Assembly, Speaker			
2	W10208383	Top, (White)	9	W11160620	Harness, User Interface			
3	3390647	Screw						


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	279318	Terminal, Brass and Tinned (Includes Terminal Block Screw Kit)	17	W11126752	Strike, Door	32	3393657	Restrainer, Belt
2	279393	Screw Kit, Terminal Block	18	W10288126	Screw	33	W11233966	Switch, Assembly
3	3397659	Block, Terminal	19	3357011	Screw	34	8564010	Assembly, Switch and Actuator
4	489463	Screw	20	3387242	Seal, Front Panel	35	W11159569	Bracket, Switch
5	W11394868	Cover, Terminal Block	21	W11307535	Assembly, Door Switch	36	W10167613	Wire, Belt Switch
6	3390647	Screw	22	3392100	Foot, Dryer	37	8539892	Wire, Motor To Belt Switch
7	W10208382	Bracket, Rear		279810	Foot, Optional (Extended Length Package Of 2) (Not Included)	38	98129	Screw
8	W10487431	Panel, Rear	23	W10344192	Assembly, Idler	39	W10836094	Pad, Sound
9	W10773242	Screw	24	343641	Screw	40	3405160	Belt, Drive (Blower Wheel)
10	3393008	Screw	25	W11084215	Bracket, Hinge			DRYER EXHAUST KIT NOT INCLUDED
11	3389420	Screw	26	W10446781	Spring, Idler			
12	8565046	Base, Cabinet	27	3387610	Belt, Drive			
13	W11461188	Appliance Control Unit (ACU)	28	W10121316	Clamp, Motor Mount			
14	W11177568	Panel, Side (White)	29	W10396034	Assembly, Motor 60 HZ.			
15	W10504381	Pad, Foam	30	3394341	Pulley, Motor			
16	W11413344	Panel, Front (White)	31	W10135695	Bracket, Motor			
							W10323246	Kit, 4-Way Vent


BULKHEAD PARTS



BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11104018	Assembly, Air Duct	14	W10521122	Seal, Drum Front	27	W11254843	Assembly, Collar (Includes Seal)
2	3390647	Screw	15	W10521118	Seal, Drum	28	W11231979	Wheel, Blower
3	W11162462	Bulkhead, Rear	16	W11344457	Element, Heater 5400W	29	W10211911	Housing, Blower
4	W10001120	Nut, Hex (Left Hand Thread)	17	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)	30	693995	Screw
5	3387459	Washer	18	W10672683	Assembly, Outlet Grill and Housing	31	W10693363	Fuse, Thermal (91C)
6	W10512946	Washer, Tri Ring	19	3387223	Sensor, Electrode	32	8577274	Thermistor
7	W10359271	Shaft, Drum Roller - Right Hand Thread	20	W10298258	Harness, Sensor	33	W10342188	Exhaust Pipe
8	W10314171	Roller, Support	21	W10516085	Lint Screen	34	W10344699	Collar, Duct
9	W10359272	Shaft, Drum Roller - Left Hand Thread	22	W10673493	Bulkhead, Front	35	W10891205	Assembly, Weld Heater Box
10	3934666	Nut, Hex	23	W10211950	Seal, Housing Outlet	36	8557403	Thermostat, High Limit
11	W10508188	Assembly, Drum (Complete)	24	W10211896	Assembly, Lint Duct	37	280148	Kit, Thermal Cut-Off (Includes Thermostat)
12	W10416098	Baffle, Drum	25	W10414388	Clip, Lint Duct	38	8066099	Bracket, Heater Box
13	W10219342	Screw	26	W10653662	Pad, Foam	39	3387230	Screw

DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11114013	Assembly, Outer Door (White)	6	W10288126	Screw	11	9742177	Screw
2	W11122999	Assembly, Inner Door	7	W11050690	Bracket, Door Catch	12	W11114011	Hinge Assembly
3	W11100789	Bracket, Glass	8	W10208401	Assembly, Spring Catch	13	8540479	Screw, Grounding
4	W10891207	Glass, Door	9	W11607784	Cover, Handle			
5	W11183899	Seal, Glass	10	W11607789	Cover, Hinge			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	Paint, Touch-up (White 1/2 oz)
	W10446202	Paint, Touch-up (Chrome Shadow 1/2 oz)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	Paint, Spray (White 12 oz)
	350938	Paint, Spray (Gray Primer 12 oz)

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	Paint, Bulk (White Uncut 1 qt)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	8529894	Kit, Hold Down
	8522199	Kit, Dryer Vent Testing
	80047	Kit, Dryer Repair
	W10315283	Kit, Door Reversing
	W10869845	Kit, Stack
	W10886894	Dry Rack

ACCESSORY PARTS|THE FOLLOWING POWER CORD CAN BE ORDERED. IMPORTANT: CHECK LOCAL WIRING CODE REQUIREMENTS TO SEE IF ONE OF THESE MEETS YOUR NEEDS.

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	PT220L	4', 30 Amp, 3 Wire, Dryer Cord
	PT400L	4', 30 Amp, 4 Wire, Dryer Cord
	PT600L	6', 30 Amp, 4 Wire, Dryer Cord